

AD-A040 795

RCA ADVANCED TECHNOLOGY LABS CAMDEN N J
LANGUAGE MANUAL FOR USE WITH IDEOGRAPHIC COMPOSING MACHINES MOD--ETC(U)
FEB 70

F/G 9/2
DAAG17-68-C-0064
NL

UNCLASSIFIED

1 OF 5
ADA040795



ADA 040795




Language Manual For Use With Ideographic Composing Machines Models AR816 and AR3L

Volume VI. Supplemental List of Characters
Chinese Wade-Giles and Pinyin Pronunciations

9 Feb. 1970

Prepared under
Contract DAAG17-68-C-0064
for
Headquarters, Natick Laboratories
U.S. Army
Natick, Massachusetts



AJ NO. **DDC** FILE COPY
Prepared by
Advanced Technology Laboratories
Defense Electronic Products
Camden, New Jersey

DISTRIBUTION STATEMENT A
Approved for public release;
Distribution Unlimited

Processing (27)	
NTES	White Section <input checked="" type="checkbox"/>
QPS	Blue Section <input type="checkbox"/>
DISTRIBUTION	
BY	
DISTRIBUTION AVAILABILITY CODES	
QPS	Final, Add or Special
A	

After on file

RCA

6

Language Manual For Use With Ideographic Composing Machines Models AR813 and AR3L

Volume VI. Supplemental List of Characters
Chinese Wade-Giles and Pinyin Pronunciations.

Prepared under
Contract DAAG17-68-C-0064
for 15
Headquarters, Natick Laboratories
U.S. Army
Natick, Massachusetts

Prepared by
Advanced Technology Laboratories
Defense Electronic Products
Camden, New Jersey

11 9 Feb 70

12 478p.

405 561

mt

CHINESE WADE-GILES PRONUNCIATION

WADE-GILES PRONUNCIATION IS A11

773	2491	2936	3028	3632	4253	4445	5020	9973
埃	𠂔	挨	𠂔	哎	嚷	唉	哀	欸

WADE-GILES PRONUNCIATION IS A12

2577	8010
捱	皑

WADE-GILES PRONUNCIATION IS A13

127	1075	2075	3132	7152
駭	藹	靄	駭	矮

WADE-GILES PRONUNCIATION IS A14

261	1206	2056	2230	2292	3392	3521	3732	4346	8397
璫	艾	𩇛	碍	礙	𩇛	𩇛	𩇛	𩇛	𩇛
8398	9551	10374							
𩇛	隘	嫫							

WADE-GILES PRONUNCIATION IS ANG1

9160
肮

WADE-GILES PRONUNCIATION IS ANG2

3747
昂

WADE-GILES PRONUNCIATION IS ANG4

4344

𪔐

WADE-GILES PRONUNCIATION IS AN1

909	933	2336	2339	4854	5165	5997	7183	8248	9897
鞍	菴	鵠	鵠	諳	庵	安	𣎵	鉸	𠂇

WADE-GILES PRONUNCIATION IS AN3

3727 7675

𠵽 俺

WADE-GILES PRONUNCIATION IS AN4

2733	3692	4523	4531	4658	5571	5998	9712
按	暗	黯	黯	岸	𠵽	案	闇

WADE-GILES PRONUNCIATION IS A02

286	287	288	289	291	292	293	294	295	296
敖	鰲	鰲	鰲	鰲	鰲	鰲	熬	遨	熬
297	619	620	621	622	624	625	626	627	628
鰲	敖	鰲	鰲	鰲	鰲	鰲	鰲	熬	遨
629	630	3413	3594	5124	5129	3418	5434	7989	7993
鰲	鰲	遨	遨	廐	廐	廐	廐	翱	翱

WADE-GILES PRONUNCIATION IS A02

7995

翱

WADE-GILES PRONUNCIATION IS A03

6966 6972 10307

袄 袄 媪

WADE-GILES PRONUNCIATION IS A04

5754 6367 6787 7579 7621 8082 9568

懊 澳 燠 傲 傲 奥 奥

WADE-GILES PRONUNCIATION IS A1

4411 10252

阿 丫

WADE-GILES PRONUNCIATION IS A4

9506

阿

WADE-GILES PRONUNCIATION IS BA04

2920

报

WADE-GILES PRONUNCIATION IS CHIA11

2812 8321 8324

拆 钹 钹

WADE-GILES PRONUNCIATION IS CHIAI2

3189 7835 7846 8421 8971
柴 儕 儕 豺 豺

WADE-GILES PRONUNCIATION IS CHIAI4

1030

蔓

WADE-GILES PRONUNCIATION IS CHIANG1

1024 3652 5559 7564 7610 7738 8980 9700 10306
葛 昌 閻 張 張 張 猖 閻 娼

WADE-GILES PRONUNCIATION IS CHIANG2

8 426 793 857 983 3032 3311 3313 3318 4013
長 長 莨 莨 莨 長 嘗 嘗 常 嘗
7543 7748 7749 8623 9129 10300
长 償 償 徜 腸 嫦

WADE-GILES PRONUNCIATION IS CHIANG3

562 677 2105 2163 3309 3310 3322 3860 5176 5668
場 場 厂 廠 敞 斃 嘗 蹠 廠 愴
7029
昶

WADE-GILES PRONUNCIATION IS. CHIANG4

3637	4023	5598	5806	5862	7781	9409
暢	唱	悵	悵	悵	倡	營

WADE-GILES PRONUNCIATION IS. CHIANG1

904	915	2823	2824	2825	2826	2828	2830	2934	2937
韌	韌	攪	攪	攪	攪	挽	挽	摻	摻
4078	4601								
韞	韞								

WADE-GILES PRONUNCIATION IS. CHIANG2

2176	3646	3804	4169	4200	4224	4357	4358	4359	4360
塵	躔	躔	蟬	蟬	蟾	曉	曉	曉	曉
4723	4724	4725	4726	4928	4929	4930	4931	4932	4933
曉	曉	曉	曉	讒	讒	讒	讒	讒	讒
5178	6482	6892	7040	7041	8295	8296	8297	8298	8309
塵	潺	禪	詭	詭	饒	饒	饒	饒	饒
8510	8511	8512	8513	8514	8576	8577	9825	10035	10101
饒	饒	饒	饒	饒	饒	饒	孱	纏	纏
10102	10245	10314	10347						
纏	纏	嬋	嬋						

WADE-GILES PRONUNCIATION IS CHIAN3

949	2938	4935	4945	5083	5085	5086	5472	5473	5579
歲	剗	詔	詔	产	産	剗	産	剗	闌
6683	6883	8228	8243	9705					
輓	禪	鏹	鏹	闌					

WADE-GILES PRONUNCIATION IS CHIAN4

4922	4923	5739	5758	5759	9809
識	識	忤	懺	懺	羣

WADE-GILES PRONUNCIATION IS CHIAO1

533	2899
超	抄

WADE-GILES PRONUNCIATION IS CHIAO2

1308	3446	3447	3636	3735	3763	4797	6067	10430
朝	鼂	鼂	嘲	晁	晁	潮	潮	巢

WADE-GILES PRONUNCIATION IS CHIAO3

4417	6808
吵	炒

WADE-GILES PRONUNCIATION IS CHIAO4

8325

鈔

WADE-GILES PRONUNCIATION IS CH'AI

1729	1736	2768	2772	2773	2890	2893	9484	9623
杈	杈	插	插	插	杈	杈	叉	叉

WADE-GILES PRONUNCIATION IS CH'IA2

1270	1453	1535	1619	1622	2549	5925	7123	8270	8274
茶	楂	查	槎	槎	搽	察	鎗	鎗	鍾
8275	8860								
鎗	簪								

WADE-GILES PRONUNCIATION IS CH'IA3

3634
躋

WADE-GILES PRONUNCIATION IS CH'IA4

4124	4868	6454	6460	6521	6534	6983	6984	7853	9377
蜡	詭	汙	汙	差	差	衩	衩	侘	刹
9429									
岔									

WADE-GILES PRONUNCIATION IS CH'ENG1

2621	2624	3432	4113	4114	4120	4121	7244	7290	7302
撐	撐	瞠	螳	螳	螳	螳	稱	称	稱

WADE-GILES PRONUNCIATION IS CHIENG1

7306

称

WADE-GILES PRONUNCIATION IS CHIENG2

499	555	590	1383	1407	1722	1966	1975	2455	3398
城	埕	埕	棖	棖	橙	醒	醒	成	呈
4309	4813	6231	6448	6939	6948	7262	7269	8606	8632
呈	誠	徵	澄	程	程	程	程	懲	懲
9182	9489	9602							
滕	承	丞							

WADE-GILES PRONUNCIATION IS CHIENG3

88	3097	3409	4311
騁	騁	逞	逞

WADE-GILES PRONUNCIATION IS CHIENG4

7198	7243
乘	秤

WADE-GILES PRONUNCIATION IS CHIEN1

1462	2638	2657	3635
榔	揀	揆	嗔

WADE-GILES PRONUNCIATION IS CHIEN2

WADE-GILES PRONUNCIATION IS CHIEN2

141	1283	1284	1519	1896	2112	3357	3474	4784	5407
辰	陳	陈	楨	臣	辰	晨	晨	謹	塵
5423	5734	5827	5861	6322	6323	9503	9524	9640	
塵	忱	宸	宸	沈	沉	陳	陈	尘	

WADE-GILES PRONUNCIATION IS CHIEN3

2238	2293	2294
磳	磳	磳

WADE-GILES PRONUNCIATION IS CHIEN4

527	531	536	1576	3179	6930	6953
趯	趯	趯	覩	齟	衬	覩

WADE-GILES PRONUNCIATION IS CHIE1

1769
車

WADE-GILES PRONUNCIATION IS CHIE3

2609
扯

WADE-GILES PRONUNCIATION IS CHIE4

704	1774	1775	1777	1778	1802	2708	6281	7118	8617
圻	輒	輒	輒	輒	輒	撤	澈	掣	彻

WADE-GILES PRONUNCIATION IS CHIE4

8618 8642 9931

徹 徹 少

WADE-GILES PRONUNCIATION IS CHIANG1

1711 1719 3871 3872 4197 4629 6541 6542 8219 8220

槍 枪 踰 踰 蜺 戕 羌 羗 鏘 鏘

8319 9168

鎗 腔

WADE-GILES PRONUNCIATION IS CHIANG2

475 497 881 957 1497 4622 4628 8697 8733 9854

牆 墙 蓄 蓄 槽 升 牆 牆 牆 疆

9362 9883 10291

强 强 牆

WADE-GILES PRONUNCIATION IS CHIANG3

2879 6942 6993 8335 8336 10209 10211

搶 襁 襁 鋺 鋺 緝 緝

WADE-GILES PRONUNCIATION IS CHIANG4

4406

嗆

WADE-GILES PRONUNCIATION IS CHIAD1

WADE-GILES PRONUNCIATION IS CHIIA01

2185	2762	3824	3904	3905	5011	7285	7289	8271
蹺	撬	蹺	蹺	蹺	敲	幫	鏊	鍬

WADE-GILES PRONUNCIATION IS CHIIA02

456	459	1072	1173	1174	1636	1642	1643	3481	3749
堯	翹	莪	蕎	莽	撬	橋	桥	瞧	焦
7512	7513	7817	7893	7894					
喬	乔	顚	僑	侨					

WADE-GILES PRONUNCIATION IS CHIIA03

504	5669
巧	悄

WADE-GILES PRONUNCIATION IS CHIIA04

906	4677	4704	4705	4830	4912	5934	5961	7752
鞘	峭	嶠	峯	諂	譙	窈	竅	俏

WADE-GILES PRONUNCIATION IS CHIIA1

2836	2833
招	招

WADE-GILES PRONUNCIATION IS CHIIA3

3152
卡

WADE-GILES PRONUNCIATION IS CH'IA4

5777 6435

恰 洽

WADE-GILES PRONUNCIATION IS CH'IEH1

2946 2980

切 切

WADE-GILES PRONUNCIATION IS CH'IEH2

1245

茄

WADE-GILES PRONUNCIATION IS CH'IEH3

3351

且

WADE-GILES PRONUNCIATION IS CH'IEH4

59 333 4261 5109 5604 5611 5940 5941 5966 5967
 挈 匿 唛 妾 愜 怯 窈 窈 竊 竊

5968 7334 8119
 竊 篋 鍬

WADE-GILES PRONUNCIATION IS CH'IEH1

901 902 1161 1938 1940 2352 2564 2565 2763 4296
 韃 韃 芊 遷 遷 牽 擥 擥 扞 兼

WADE-GILES PRONUNCIATION IS CHIEN1

4878	4879	5512	5523	5636	5835	5838	5842	5844	7193
謙	謙	牽	牽	慳	騫	騫	褰	褰	千
7226	7469	7470	7485	7486	7882	8264	8312	8330	8644
迂	籤	籤	簽	簽	仟	針	鉛	鋟	愆
9383	9558								
餼	阡								

WADE-GILES PRONUNCIATION IS CHIEN2

1314	2537	2757	3247	3249	4532	4535	6017	6146	6660
軋	柑	捐	虔	虔	黔	黔	潛	潛	前
7390	8140	8173	8317						
柑	鉗	錢	鈐						

WADE-GILES PRONUNCIATION IS CHIEN3

3962	3992	4837	4840	6138	8469	8470	10078	10080
遣	遣	譴	譴	淺	髓	髓	縊	縊

WADE-GILES PRONUNCIATION IS CHIEN4

933	1178	1222	1814	1815	4644	5726	6665	7578	8765
茜	倩	苒	塹	塹	嵌	慊	歉	倩	欠
10107	10110	10136	10247						
緯	緯	紆	紆						

WADE-GILES PRONUNCIATION IS CH'IH1

3376	3542	3600	4102	4186	4317	4441	4651	7506	8047
喫	眈	哧	嗤	螭	吃	嗤	蚩	咎	魑
9052	9394	9932	10194	10323	10423				
鴟	郗	蚩	絺	媼	媼				

WADE-GILES PRONUNCIATION IS CH'IH2

124	752	753	2525	3129	3418	3899	5290	5350	6496
馬也	墀	墀	持	馳	匙	跣	痴	癡	池
7387	7400	7471	9783	9787	9808	9880			
簾	簾	簾	遲	遲	迟	弛			

WADE-GILES PRONUNCIATION IS CH'IH3

390	402	792	808	1914	3166	3180	4432	6629	6927
耻	恥	耻	恥	鼓	齒	齒	呖	粃	褫
6974	7929	9831							
褫	侈	尺							

WADE-GILES PRONUNCIATION IS CH'IH4

714	1765	1874	1877	2372	3853	4444	5121	7928	8496
赤	翅	敕	勅	勅	跽	叱	啻	僚	飭
8592	8601								
斥	彳								

WADE-GILES PRONUNCIATION IS CHING1

277	278	1792	4110	6012	6013	7172	7173	7690	7728
青	青	輕	蜻	清	清	氙	氫	傾	傾
8106	8778	9064							
傾	鯖	卿							

WADE-GILES PRONUNCIATION IS CHING2

1251	1254	3365	3366	4522	4530	5599	5600
擎	擎	晴	晴	黥	黥	情	情

WADE-GILES PRONUNCIATION IS CHING3

2945	2979	4761	4762	9940
頃	頃	請	請	頃

WADE-GILES PRONUNCIATION IS CHING4

763	764	765	5164	5438
磬	磬	磬	庆	慶

WADE-GILES PRONUNCIATION IS CHIN1

122	3128	4717	5046	5047	8015	8294	9417
駸	駸	欽	亲	親	侵	欽	衾

WADE-GILES PRONUNCIATION IS CHIN2

133	137	152	157	889	890	1216	1273	1709	2793
秦	秦	琴	琴	勤	勤	芹	苓	檣	揜

WADE-GILES PRONUNCIATION IS CHI'IN2

2874 4108 4109 4402 9408
擒 螭 螭 噙 禽

WADE-GILES PRONUNCIATION IS CHI'IN3

5880 5894
寢 寢

WADE-GILES PRONUNCIATION IS CHI'IN4

2794 2877 4303 4421 6331
揶 揶 吡 噤 沁

WADE-GILES PRONUNCIATION IS CHI'UNG2

229 266 267 268 269 736 737 745 1345 5964
琮 瓊 瓊 瓊 瓊 楚 蛭 邛 芎 窮
5974 6768 6769 7364
窈 熒 熒 邛

WADE-GILES PRONUNCIATION IS CHI'UNG3

5982
穹

WADE-GILES PRONUNCIATION IS CHI'U1

684 910 1164 1640 4217 6778 7282 7288 7608 7628
丘 鞫 萩 楸 蚯 炆 秋 鶩 丘 邱

WADE-GILES PRONUNCIATION IS CHI1U1

8816 8820
鱖 鮓

WADE-GILES PRONUNCIATION IS CHI1U2

181 2496 2497 2498 3499 4244 4245 4541 6226 6639
球 求 裘 逌 賕 蚪 虬 囚 洵 酋
6647 7165 7689
適 毬 球

WADE-GILES PRONUNCIATION IS CHI1U3

6615 8501
糗 餽

WADE-GILES PRONUNCIATION IS CHI11

818 820 974 1510 2148 2151 2326 2961 2975 3717
欺 期 萋 棲 慼 慼 敔 妻 七 噦
4666 4719 5647 5659 6081 6137 6139 6144 6145 6379
崎 嶇 慼 悽 漆 沕 淒 柒 沕 溪
7058 8438 10253
淒 谿 𡿨

WADE-GILES PRONUNCIATION IS CHI12

13 68 80 167 177 430 496 703 731 811
髻 騏 騎 琪 琦 髻 琦 圻 耆 其

WADE-GILES PRONUNCIATION IS CH112

814	815	821	875	1041	1237	1429	2325	3035	3079
基	基	綦	其	蕲	芪	棋	奇	髻	騏
3091	3191	3800	3835	3848	4122	4648	5111	5408	5424
騎	歧	畦	跂	踦	蜞	岐	齊	麒	麒
5443	5454	5481	5484	6040	6859	6898	6899	6900	6903
旗	旂	齊	齊	淇	祺	祈	祈	祇	祁
8165	8587	8782	9149	9161					
錡	頤	鰭	臍	臍					

WADE-GILES PRONUNCIATION IS CH113

537	1748	2287	4652	4743	4744	7006	7010	7011	7019
起	杞	啓	豈	岂	屺	啓	启	啟	檠
7020	7022	7559	10039						
啓	檠	乞	綺						

WADE-GILES PRONUNCIATION IS CH114

57	2149	2175	2218	2220	4052	4061	4063	4708	4905
契	戚	磧	砌	砌	噐	噐	噐	屹	訖
5509	5510	5511	6245	6337	7171	7185	7216	7222	7560
弃	棄	棄	泣	汽	气	氣	憇	憇	迄
9404	10067	10068							
企	緝	緝							

WADE-GILES PRONUNCIATION IS CH'OU1

2651 2838 2856 5349
抽 搗 搗 瘳

WADE-GILES PRONUNCIATION IS CH'OU2

1982 1986 3795 3799 3801 3814 3821 3826 3827 5772
酎 酎 畴 畴 畴 踣 踣 踣 踣 惆
7286 7312 7347 7355 7363 7567 7596 7626 7815 7821
愁 稠 筹 筹 筹 俦 俦 俦 讎 讐
7949 10075 10180
仇 紬 綢

WADE-GILES PRONUNCIATION IS CH'OU3

1995 3476 3477 3568 9884
醜 瞅 瞋 瞋 丑

WADE-GILES PRONUNCIATION IS CH'OU4

7978

臭

WADE-GILES PRONUNCIATION IS CH'OU1

6000 6997 8684 9913
之 之 走 戳

WADE-GILES PRONUNCIATION IS CHIO4

1834 2005 3169 4415 9636 10056
輟 𪗇 齧 啜 𪗇 綽

WADE-GILES PRONUNCIATION IS CHIUAI1

2580 2816
𢶏 𢶏

WADE-GILES PRONUNCIATION IS CHIUAI3

2675
𢶏

WADE-GILES PRONUNCIATION IS CHIUAI4

3873
𢶏

WADE-GILES PRONUNCIATION IS CHIUANG1

5326 5329 5949 5962 5963 5983 7726
瘡 瘡 窓 窗 窓 窓 牕

WADE-GILES PRONUNCIATION IS CHIUANG2

4589 4626 5142 5207
幢 牀 床 𢶏

WADE-GILES PRONUNCIATION IS CHIUANG3

WADE-GILES PRONUNCIATION IS CHUANG3

5567 9674 9696
闯 闖 闖

WADE-GILES PRONUNCIATION IS CHUANG4

4996 5781 6550 6551 8447
翔 愴 翔 報 創

WADE-GILES PRONUNCIATION IS CHUAN1

5942 7736 10429
穿 川 川

WADE-GILES PRONUNCIATION IS CHUAN2

1757 4665 7647 8717 8726 8753 8762
椽 遄 傳 船 船 船 船

WADE-GILES PRONUNCIATION IS CHUAN3

6104 8846
喘 舛

WADE-GILES PRONUNCIATION IS CHUAN4

4056 8278
串 釧

WADE-GILES PRONUNCIATION IS CHUI1

4355 6792
吹 炊

WADE-GILES PRONUNCIATION IS CHIUI2

1651 1664 2759 2792 7104 7446 8261 8288 9557
椎 槌 捶 搥 垂 簋 錘 鎚 陞

WADE-GILES PRONUNCIATION IS CHIUNG1

138 2506 5514 5681 5709 6202 7064 8653
春 搯 充 忡 憧 冲 冲 衝

WADE-GILES PRONUNCIATION IS CHIUNG2

4105 4170 4696 7265
虫 蟲 崇 种

WADE-GILES PRONUNCIATION IS CHIUNG3

5896 5897 6835 6836
寵 寵 寵 寵

WADE-GILES PRONUNCIATION IS CHIUNG4

2770 8244
撞 銃

WADE-GILES PRONUNCIATION IS CHIUN1

135 1389
春 椿

WADE-GILES PRONUNCIATION IS CHIUN2

WADE-GILES PRONUNCIATION IS CHIUN2

143	145	922	1360	1977	2001	2114	2116	5025	6239
唇	脣	蓴	蕬	醇	醅	唇	脣	鶉	漚
6242	10188								
淳	純								

WADE-GILES PRONUNCIATION IS CHIUN3

136
齏

WADE-GILES PRONUNCIATION IS CHIU1

3175	6977	9926
齏	初	出

WADE-GILES PRONUNCIATION IS CHIU2

47	1263	1485	1487	1583	1584	2123	2134	3829	3841
齏	藟	櫛	櫛	櫛	櫛	廚	厨	踖	蹶
3042	3880	3883	4233	5128	5162	6456	8189	8198	8916
蹶	蹶	蹶	蛛	廚	厨	滁	鉏	鋤	𠂔
9302	9303	9304	9585						
芻	雛	鵠	除						

WADE-GILES PRONUNCIATION IS CHIU3

1419	1461	1631	2196	2291	6917	7826
楮	楚	杵	礎	础	褚	儲

WADE-GILES PRONUNCIATION IS CHIU4

365	1301	2709	3252	4533	4536	5521	5626	8874	8875
于	矗	搖	處	黜	黜	畜	怵	触	觸
8897	8898	8943	10217						
触	觸	处	絀						

WADE-GILES PRONUNCIATION IS CHIU1AN1

4539	5799
圈	悛

WADE-GILES PRONUNCIATION IS CHIU1AN2

27	442	1042	1267	1439	1734	3047	3893	4198	5323
鬚	鬚	觀	荃	權	杈	鬚	蹠	蜷	痊
5724	6561	7482	8033	8313	9363	9630			
惓	拳	筌	泉	銓	全	劝			

WADE-GILES PRONUNCIATION IS CHIU1AN3

2345	3806	8949	10126
犬	吠	牙	綣

WADE-GILES PRONUNCIATION IS CHIU1AN4

1046	6562	6563
勸	券	券

WADE-GILES PRONUNCIATION IS CHIUIEH1

7133

缺

WADE-GILES PRONUNCIATION IS CHIUIEH2

5319

癩

WADE-GILES PRONUNCIATION IS CHIUIEH4

601	665	674	778	924	1605	1627	2239	2249	2258
塙	慤	慤	却	鵲	權	權	碯	確	確
2273	2274	2725	2753	5578	5593	8556	9644	9718	9733
确	确	摧	摧	阙	阙	卻	雀	闕	閏

WADE-GILES PRONUNCIATION IS CHIUIH1

9977

逡

WADE-GILES PRONUNCIATION IS CHIUIH2

6987	9744	9745
裙	羣	群

WADE-GILES PRONUNCIATION IS CHIUI1

75	83	532	534	1886	2483	2486	3086	3996	4152
驅	驅	趨	趨	區	區	歧	驅	曲	蛆

WADE-GILES PRONUNCIATION IS CHIUI1

4165	4556	4650	4671	6858	8087	8088	9083	9829
蚰	驱	嶇	岖	祛	軀	軀	肱	屈

WADE-GILES PRONUNCIATION IS CHIUI2

204	993	2369	2370	3441	3442	3443	5255	6064	6141
璩	遽	麥	麴	瞿	毳	鸛	癰	渠	渠
7719	8626	9264	9266						
巨	衢	鵠	劬						

WADE-GILES PRONUNCIATION IS CHIUI3

410	419	832	841	3173
取	娶	取	娶	齣

WADE-GILES PRONUNCIATION IS CHIUI4

518	519	770	3233	3237	5584	9724
趣	趣	去	覷	覷	闕	闕

WADE-GILES PRONUNCIATION IS CHAI1

2693	5115	5471	5483	9980
摘	齋	齋	齋	叁

WADE-GILES PRONUNCIATION IS CHAI2

5916

宅

WADE-GILES PRONUNCIATION IS CHA13

5957

窄

WADE-GILES PRONUNCIATION IS CHA14

3190

些

5312

察

5837

寨

7576

債

WADE-GILES PRONUNCIATION IS CHANG1

232

璋

1578

樟

5058

章

5063

彰

5411

麇

5427

麇

6247

漳

8808

鯮

8993

獐

9849

張

9851

張

9860

張

10330

璋

WADE-GILES PRONUNCIATION IS CHANG3

905

鞫

3320

掌

7948

仇

WADE-GILES PRONUNCIATION IS CHANG4

1503

杖

2480

丈

3455

璋

3484

賬

3490

賬

3502

賬

4567

帳

4571

帳

4577

帳

4588

幃

4694

嶂

5208

瘡

5211

瘡

5246

瘡

5270

瘡

6487

漲

6488

漲

6491

漲

6589

杖

7685

仗

WADE-GILES PRONUNCIATION IS CHANG4

9072 9080 9114 9541
脹 脹 脹 障

WADE-GILES PRONUNCIATION IS CHAN1

2082 3198 3206 3541 3951 4356 4926 5037 5446 5457
霑 沾 覘 瞻 沾 瞻 譚 氈 擅 旃
6161 6594 7166 7167 8473 8769
沾 粘 毡 氈 贍 詹

WADE-GILES PRONUNCIATION IS CHAN3

1813 1835 2906 2959 4649 9773
斬 輓 振 盞 斬 展

WADE-GILES PRONUNCIATION IS CHAN4

826 934 1509 1816 3204 4076 5036 5056 6042 6959
戡 蘸 機 暫 战 戰 顫 站 湛 綻
7740 10112
佔 綻

WADE-GILES PRONUNCIATION IS CHAO1

2847 3750 8186
招 昭 釗

WADE-GILES PRONUNCIATION IS CHAO2

WADE-GILES PRONUNCIATION IS CHAO2

6522 6537 6750 6751
着 着 燭 燭

WADE-GILES PRONUNCIATION IS CHAO3

2600 6411 8388 8679
找 沼 少 爪

WADE-GILES PRONUNCIATION IS CHAO4

524 535 1752 3440 3751 4484 4941 5458 6162 6799
趙 趙 櫟 壘 照 罩 詔 旄 淖 炤
7007 7021 7472 8581 9250 9319
肇 肇 爪 兆 召 兆

WADE-GILES PRONUNCIATION IS CHA1

1754 2534 2931 3649 6078
紮 揸 紮 喳 渣

WADE-GILES PRONUNCIATION IS CHA2

1209 1753 2928 3772 5558 7466 7722 7723 7724 8197
劓 札 扎 晰 阡 劓 插 插 插 鋤
9699
閏

WADE-GILES PRONUNCIATION IS CHA3

WADE-GILES PRONUNCIATION IS CHA3

3535 8818

眨 鮓

WADE-GILES PRONUNCIATION IS CHA4

1561	1608	1697	1983	2728	2764	4210	4283	4310	4316
柵	榨	柵	酢	搾	作	蚱	宅	咋	吒
4896	5291	6777	7195						
詐	瘥	炸	乍						

WADE-GILES PRONUNCIATION IS CHENG1

1294	3524	4718	4920	5307	7468	8132	8290	8434	8605
蒸	睜	嶢	諍	癥	箏	鉦	錚	爭	征
8631	9018	9603							
徵	猙	烝							

WADE-GILES PRONUNCIATION IS CHENG3

1875 2892
整 拯

WADE-GILES PRONUNCIATION IS CHENG4

505	514	2804	4774	4961	5213	6564	6642	7034
正	政	掙	証	證	症	郑	鄭	証

WADE-GILES PRONUNCIATION IS CHEN1

WADE-GILES PRONUNCIATION IS CHEN1

248	265	303	812	816	827	1303	1304	1388	1390
玆	玆	珍	蓁	蓁	斟	真	真	榛	榛
1430	1523	1931	1932	1962	1963	2188	2225	3006	3007
椹	楨	甄	甄	甄	甄	礎	砧	臻	臻
3202	3374	4580	6004	6006	6871	6872	7386	7742	8128
貞	瞋	幘	溱	溱	禎	禎	箴	偵	針
8163									
鍼									

WADE-GILES PRONUNCIATION IS CHEN3

1628	1831	3981	4959	5328	7237	9228	10021	10196
枕	軫	畛	診	疹	稕	胗	縝	紕

WADE-GILES PRONUNCIATION IS CHEN4

1987	2053	2063	2507	2576	3485	3493	6840	6843	8150
醜	震	震	振	振	賑	賑	鵠	鵠	鎮
8151	9178	9179	9502	10256	10288				
鎮	朕	朕	陣	娠	娠				

WADE-GILES PRONUNCIATION IS CHE1

719	4265	5138
螫	噉	遮

WADE-GILES PRONUNCIATION IS CHE2

642	2272	2809	2810	2811	2922	4144	4857	4858	5605
蟄	磔	折	哲	蜇	摺	蜥	謫	適	懾
5612	5793								
懾	懾								

WADE-GILES PRONUNCIATION IS CHE3

688	689	715
者	者	赭

WADE-GILES PRONUNCIATION IS CHE4

564	1092	1491	3845	3881	4886	5139	5480	6136
喆	蔗	柘	跖	蹠	這	鷓	这	浙

WADE-GILES PRONUNCIATION IS CHIANG1

900	925	1913	1918	2402	3337	3338	3932	4630	4634
韁	薑	缸	絳	殭	將	漿	蹌	將	漿
4635	4639	6024	6545	7650	9852	10026			
將	漿	江	姜	僵	疆	疆			

WADE-GILES PRONUNCIATION IS CHIANG3

43	1070	1071	3334	3336	4631	4633	4636	4638	4764
耑	蔣	蔣	漿	獎	漿	獎	漿	獎	講

WADE-GILES PRONUNCIATION IS CHIANG3

4765 7033
講 讲

WADE-GILES PRONUNCIATION IS CHIANG4

2304 3335 4632 4637 6600 6631 6632 7932 9576 9578
匠 醬 醬 醬 糲 糲 糲 倅 降 降
10174
絳

WADE-GILES PRONUNCIATION IS CHIAO1

102 1096 1186 1521 1836 2263 3110 3885 4182 4323
驕 茭 蕉 椒 轆 礁 驕 跤 蛟 焦
4556 5198 5201 6027 6782 7816 7818 7903 8809 9155
駝 交 郊 澆 焦 焦 鷄 焦 蛟 胶
9296 9560 10334 10359 10360
膠 陟 姣 嬌 娇

WADE-GILES PRONUNCIATION IS CHIAO2

1655 4345
樵 嚼

WADE-GILES PRONUNCIATION IS CHIAO3

2774 2775 2779 7153 7154 7612 7838 7907 8012 8025
擣 拈 攪 矯 矯 僥 佼 傲 皎 皦

WADE-GILES PRONUNCIATION IS CHIAO3

8236	8285	8475	8656	8869	8892	8998	9084	9205	10103
較	繳	餃	徼	角	角	狡	腳	腳	絞
10149	10431	10432	10433						
繳	剿	勦	勦						

WADE-GILES PRONUNCIATION IS CHIAO4

712	1799	1810	1952	1994	3002	3813	4275	4439	5958
教	較	轎	酵	醮	轿	叫	叫	叫	窖
9397									
教									

WADE-GILES PRONUNCIATION IS CHIA1

284	570	586	1021	1322	1694	2050	2374	2375	3924
珈	嘉	嘉	葭	葭	枷	夾	郊	夾	跣
5318	5370	7478	7611	7849	7942	9251	9261	9262	
珈	家	茄	佳	傢	伽	加	袈	迦	

WADE-GILES PRONUNCIATION IS CHIA2

959	2172	2203	2373	4143	6127	6929	6979	8168
莢	戛	戛	頰	蛺	浹	袂	袷	鉞

WADE-GILES PRONUNCIATION IS CHIA3

1942	3577	4087	4683	5258	5341	7775	8039	8199	8702
賈	甲	屮	岬	瘥	瘥	假	假	鉀	舛

WADE-GILES PRONUNCIATION IS CHIA3

8738 9130

舢 舢

WADE-GILES PRONUNCIATION IS CHIA4

1599 7279 7659 9254 9255 9259 10339

稼 稼 價 駕 架 駕 嫁

WADE-GILES PRONUNCIATION IS CHIEH1

501 502 2647 2691 2952 2993 3773 3782 5273 5296

堦 堦 揭 接 皆 皆 啐 啐 痰 癰

5348 7249 7252 8603 9521 9523 9591

疔 稽 稽 街 階 階 阶

WADE-GILES PRONUNCIATION IS CHIEH2

687 771 774 775 776 777 1348 1413 1592 1641

截 刳 刳 刳 刳 刳 节 桔 杰 櫛

2253 2526 2528 2601 2616 3389 3396 3421 4760 4775

碣 拮 擷 捷 捷 映 睫 睫 訐 詰

5071 6002 6028 6512 7397 7401 7497 7498 7784 7925

竭 潔 洁 錫 筴 筴 節 節 偈 傑

7926 8847 9606 9899 9921 10008 10294 10299

傑 桀 子 卩 巳 結 婕 婕

WADE-GILES PRONUNCIATION IS CHIEH3

8877	8889	8888	8900	8908	8911	10302
解	解	解	解	解	解	姐

WADE-GILES PRONUNCIATION IS CHIEH4

354	795	1276	2472	3980	4237	4766	5327	7629	7964
戒	藉	芥	沏	界	蚧	誠	疥	借	价
8565	9423	9764	9770	9790					
沏	介	屈	屈	屈					

WADE-GILES PRONUNCIATION IS CHIEN1

895	1116	1121	1488	1901	1906	2420	2424	2425	2466
艱	菅	菅	械	監	堅	歼	殲	殲	僊
2469	2957	3283	3285	5557	6310	6661	6664	6666	6667
僊	莖	監	堅	间	湔	煎	鷄	兼	兼
7025	7396	8562	8564	8788	9637	9641	9698	10034	10130
肩	箋	濫	謙	鯁	艰	尖	間	緘	縑
10257	10427								
奸	姦								

WADE-GILES PRONUNCIATION IS CHIEN3

491	1047	1064	1065	1141	1543	1705	1948	2207	2284
域	蚩	繭	繭	戩	覷	檢	柬	碱	硷

WADE-GILES PRONUNCIATION IS CHIEN3

2567	2606	2871	3014	3214	3215	3816	3818	4876	4877
揀	揀	檢	戩	鹵	鹵	趺	趺	謫	謫
5040	5841	6116	6662	6663	7056	7410	7432	7494	7718
蹇	蹇	減	剪	翦	減	覓	簡	簡	戔
7954	8329	8355							
儉	鐳	銅							

WADE-GILES PRONUNCIATION IS CHIEN4

946	1098	1473	1903	3284	3501	3547	3851	4551	4805
荐	薦	檻	鑒	鑒	賤	見	踐	见	諫
6085	6119	6183	6285	6472	7170	7442	7540	7589	7729
漸	游	濺	洵	澗	鍵	箭	捷	僭	僭
7878	7976	8156	8326	8364	8367	8368	8461	8695	8701
件	健	鑑	鍵	劍	劍	劍	錢	艦	靦
8704	8731	8737	8740	9232	9657				
靦	艦	靦	靦	腭	建				

WADE-GILES PRONUNCIATION IS CHIH1

1149	1464	1673	1674	1764	2533	2744	4209	6023	6901
芝	枝	梔	梔	支	摺	擲	蚰	汁	祇
6998	7146	7824	8599	8600	9095	9212	9238	9925	10097
之	知	隻	卮	卮	肢	胝	脂	出	織

WADE-GILES PRONUNCIATION IS CHIH1

10244

织

WADE-GILES PRONUNCIATION IS CHIH2

395	397	639	647	801	803	1300	1315	1442	1443
职	職	執	繫	职	職	直	直	植	植
2400	2401	2698	2859	3894	7638	7639	7734	10297	
殖	殖	撫	執	躑	值	值	侄	姪	

WADE-GILES PRONUNCIATION IS CHIH3

512	987	1556	2929	3160	3279	3855	4339	5795	6154
址	芷	枳	指	止	耑	趾	只	怡	汜
6869	6870	8931	9050	9526	9833	9941	10179		
祉	祉	父	帑	陟	咫	旨	紙		

WADE-GILES PRONUNCIATION IS CHIH4

641	644	645	676	1515	1791	3005	3009	3011	3012
執	摯	鷲	志	桎	輕	至	致	致	邳
3915	4147	4476	4477	4586	4590	4596	4642	4780	5125
躑	蛭	置	置	帟	幟	帙	峙	誌	袞
5212	5214	5623	5624	5643	5855	5943	6056	6060	6500
痔	痣	懷	懷	懷	寘	窒	滯	滯	治

WADE-GILES PRONUNCIATION IS CHIH4

6730	6739	7116	7117	7148	7155	7294	7297	7325	7326
炽	熾	制	製	智	雉	秩	稚	穉	穉
7327	8414	8590	8591	8595	8853	8873	8880	8896	8903
穉	豸	質	质	質	炙	斛	斛	斛	斛
9169	9527	9528	9529	9593	9594	9985	9986	10049	10050
臙	陟	隲	隲	隲	隲	彘	彘	緻	緻

WADE-GILES PRONUNCIATION IS CHING1

845	847	1250	1252	3355	3659	5030	5449	5704	6148
菁	荊	驚	驚	晴	晶	京	旌	惊	涇
6572	6573	8807	10053						
精	精	鯨	經						

WADE-GILES PRONUNCIATION IS CHING3

221	321	1253	3018	3687	5678	5931	7636	9493
璟	井	警	璽	景	憬	甯	倣	阱

WADE-GILES PRONUNCIATION IS CHING4

279	281	609	979	1249	1337	3017	3019	3020	3854
靚	靜	境	莖	敬	競	頸	逕	勁	踴
5041	5042	5072	5077	5078	5245	6378	7050	7071	8227
靖	靖	竟	竟	競	瘳	淨	清	淨	鏡

WADE-GILES PRONUNCIATION IS CHING4

8619 8994 9112
徑 獍 脛

WADE-GILES PRONUNCIATION IS CHIN1

4565 6467 6920 6981 7477 8118 8586 8884 8907 9413
巾 津 襟 衿 筋 金 斤 勛 勛 今
9462 10195
矜 紵

WADE-GILES PRONUNCIATION IS CHIN3

169 887 888 1435 1904 1911 2128 3286 4787 5133
瑾 堇 覲 槿 緊 緊 厖 紧 謹 厖
7630 7969 8005 8056 8284 9604
僅 仅 儘 佟 錦 𪔐

WADE-GILES PRONUNCIATION IS CHIN4

330 914 1140 1316 1447 2399 2548 2605 3013 3536
进 靳 晋 藎 禁 殓 搢 搢 晉 贐
3648 5899 6474 6809 6812 7053 7819 8452 8593 9666
噤 寢 浸 燼 烜 凜 進 饑 近 賁
9667 9834 10020 10051 10391
盡 尽 緡 緡 矜

WADE-GILES PRONUNCIATION IS CHIUNG1

599 4562
垌 𠂔

WADE-GILES PRONUNCIATION IS CHIUNG3

4605 5980 6733 6734 7016 8098 10088
迥 窘 炯 炆 尙 迥 絢

WADE-GILES PRONUNCIATION IS CHIU1

195 196 197 198 199 200 540 2769 3146 3147
𪛗 𪛗 𪛗 𪛗 𪛗 𪛗 𪛗 𪛗 𪛗 𪛗
3143 3149 3150 3151 4313 5977 6341 7287 9343 9923
𪛗 𪛗 𪛗 𪛗 𪛗 𪛗 𪛗 𪛗 𪛗 𪛗
10055 10216 10218
糾 糾 糾

WADE-GILES PRONUNCIATION IS CHIU3

272 985 996 3060 3261 6103 8930 8941 9325
玖 菲 菲 韭 韭 酒 久 灸 九

WADE-GILES PRONUNCIATION IS CHIU4

1187 1500 1650 2449 2499 3287 5031 5033 5313 5404
舊 柩 柏 𪛗 𪛗 𪛗 𪛗 𪛗 𪛗 𪛗

WADE-GILES PRONUNCIATION IS CHIU4

7700	7704	7830	8944	8946
臼	舅	僦	咎	咎

WADE-GILES PRONUNCIATION IS CHI1

215	317	344	813	819	1087	1088	1701	1759	1837
勸	璣	击	基	碁	璿	璿	机	機	擊
1885	2296	2327	2328	2362	3208	3590	3610	3805	3817
賣	磯	敲	剝	賈	乚	咭	嚙	畸	蹟
3878	3887	4424	4455	4472	4473	4474	4989	5112	5113
躋	跻	唧	噤	羈	羈	羈	譏	齏	齏
5114	5292	6363	7232	7246	7247	7270	7349	7352	7366
齏	癘	激	積	嵇	稽	积	筭	筭	箕
7526	8436	8437	8521	8522	8531	8578	8871	8894	9223
犄	雞	鷄	飢	飢	饑	飢	騎	騎	肌
9324	9626	9627	9628	9820	9998	10232	10275		
几	鷄	鸡	鸡	屐	績	幾	姬		

WADE-GILES PRONUNCIATION IS CHI2

552	710	1097	1231	1518	1547	1548	1549	1550	1687
吉	圾	蒺	芟	極	楫	檝	楫	檝	极
1733	2020	2405	2434	3025	4241	4728	5277	5288	5289
極	棘	殛	殛	亟	螂	岌	瘠	瘠	疾

WADE-GILES PRONUNCIATION IS CH12

5804	5877	6403	7072	7344	7345	7474	7616	7812	7930
鵲	寂	汲	鵲	籍	籍	笈	佶	集	汲
8915	8917	9597	9755	9756	10170				
及	急	亟	即	即	級				

WADE-GILES PRONUNCIATION IS CH13

1306	2692	2707	3200	4246	5160	5420	5436	5805	7073
戟	擠	擠	戟	蟻	度	麂	麂	脊	脊
9838	10233								
己	幾								

WADE-GILES PRONUNCIATION IS CH14

12	84	429	884	1089	1102	1223	1796	1797	1933
髻	驥	髻	芰	薺	薺	薊	輯	輯	羈
1934	1935	2077	2080	2555	3034	3093	3158	3583	3609
霸	羈	霽	霽	技	髻	驥	冀	戢	戢
3086	3944	4655	4770	4967	5110	5294	5387	5482	5485
跡	跽	覬	計	記	劑	瘳	迹	劑	劑
5627	5742	5867	6255	6275	6276	6360	7266	7323	7643
伎	悒	寄	濟	濟	濟	洎	稷	季	伎
8332	8859	9496	9573	9655	9751	9752	9754	9843	9984
鯽	祭	际	際	丑	既	既	暨	忌	仝

MADE-GILES PRONUNCIATION IS CHI4

10127 10208 10224 10246 10276 10335 10415

繼 紀 繼 继 妓 嫉 媳

MADE-GILES PRONUNCIATION IS CHOU1

3532 4378 6313 6690 7918 7919 8692 8728 9119 9121

賙 啣 洲 州 侑 侑 舟 舟 周 週

9867

粥

MADE-GILES PRONUNCIATION IS CHOU2

1798 10309

軸 妯

MADE-GILES PRONUNCIATION IS CHOU3

7495 9110 9741

箒 肘 帚

MADE-GILES PRONUNCIATION IS CHOU4

3977 4091 4092 4843 5887 7283 7284 7394 8919 9305

胄 呪 咒 詭 宙 瓠 瓠 籀 皺 皺

9659 9832 10043 10186 10249

晝 昼 紂 紂 纒 纒

MADE-GILES PRONUNCIATION IS CHOI

WADE-GILES PRONUNCIATION IS CH01

1522	2655	2924	3199	3201	6132
棹	捉	拙	卓	桌	涿

WADE-GILES PRONUNCIATION IS CH02

178	1352	1501	2000	2269	2921	3603	3621	3745	3858
琢	茁	楮	酌	斫	擢	斲	斲	啄	蹕
4812	6216	6224	6497	6800	7741	8213	9054		
詠	浊	濁	濯	灼	倬	鐸	斲		

WADE-GILES PRONUNCIATION IS CHUAI3

3886
踈

WADE-GILES PRONUNCIATION IS CHUAI4

2649
拽

WADE-GILES PRONUNCIATION IS CHUANG1

1069	1391	1532	3330	3339	4625	4640	5126	6601
莊	椿	桩	装	妝	裝	妝	庄	粧

WADE-GILES PRONUNCIATION IS CHUANG4

2628	3329	3331	4623	4627	5062	5065
撞	壯	狀	壯	狀	戇	戇

WADE-GILES PRONUNCIATION IS CHUAN1

378 1844 1845 1846 2197 4663 4664
專 專 甄 甄 磚 端 顚

WADE-GILES PRONUNCIATION IS CHUAN3

3654

轉

WADE-GILES PRONUNCIATION IS CHUAN4

1762 2915 3510 3517 4968 7505 8526
轉 撰 賄 賺 譔 篆 饌

WADE-GILES PRONUNCIATION IS CHUA1

2658 2817

過 抓

WADE-GILES PRONUNCIATION IS CHUI1

105 3113 7809 8061 8279

雛 雛 佳 追 雛

WADE-GILES PRONUNCIATION IS CHUI4

290 623 2259 3701 8525 9555 9556 10152 10201

贅 贅 碰 喘 餞 墜 墜 緹 綴

WADE-GILES PRONUNCIATION IS CHUNG1

WADE-GILES PRONUNCIATION IS CHUNG1

1879	3792	4006	4035	5006	8203	8226	8273	8354	8940
衷	中	盅	忠	衷	鍾	鐘	鍾	钟	蝨

10176
終

WADE-GILES PRONUNCIATION IS CHUNG3

662	3902	6831	7295	9132	9197
塚	踵	冢	種	肿	腫

WADE-GILES PRONUNCIATION IS CHUNG4

4494	4495	4498	4499	7332	7785	8071	8072	8074	8075
眾	眾	眾	眾	重	仲	眾	眾	眾	眾

8557
众

WADE-GILES PRONUNCIATION IS CHUN1

4652	5975	9222
諄	寔	肫

WADE-GILES PRONUNCIATION IS CHUN3

6357	7069	7070	7810	7811
準	准	準	隼	鷄

WADE-GILES PRONUNCIATION IS CHU1

WADE-GILES PRONUNCIATION IS CHU1

251	1138	1565	1632	2260	2441	2442	4208	4781	4782
珠	菜	櫛	株	硃	豬	𧈧	蛛	諸	諸
4894	6133	6335	7113	7880	8262	8956			
誅	潚	洙	朱	侏	銖	猪			

WADE-GILES PRONUNCIATION IS CHU2

1564	2444	3869	6729	6732	7227	7228	7341	7342	7361
朮	逐	躅	烛	燭	竹	竹	竹	竺	瓠
8957									
猪									

WADE-GILES PRONUNCIATION IS CHU3

691	692	2679	3564	3565	4427	4428	4430	4755	4990
煮	煮	拄	矚	矚	囁	囁	囁	、	主
5410	5426	6032							
塵	塵	渚							

WADE-GILES PRONUNCIATION IS CHU4

93	697	865	866	1115	1566	1726	3102	3515	3544
駐	翥	著	著	苧	柱	杼	駐	貯	助
4179	4850	5082	5872	6237	6736	6884	6885	7359	7362
蛀	註	苧	宁	注	炷	祝	祝	箸	築

WADE-GILES PRONUNCIATION IS CHU4

7409 7827 7850 8120 8127 8137 8349 10115
筋 住 佇 鑄 鑄 鑄 鑄 紵

WADE-GILES PRONUNCIATION IS CHUIAN1

2666 4379 6219 6657 8222 8280 8281 10317
捐 鵲 涓 蠟 鐫 鐫 鐫 娟

WADE-GILES PRONUNCIATION IS CHUIAN2

4953
詮

WADE-GILES PRONUNCIATION IS CHUIAN3

1623 2740 8250 8487
捲 捲 鏢 餒

WADE-GILES PRONUNCIATION IS CHUIAN4

3464 4488 5689 6557 6566 7864 8988 8989 10085
睽 胃 帽 眷 卷 倦 狷 獮 絹

WADE-GILES PRONUNCIATION IS CHUIEH1

3733 4290 4291
噉 嗟 嗟

WADE-GILES PRONUNCIATION IS CHUIEH2

151 307 956 1496 1683 1685 2354 2355 2356 2588
玗 玦 蕨 椶 桷 桷 厥 厥 檠 擲

WADE-GILES PRONUNCIATION IS CHUIEH2

2635	2909	2912	3444	3849	3864	3984	4741	4963	4985
攪	扶	拙	矍	蹶	躩	噓	岨	譎	訣
5284	5782	5816	5818	6481	6789	7090	7592	8003	8054
癩	燭	覓	覓	決	燭	決	覺	馱	佢
8167	8195	8334	8395	8396	8891	8914	8968	8977	9605
鋤	矍	缺	爵	爵	缺	缺	獺	攫	子
9814	10171								
鳩	絕								

WADE-GILES PRONUNCIATION IS CHUIN1

725	4340	5409	5425	6826	6829	8306	9743
均	困	麇	麇	軍	鞞	鈞	君

WADE-GILES PRONUNCIATION IS CHUIN3

932	1062
蕈	菌

WADE-GILES PRONUNCIATION IS CHUIN4

128	3133	3994	4747	5108	6164	6501	7806	7807	7814
駿	駿	駿	峻	竣	濬	浚	僞	僞	雋
7823	7902	7904	8112	8530	9746				
隼	僞	僞	俊	餽	郡				

WADE-GILES PRONUNCIATION IS CHU11

109	525	919	1000	2229	2848	3117	3479	5253	6990
駒	趯	鞠	苴	𠵽	拘	駒	睢	疽	裾
7770	8974	9775							
俱	狙	居							

WADE-GILES PRONUNCIATION IS CHU12

918	1258	1728	2849	2850	3943	4944	7645	8053	9279
鞠	菊	橘	掬	掬	跼	詢	佢	佢	菊
9028									
局									

WADE-GILES PRONUNCIATION IS CHU13

1049	1465	1511	3168	3908	4037	5808	6177	7143	7145
莒	柜	柜	齟	踣	咀	举	沮	矩	矩
7571	7572	7574	7603	7605					
舉	舉	舉	舉	舉					

WADE-GILES PRONUNCIATION IS CHU14

411	414	415	418	554	833	836	837	840	885
聚	聚	聚	聚	埧	聚	聚	聚	聚	苴
975	1767	1964	2556	2602	2613	2907	2973	3228	3229
苴	巨	釀	拒	拒	據	据	巨	劇	遽

WADE-GILES PRONUNCIATION IS CHU14

3383	3836	3852	3942	4799	4817	5672	5673	5884	5900
具	距	距	踞	詎	詎	惧	懼	婁	婁
5946	5954	6578	6592	6702	6713	7239	7250	8051	8153
婁	婁	𡗗	𡗗	炬	炬	𡗗	𡗗	倨	鉅
8174	8178	8333	9252	9346	9776	9822			
鉅	鑠	鋸	句	颶	劓	屨			

WADE-GILES PRONUNCIATION IS E11

10251

ㄣ

WADE-GILES PRONUNCIATION IS E13

3761

ㄣ

WADE-GILES PRONUNCIATION IS EN1

4090 4343 10442 10443

恩 思 ㄣ ㄣ

WADE-GILES PRONUNCIATION IS EN4

2664

摠

WADE-GILES PRONUNCIATION IS ERH2

WADE-GILES PRONUNCIATION IS CHU11

109	525	919	1000	2229	2848	3117	3479	5253	6990
駒	超	鞠	苴	咀	拘	駒	睢	疽	裾
7770	8974	9775							
俱	狙	居							

WADE-GILES PRONUNCIATION IS CHU12

913	1258	1728	2849	2850	3943	4944	7645	8053	9279
鞠	菊	橘	掬	掬	跼	詢	佢	侷	菊
9028									
局									

WADE-GILES PRONUNCIATION IS CHU13

1049	1465	1511	3168	3908	4037	5808	6177	7143	7145
莒	柜	柜	齟	踣	咀	举	沮	矩	矩
7571	7572	7574	7603	7605					
舉	舉	舉	舉	舉					

WADE-GILES PRONUNCIATION IS CHU14

411	414	415	418	554	833	836	837	840	885
聚	聚	聚	聚	埧	聚	聚	聚	聚	苴
975	1767	1964	2556	2602	2613	2907	2973	3228	3229
苴	巨	釀	拒	拒	據	据	巨	劇	遽

WADE-GILES PRONUNCIATION IS ERH2

2305 4321 7707 9047 9311 9318

而 兒 兒 儿 儿 儿

WADE-GILES PRONUNCIATION IS ERH3

161 166 384 788 2042 2045 2051 2341 2344 6025
耳 耳 耳 耳 爾 邇 爾 爾 邇 耳

6039 6845 6846 8449 8451 8766 8767
耳 尔 迤 餌 餌 尔 迤

WADE-GILES PRONUNCIATION IS ERH4

²二 ⁶¹貳 ¹⁴⁶弍

WADE-GILES PRONUNCIATION IS E1

768 5336 9826 10396
古 痾 厠 婀

WADE-GILES PRONUNCIATION IS E2

1175 4215 4315 4706 4707 4884 4914 4919 5930 7538
莪 蛾 哦 莪 峨 譌 訛 譌 額 鵝
7539 7896 10361
鵞 俄 娥

WADE-GILES PRONUNCIATION IS E3

WADE-GILES PRONUNCIATION IS E3

10305

嫫

WADE-GILES PRONUNCIATION IS E4

783	784	1040	1142	1789	1881	2457	2593	2746	3170
堊	惡	萼	惡	輓	噩	厄	扼	搯	齧
3220	3755	3760	4047	4048	4049	4841	5572	5685	7027
夕	遏	呃	顎	鶚	鄂	諤	闕	愕	戾
8497	8498	8787	8803	9137	9517	9713			
餓	餓	鯉	鰐	鵞	阨	闕			

WADE-GILES PRONUNCIATION IS FANG1

1099	1586	5439	10336
芳	枋	方	妨

WADE-GILES PRONUNCIATION IS FANG2

618	7017	8810	9159	9544
坊	房	魴	肪	防

WADE-GILES PRONUNCIATION IS FANG3

23	438	3043	3697	4863	7843	7844	8641	8707	8743
髻	髻	髻	昉	訪	仿	倣	彷彿	舫	舫
10104									
紡									

WADE-GILES PRONUNCIATION IS FANG4

5459

放

WADE-GILES PRONUNCIATION IS FAN1

1131	4599	4600	4602	5453	8537	8540	8541	8542	8543
藩	幡	帆	帆	幡	番	翻	翻	翻	翻

10159
緇

WADE-GILES PRONUNCIATION IS FAN2

702	1215	1459	1713	1714	2283	3912	6709	6791	7550
藩	蕃	梵	樊	樊	矾	蹠	煩	燔	繁

7552	8704	9204	9337
繁	凡	藩	凡

WADE-GILES PRONUNCIATION IS FAN3

2437	2439	8685	8686
反	返	反	返

WADE-GILES PRONUNCIATION IS FAN4

1136	3497	3529	6383	6389	6430	6498	7375	8459	8460
范	販	販	泛	汎	汎	汜	範	飯	飯

WADE-GILES PRONUNCIATION IS FAN4

8506 9042

飯 犯

WADE-GILES PRONUNCIATION IS FA1

7698 9461 9933

伐 發 发

WADE-GILES PRONUNCIATION IS FA2

1649 4490 4491 5583 7453 8575 9723

械 罰 罰 閥 筏 乏 閥

WADE-GILES PRONUNCIATION IS FA3

18 434 3039 6036

髮 髮 髮 法

WADE-GILES PRONUNCIATION IS FA4

164 243 2186

珐 珐 砧

WADE-GILES PRONUNCIATION IS FEI1

2067 2068 3059 3260 3796 3997 7008 7009 9954 9955

霏 霏 非 非 啡 啡 扉 扉 飞 飛

9956 10054 10057 10414 10422

飛 緋 緋 妃 妃

WADE-GILES PRONUNCIATION IS FEI2

6410 9115 9117 9234

肥 腓 腓 肥

WADE-GILES PRONUNCIATION IS FEI3

385	789	984	995	1405	1427	3061	3063	3070	3072
匪	匪	菲	菲	榧	榧	斐	蜚	斐	翡
3262	3204	3266	3268	4822	4827	5663	5665	7357	7365
斐	蜚	斐	翡	誹	誹	悱	悱	篚	篚

WADE-GILES PRONUNCIATION IS FEI4

935	1080	3728	5247	5251	5331	5346	5374	6493	9101
蒂	蒂	吠	痲	痲	癢	痹	廢	沸	肺
9144	9875								
肺	費								

WADE-GILES PRONUNCIATION IS FENG1

5	460	859	1702	3064	3068	4231	4729	4730	5321
丰	封	葑	楓	豐	鄧	蜂	峯	峰	瘋
6151	6796	7094	8300	8734	9344	9352			
灃	烽	丰	鋒	蜂	風	风			

WADE-GILES PRONUNCIATION IS FENG2

WADE-GILES PRONUNCIATION IS FENG2

7046 7061 8933 10172

馮 馮 逢 縫

WADE-GILES PRONUNCIATION IS FENG3

3366

奉

WADE-GILES PRONUNCIATION IS FENG4

132 4950 7568 9331 9353

奉 諷 俸 鳳 夙

WADE-GILES PRONUNCIATION IS FEN1

1277 1278 2095 4409 7187 9425 10197

芬 榮 零 吩 氛 分 紛

WADE-GILES PRONUNCIATION IS FEN2

463 632 681 1456 1460 1712 6444

墳 坟 坎 焚 焚 粉 汾

WADE-GILES PRONUNCIATION IS FEN3

6624

粉

WADE-GILES PRONUNCIATION IS FEN4

549 2340 2358 5609 6575 6597 7615 7965 9430

賁 奮 奮 憤 糞 糞 債 份 忿

WADE-GILES PRONUNCIATION IS FOU3

2159 7119 7125 7126
否 缶 瓠 瓠

WADE-GILES PRONUNCIATION IS FO2

8063

佛

WADE-GILES PRONUNCIATION IS FU1

159 270 346 2366 3244 3819 7588 8125 8410 8411
瓠 瓠 夫 瓠 膚 跌 伏 鉄 鄒 鄒
9059 9063 9076
鄒 鄒 肤

WADE-GILES PRONUNCIATION IS FU2

35 450 850 1180 1181 1212 1238 1242 1666 1698
髻 髻 芙 苾 苾 苾 菰 菰 桴 枹
1783 2014 2512 2917 3055 3281 4111 4140 4221 4480
輻 敷 扶 拂 髻 黻 蚨 蝠 蜉 罌
5791 6246 6377 6861 6862 6967 7191 7452 7676 7914
拂 涪 浮 福 福 祱 氤 符 伏 俘
8002 8409 8412 8674 9141 9235 9247 9874 9876 9887
鳧 孚 鄂 佛 服 服 匐 弗 艷 鞞

WADE-GILES PRONUNCIATION IS FU2

10031 10041 10210

縛 紱 紼

WADE-GILES PRONUNCIATION IS FU3

1785 2013 2702 2760 2780 3280 3678 4575 5356 5357

輔 甫 拊 撫 拊 黼 哺 幅 府 腐

7384 7840 8567 8571 9099 9156

簠 俯 釜 斧 脯 腑

WADE-GILES PRONUNCIATION IS FU4

103 522 685 1287 1882 1944 1946 3111 3486 3494

駙 赴 埵 蒔 副 霈 覆 駙 賦 賄

3907 4214 4319 4828 5859 6868 6965 7264 7335 7660

跗 蝮 咐 訃 富 祓 複 馥 復 傅

7688 8057 8566 8654 8771 8772 8821 9198 9562 10408

付 阜 父 復 負 負 鮒 腹 附 婦

10411

婦

WADE-GILES PRONUNCIATION IS GUNG1

4238

蚣

WADE-GILES PRONUNCIATION IS HAI1

4286 4287

嗨 嗨

WADE-GILES PRONUNCIATION IS HAI2

4028 5516 9608

骸 頰 孩

WADE-GILES PRONUNCIATION IS HAI3

1959 6344 6346

醃 海 海

WADE-GILES PRONUNCIATION IS HAI4

96 3104 4276 5515 5822 7182

駭 駭 嗜 亥 害 氦

WADE-GILES PRONUNCIATION IS HANG1

2379

夯

WADE-GILES PRONUNCIATION IS HANG2

1587 1675 4272 5467 8708 8744

杭 桁 吭 頰 航 航

WADE-GILES PRONUNCIATION IS HANG4

WADE-GILES PRONUNCIATION IS HANG4

6272

沆

WADE-GILES PRONUNCIATION IS HAN1

257 508 548 1953 4119 7981

顛 慇 慇 酣 蚶 軒

WADE-GILES PRONUNCIATION IS HAN2

342 852 980 981 1292 1293 1313 3026 3027 4404

邗 邗 菡 菡 菡 菡 韓 函 函 哈

5043 6149 6150 6457 6458 7515 9414 9454 9598 9599

寒 涵 涵 涵 涵 邗 含 函 函 函

9601

函

WADE-GILES PRONUNCIATION IS HAN3

3712 6842

喊 罕

WADE-GILES PRONUNCIATION IS HAN4

1312 2508 2578 2579 2630 3359 5535 5645 5646 5671

翰 扞 撼 撼 捍 旱 𠂔 憾 憾 悍

6009 6044 6069 6459 6699 6717 8122 8191 8415 8440

汗 漢 瀚 汙 燠 焊 鉦 鐸 豸 頷

WADE-GILES PRONUNCIATION IS HAN4

8950 8975 9675
犴 犴 閑

WADE-GILES PRONUNCIATION IS HAO1

1078 1367 1369 3625
蒿 薅 薅 嗆

WADE-GILES PRONUNCIATION IS HAO2

602 3389 4180 4251 4327 4328 4329 5013 5016 6241
壕 昊 壕 豪 皞 皞 皞 豪 毫 濠

WADE-GILES PRONUNCIATION IS HAO3

720 10395
郝 好

WADE-GILES PRONUNCIATION IS HAO4

51 52 3689 3710 3788 3789 6195 6338 6364 8011
耗 耗 顗 皓 号 號 灝 浩 浩 皛
8021 8022 8023 8024 8224
皓 皞 皞 皞 鎬

WADE-GILES PRONUNCIATION IS HAI

4397
哈

WADE-GILES PRONUNCIATION IS HEI1

4095 4524
黑 黑

WADE-GILES PRONUNCIATION IS HENG1

4254 5021
亨 亨

WADE-GILES PRONUNCIATION IS HENG2

264 1221 1433 1436 5628 5655 5651 8665 10277
珩 衡 横 横 恒 恒 恒 衡 姁

WADE-GILES PRONUNCIATION IS HENG4

4778
諱

WADE-GILES PRONUNCIATION IS HEN2

5340
痕

WADE-GILES PRONUNCIATION IS HEN3

8673 9038
很 狠

WADE-GILES PRONUNCIATION IS HEN4

WADE-GILES PRONUNCIATION IS HEN4

5788

恨

WADE-GILES PRONUNCIATION IS HE1

3673

4064

4802

呵 喝 訶

WADE-GILES PRONUNCIATION IS HE2

772

1179

1589

1945

3172

3604

3754

3756

5519

5546

盍 荷 核 覈 齧 嗑 曷 鴉 効 闕

5574

6096

6211

6943

7230

7258

7654

8363

8429

9380

閔 河 涸 褐 禾 和 何 龠 貉 合

9384

9683

9715

10140

盒 闔 閔 紇

WADE-GILES PRONUNCIATION IS HE4

716

3218

3601

5920

6837

9260

赫 壑 嚇 鶴 鶴 賀

WADE-GILES PRONUNCIATION IS HOU1

7986

7987

勹 勹

WADE-GILES PRONUNCIATION IS HOU2

WADE-GILES PRONUNCIATION IS HOU2

4336 5305 6617 7461 8050 8503 8768 9014

喉 痰 糍 篸 候 餵 戾 猴

WADE-GILES PRONUNCIATION IS HOU3

4412 9037

吼 吼

WADE-GILES PRONUNCIATION IS HOU4

699 2217 7796 8597 8678

堍 厚 候 后 後

WADE-GILES PRONUNCIATION IS HSIANG1

95 1537 3103 5009 5159 6079 7259 7374 8223 8693

驤 相 驤 襄 廂 湘 香 箱 鑲 舡

6729 10022 10235 10236

舡 緬 乡 鄉

WADE-GILES PRONUNCIATION IS HSIANG2

4370 5192 6520 6890 6891

詳 庠 翔 祥 祥

WADE-GILES PRONUNCIATION IS HSIANG3

1540 4338 5022 8504 10237 10239

想 响 享 餉 響 饗

WADE-GILES PRONUNCIATION IS HSIANG4

494	961	962	1682	3787	7923	8097	8608	8838	10238
項	巷	巷	橡	鄉	像	向	街	象	嚮

WADE-GILES PRONUNCIATION IS HSIAN4

1020
覓

WADE-GILES PRONUNCIATION IS HSIAO1

67	1317	1318	1553	2069	2227	2223	3078	3323	3324
驍	蕭	蕭	枵	霄	硝	硝	驍	肖	肖
3325	3326	3327	3585	3791	4059	4436	5215	5878	5879
削	削	逍	曉	鴉	囂	嘒	瘳	宵	宵
6070	6071	6174	6175	7492	7493	7760	7767	7997	8045
滿	滿	消	消	簫	簫	脩	脩	梟	魑
8185	10059								
銷	綃								

WADE-GILES PRONUNCIATION IS HSIAO3

3401	7455	7456	7457	9639
曉	攸	條	條	小

WADE-GILES PRONUNCIATION IS HSIAO4

WADE-GILES PRONUNCIATION IS HSIAO4

711	1585	3599	4292	4419	4420	5199	5200	7451	7595
孝	校	哮	咲	嘯	嘯	效	効	笑	斂

7839
倣

WADE-GILES PRONUNCIATION IS HSIA1

3463	4136	4155	4242	8798	8833
瞎	虾	蝦	蝦	鰕	鰕

WADE-GILES PRONUNCIATION IS HSIA2

218	306	1546	1803	1843	2070	2099	2210	3566	3658
瑕	瑕	柙	轄	匣	霞	霞	硤	遐	暇

3776	4090	4518	4526	4668	7679	8969	8979	9762
暇	呬	黠	黠	峽	俠	狹	狎	遐

WADE-GILES PRONUNCIATION IS HSIA4

1372	1926	2140	2183	3641	5163	7128	9530
下	西	厦	夏	吓	廈	罅	障

WADE-GILES PRONUNCIATION IS HSIEH1

1385	3188	3757	4157	4158
楔	些	歇	蝎	蠍

WADE-GILES PRONUNCIATION IS HSIEH2

WADE-GILES PRONUNCIATION IS HSIEN2

60	571	747	897	913	1761	1762	2589	2987	3578
繫	頤	邪	鞋	鞣	協	協	挾	邪	叶
4016	4820	5775	7692	7732	8346	9216	9218	9293	9294
諧	諧	協	偕	偕	斜	肋	脇	勰	脅
9368	10009								
斜	頤								

WADE-GILES PRONUNCIATION IS HSIEN3

5919	6832	6848
寫	写	写

WADE-GILES PRONUNCIATION IS HSIEN4

963	964	1396	1665	3875	4225	4226	4227	4228	4229
薤	薤	械	榭	躐	蟬	蟬	蟬	蟬	蟬
4230	4883	4913	4991	4992	4997	5364	5365	5366	5367
蟬	燮	謝	褻	褻	褻	廨	廨	廨	廨
5368	5369	5763	5764	5765	5766	5767	5768	6057	6058
廨	廨	懈	懈	懈	懈	懈	懈	泄	渫
6165	6166	6198	6300	6319	6324	6397	6398	6399	6400
瀝	瀝	洩	瀉	泻	泻	泮	泮	泮	泮
6401	6402	7099	7103	7565	8878	8879	8886	8887	8889
泮	泮	卸	卸	僨	蟹	邇	蟹	邇	蟹

WADE-GILES PRONUNCIATION IS HSIEN4

8890	8901	8902	8909	8910	8912	8913	9021	9022	9023
邂	蟹	邂	蟹	邂	蟹	邂	獬	獬	獬
9024	9025	9026	9784	10019	10072	10273			
獬	獬	獬	屑	絀	絀	媾			

WADE-GILES PRONUNCIATION IS HSIEN1

1678	2815	3720	3838	3839	7207	7657	7658	7804	8269
杓	掀	遲	蹢	蹢	先	僊	僊	仙	銛
8293	8811	10161	10162	10378	10379				
鉦	鮮	纖	纖	鐵	鐵				

WADE-GILES PRONUNCIATION IS HSIEN2

1908	2136	3211	3462	3562	4305	4306	4352	5274	5275
賢	咸	鹹	眈	眈	啣	啣	銜	痃	痃
5276	5338	5339	5550	5591	6352	8657	8709	8745	9689
痃	痃	痃	閑	閑	涎	銜	舷	舷	閑
9731	9864	10109	10337	10338	10346	10409	10410		
閑	弦	絃	嫻	嫻	嫌	嫻	嫻		

WADE-GILES PRONUNCIATION IS HSIEN3

829	1224	2443	3428	3626	3786	3900	4154	4593	4736
尠	薛	燹	顯	顯	顯	跣	蜺	懣	嶮

WADE-GILES PRONUNCIATION IS HSIEN3

8266 9031 9537
銑 獫 險

WADE-GILES PRONUNCIATION IS HSIEN4

216 1390 3226 3394 3573 4678 5825 5915 6531 6533
現 獻 獻 縣 峴 憲 宪 羨 羨
6515 8517 9202 9574 9582 9596 10045 10150
餡 餡 腺 陷 陷 限 綫 線

WADE-GILES PRONUNCIATION IS HSING1

766 3707 4543 5679 5807 7580 7584 8981 9131
馨 星 典 惺 兴 興 興 猩 腥

WADE-GILES PRONUNCIATION IS HSING2

327 328 331 332 2180 6770 8463 8602 9525
刑 型 形 邢 硯 漿 錫 行 陞

WADE-GILES PRONUNCIATION IS HSING3

1969 2787
醒 擗

WADE-GILES PRONUNCIATION IS HSING4

637 1217 1533 5610 5736 7622 10354
幸 苻 杏 悻 性 倖 姓

WADE-GILES PRONUNCIATION IS HSIN1

1061	1082	1153	3736	5043	5049	5068	5597	5760	7030
莘	薪	芯	昕	辛	新	歆	忡	忻	心
7102	8225	8289	8596	9642					
牲	鉉	鑫	欣	小					

WADE-GILES PRONUNCIATION IS HSIN3

7877
仈

WADE-GILES PRONUNCIATION IS HSIN4

7583	7587	7825	8069	8085
𢆶	𢆶	信	𣎵	𣎵

WADE-GILES PRONUNCIATION IS HSIUNG1

4390	4946	5776	6420	6445	9219	9296	9297	9436	9437
兄	詢	恂	洵	汹	胸	匈	胷	凶	兇

WADE-GILES PRONUNCIATION IS HSIUNG2

2479	9975
雄	熊

WADE-GILES PRONUNCIATION IS HSIU1

4318	5355	6523	6540	7641	7758	7759	7765	7766	8423
咻	麻	羞	羞	休	修	脩	修	脩	貅

WADE-GILES PRONUNCIATION IS HSIU1

8482 8485 9173 9176
餵 餵 膳 膳

WADE-GILES PRONUNCIATION IS HSIU3

1517
朽

WADE-GILES PRONUNCIATION IS HSIU4

4326 4686 6362 6946 7309 8272 8327 8328 10139 10203
嗅 岫 溴 袖 秀 锈 鏽 鏽 綉 繡
10204
繡

WADE-GILES PRONUNCIATION IS HSI1

379	568	582	886	1326	1479	1668	1669	1672	1745
丁	熹	熹	昔	熙	栖	析	皙	皙	樺
1746	1949	1981	2200	2446	2677	2784	2785	2837	2976
樺	西	醯	硒	猗	攜	攜	携	扱	匸
3437	3590	3591	3592	3650	3701	3765	3911	4137	4223
晰	晞	嘻	嘻	晰	曦	晞	蹊	蜥	蟋
4368	4398	4400	4674	4675	4676	4975	5639	6080	6535
吸	噏	唏	巖	巖	巖	談	恹	浙	羲

WADE-GILES PRONUNCIATION IS HSI1

6856	7319	7337	7525	7528	7617	7618	7713	7915	8435
禧	稀	熙	牺	犧	僖	僖	鼯	僖	奚
8545	8659	9094	9392	9393	9402	9782	9786	10267	10268
悉	僖	膝	希	歛	兮	犀	犀	嬉	嬉

WADE-GILES PRONUNCIATION IS HSI2

1091	1661	4921	5097	5104	5136	5613	6784	7991	8202
蓆	檄	謨	襲	襲	席	惜	熄	息	錫
9537	9902	9914	9915	10366					
隰	刁	習	習	媳					

WADE-GILES PRONUNCIATION IS HSI3

567	569	581	583	1218	2043	2342	2977	4116	4117
喜	憇	喜	憇	蓰	璽	璽	匸	蟪	蟪
6339	6855	8621	9821	9966					
洗	禧	徙	徙	杲					

WADE-GILES PRONUNCIATION IS HSI4

194	1838	2271	3145	3227	3232	3236	5587	5972	6350
鬩	繫	矽	鬩	戲	戲	戲	鬩	窳	瀉
6396	6850	7706	7951	8371	8489	8555	8844	9358	9389
汐	楔	舄	係	歛	餽	卻	夕	糸	翕

WADE-GILES PRONUNCIATION IS HSI4

9401	9531	9595	9620	9727	9788	10076	10163
郢	隙	隙	戏	闕	肩	細	裕

WADE-GILES PRONUNCIATION IS HSUIAN1

241	1113	1596	1768	1771	2717	3698	4277	4866	4916
瑄	萱	萱	亘	軒	揔	暄	喧	諠	媛
5357	6703	6745	7799	10113					
宣	烜	煊	儼	緇					

WADE-GILES PRONUNCIATION IS HSUIAN2

202	235	3395	3570	3575	5460	5520
璿	璇	懸	懸	悬	旋	玄

WADE-GILES PRONUNCIATION IS HSUIAN3

5310	7208	9846
癬	选	選

WADE-GILES PRONUNCIATION IS HSUIAN4

3459	6269	6282	6290	6742	8241	10183
眩	漩	洿	渲	炫	鍈	絢

WADE-GILES PRONUNCIATION IS HSUIEH1

899	912	1200
韡	靴	薛

WADE-GILES PRONUNCIATION IS HSUIEH2

5486 5820 7594

學 學 學

WADE-GILES PRONUNCIATION IS HSUIEH3

2098

雪

WADE-GILES PRONUNCIATION IS HSUIEH4

5987 8066

穴 血

WADE-GILES PRONUNCIATION IS HSUIN1

576 680 1172 1993 3713 4046 6779 7338 7339 7340

塤 塤 薰 醺 曛 勛 燠 熏 勳 勳

9012

獫

WADE-GILES PRONUNCIATION IS HSUIN2

285 1248 3112 4734 4942 5773 6412 6468 6469 8664

珣 荀 馴 峴 詢 恂 洵 潯 潯 循

8830 8831 9253 9257 9660 9664 9665 10439 10441

鯪 鯪 旬 邨 尋 尋 尋 巡 巡

WADE-GILES PRONUNCIATION IS HSUIN4

104	2039	2427	4806	4910	6111	8667	9028	9340	9612
馴	迅	殉	訊	訓	汎	徇	狗	迅	遜
9614	9845								
遜	巽								

WADE-GILES PRONUNCIATION IS HSUI1

31	446	541	542	2064	2146	3051	3231	3234	3235
鬚	鬚	墟	墟	需	戌	鬚	虛	歔	虛
3238	3358	3557	3986	3987	4769	6120	6626	8682	8683
歔	吁	吁	嘘	嘘	訐	湏	精	須	須
9446									
胥									

WADE-GILES PRONUNCIATION IS HSUI2

8669
徐

WADE-GILES PRONUNCIATION IS HSUI3

1751	4893	4971
栩	許	詡

WADE-GILES PRONUNCIATION IS HSUI4

WADE-GILES PRONUNCIATION IS HSU14

742	1106	2004	3527	3656	3657	3752	4672	4709	4710
壻	蓄	酗	賁	勛	勛	煦	屿	嶼	嶼
4748	4949	5375	5753	6366	6369	6370	6371	6772	6079
屿	訊	序	恤	洫	漱	漱	漱	歛	卹
8345	8347	8348	9335	10010	10013	10014	10318	10393	
敘	敘	叙	旭	續	緒	緒	絮	婿	

WADE-GILES PRONUNCIATION IS HUA12

1663	3863	5648	5649	5705	5706	6356
槐	踝	怀	怀	懷	懷	淮

WADE-GILES PRONUNCIATION IS HUA14

492	604	605
坏	壞	壞

WADE-GILES PRONUNCIATION IS HUANG1

1105	5504	5617
荒	盲	慌

WADE-GILES PRONUNCIATION IS HUANG2

168	170	849	928	2189	2190	4123	4125	4219	5218
璜	璜	黃	黃	磺	磺	蟻	蟻	蝗	瘡
5220	5751	6043	6046	6361	6783	7368	7369	7458	7906
瘡	惶	潢	潢	湟	煌	簧	簧	篁	惶

WADE-GILES PRONUNCIATION IS HUANG2

7973 7974 8655 9342 9564

皇 遑 徨 凰 隍

WADE-GILES PRONUNCIATION IS HUANG3

3642 4582 4794 5666 5675 5690 6723

晃 幌 謊 恍 恍 恍 煨

WADE-GILES PRONUNCIATION IS HUANG4

2642

晃

WADE-GILES PRONUNCIATION IS HUANI

74 1045 3085 4793 5614 8418 8960 9629

驩 歡 驩 謹 懽 驩 驩 歡

WADE-GILES PRONUNCIATION IS HUANI2

21 176 223 436 1466 2162 3041 4479 4512 5566

鬟 环 環 鬟 桓 还 鬟 還 園 園

5091 8212 9708 10087 10321

寰 環 闐 環 媛

WADE-GILES PRONUNCIATION IS HUANI3

6063 6287 10154

澣 浣 緩

WADE-GILES PRONUNCIATION IS HUAN4

2831	2832	4072	4362	4363	5311	5860	5890	5992	6214
換	換	患	喚	喚	換	宦	追	追	患
6395	6556	6793	8843	10231					
渙	泰	煥	奐	幻					

WADE-GILES PRONUNCIATION IS HUA1

1207	1279	3612	4604
花	花	嘩	嘩

WADE-GILES PRONUNCIATION IS HUA2

73	846	1432	2960	3084	4786	6213	8105	8143	8934
驊	華	樺	划	驊	譚	滑	华	鐸	猾

WADE-GILES PRONUNCIATION IS HUA4

1059	1860	4899	4937	8104	9661	9662	9663
画	画	話	詬	化	畫	劃	畫

WADE-GILES PRONUNCIATION IS HUI1

2376	2377	2751	2752	2803	3290	3293	3702	4722	4811
灰	灰	搗	揮	搗	輝	輝	暉	徽	誼
5154	5694	6774	8638	9511	9911				
麾	恢	煇	徽	隳	翬				

WADE-GILES PRONUNCIATION IS HUI2

1052	1061	1068	4173	4174	4177	4461	4463	4464	4507
茴	茴	茴	蛔	蛔	蛔	圃	迴	迴	回
4509	4510	4618	4619	4620	5693	5696	5699	6222	6225
迴	迴	回	迴	迴	恁	恁	恁	洵	洵
6229	8627	8628	8630						
洵	洵	洵	洵						

WADE-GILES PRONUNCIATION IS HUI3

2467	4907	5745	5747	6781	7701	8563
虺	誼	悔	悔	燬	毀	虺

WADE-GILES PRONUNCIATION IS HUI4

6	7	511	544	923	1269	1272	1847	2046	2301
慧	慧	卉	卉	蕙	荟	薈	惠	匯	饋
2410	3496	3714	3715	4138	4448	4902	4903	4969	5561
殞	賄	晦	晦	蟪	喙	誨	誨	諱	饋
6118	6143	6805	6806	7253	7272	7273	9372	9390	9649
滙	匯	烺	燴	穢	穢	穢	会	會	滙
9702	9991	10077	10190	10192	10250				
閼	彙	績	繪	繪	繪				

WADE-GILES PRONUNCIATION IS HUNG1

1055	1781	1833	3003	4304	6700	9274
薨	轟	叟	轰	哖	烘	旬

WADE-GILES PRONUNCIATION IS HUNG2

4112	4771	5055	5554	5871	6033	6050	6494	7590	7591
虹	訏	竝	罔	宏	鴻	洪	泓	鬻	鬻
9894	9882	10003	10042						
閏	弘	紅	紘						

WADE-GILES PRONUNCIATION IS HUNG3

3619
哄

WADE-GILES PRONUNCIATION IS HUNG4

185	3136	5548	9687
閏	閏	閏	閏

WADE-GILES PRONUNCIATION IS HUN1

246	1146	3543	5590	5770	9049	9730	10386
琿	葦	昏	閻	惛	昏	閻	婚

WADE-GILES PRONUNCIATION IS HUN2

375	6318	8464	8465	8488
魂	渾	餽	餽	餽

WADE-GILES PRONUNCIATION IS HUN3

6189 6190
混 混

WADE-GILES PRONUNCIATION IS HUN4

4374 4895 6218
混 諱 潤

WADE-GILES PRONUNCIATION IS HUO1

1188 5824
割 豁

WADE-GILES PRONUNCIATION IS HUO2

6340
活

WADE-GILES PRONUNCIATION IS HUO3

3438 5803 6691 7868
夥 伙 伙 伙

WADE-GILES PRONUNCIATION IS HUO4

941	1233	1236	1848	1851	1852	2090	2575	3630	4132
藿	荻	獲	惑	或	惑	霍	擢	噉	蠖
5236	6881	6882	7142	7236	8107	8148	8961	9102	
癯	禍	禍	矧	穫	貨	鑊	獲	臙	

WADE-GILES PRONUNCIATION IS HU1

3224	3251	3988	4347	4385	5774	6170	8547	9288
虎	虜	嘑	呼	唵	惚	滹	乎	忽

WADE-GILES PRONUNCIATION IS HU2

14	172	431	660	661	668	669	880	1229	1230
鬚	瑚	鬚	齧	齧	壺	壺	葫	斛	斛
1333	1334	1684	1686	1956	3036	4134	4366	4367	4548
胡	胡	榘	榘	醐	鬚	瑚	斛	斛	圀
6072	6377	6701	8455	8609	8876	8899	8962	9019	9877
湖	糊	煨	餬	衡	斛	斛	獮	狐	弧

WADE-GILES PRONUNCIATION IS HU3

205	3254	3255	3989	4826	6234
琥	虎	虎	唬	詭	許

WADE-GILES PRONUNCIATION IS HU4

1048	1076	1160	1165	1208	2314	2755	3015	4645	4795
護	護	獲	獲	獲	瓠	护	互	岵	護
5619	6326	6328	6329	6860	7004	7012	7018	7481	
怙	沪	滬	滬	祜	户	扈	扈	笏	

WADE-GILES PRONUNCIATION IS II

WADE-GILES PRONUNCIATION IS 11

1	371	656	2106	2107	2110	2329	2640	2641	2953
一	弋	壹	医	醫	緊	歆	揖	揖	弋
4332	4422	5398	6407	6906	6911	7841	8019	8966	
呀	伊	衣	漪	禕	衣	依	伊	猗	

WADE-GILES PRONUNCIATION IS 12

657	758	1325	2974	3537	3574	3778	3953	4974	5243
懿	圮	頤	夷	貽	貽	嘖	遺	詒	瘕
5798	5881	6142	6385	7307	7450	7545	7862	7872	7959
怡	宜	洩	沂	移	穉	迤	儀	儀	儀
8529	8862	9111	9943	9987	9988	9989	9990	10295	
飴	迤	胰	疑	彝	彝	彝	彝	姨	

WADE-GILES PRONUNCIATION IS 13

1073	1298	1495	4754	5445	7674	8711	8712	8723	8747
苙	苙	椅	以	旖	倚	艤	舩	舩	舩
6740	8759	9654	9839	9947	9972				
舩	舩	以	已	乙	矣				

WADE-GILES PRONUNCIATION IS 14

91	862	863	867	868	1084	1353	1809	2108	2109
驛	藝	藝	藝	藝	薏	艺	軼	腎	腎

WADE-GILES PRONUNCIATION IS 14

2111	2398	2403	2668	2700	2844	3100	3613	3614	3758
娶	殪	殄	挹	掖	抑	驛	嘖	嘖	易
3803	4159	4178	4196	4202	4235	4258	4433	4468	4690
異	蜴	螳	蟻	蚁	蚁	噫	邑	畢	嶧
4846	4867	4871	4973	5067	5089	5106	5239	5322	5380
譯	誼	議	詣	意	毅	翊	瘞	疫	亦
5381	5383	5399	5691	5694	5710	5796	6221	6309	6536
弈	奕	裔	悒	懌	憶	忆	浥	溢	義
6655	6656	6822	7039	7044	7834	7881	7900	7966	7983
益	益	义	议	议	億	佚	仡	侑	劓
8108	8251	8668	8836	8840	9145	9359	9405	9407	9492
亿	鎰	役	逸	逸	臆	乂	刈	义	卩
9341	9905	9906	9907	9908	9909	9944	10086	10128	
异	羿	翼	翼	翌	翌	肄	繹	縊	

WADE-GILES PRONUNCIATION IS JANG2

2682	5007	5008	6240	6886	7274
攘	瓢	勦	灤	襍	穰

WADE-GILES PRONUNCIATION IS JANG3

600	4250
壤	壤

WADE-GILES PRONUNCIATION IS JAN4

4021 4851 4887 7036
訖 讓 讓 让

WADE-GILES PRONUNCIATION IS JAN2

22 437 3042 6794 6801 8851 9283
髻 髻 髻 燃 燃 然 然

WADE-GILES PRONUNCIATION IS JAN3

1063 4563 6428
苒 冉 染

WADE-GILES PRONUNCIATION IS JA02

850 1409 8450 10265
堯 撓 饒 撓

WADE-GILES PRONUNCIATION IS JA03

2503 2594
擾 扰

WADE-GILES PRONUNCIATION IS JA04

456 10005
遶 繞

WADE-GILES PRONUNCIATION IS JENG1

WADE-GILES PRONUNCIATION IS JENG1

2839

扔

WADE-GILES PRONUNCIATION IS JENG2

7931

仍

WADE-GILES PRONUNCIATION IS JEN2

7194 7561 7562 9360 10137 10147 10357 10365

壬 亅 仁 人 絰 維 妊 姪

WADE-GILES PRONUNCIATION IS JEN3

1191 7320 9278 9310

苙 稔 忍 忍

WADE-GILES PRONUNCIATION IS JEN4

917 920 1824 1825 4943 4948 4952 6964 6970 7043

韌 韌 韌 韌 認 認 訖 衽 衽 讖

7883 7886 7944 7946 8490 8500 9271 9309 9891 9892

任 恁 仞 仞 飪 飪 刃 刃 韌 韌

10184 10187

紉 紉

WADE-GILES PRONUNCIATION IS JE3

WADE-GILES PRONUNCIATION IS JE3

950 3618
惹 喏

WADE-GILES PRONUNCIATION IS JE4

643 727 864 869 2861
執 執 執 執 執

WADE-GILES PRONUNCIATION IS JIH1

4513
日

WADE-GILES PRONUNCIATION IS JIH4

3349 6168
日 鈞

WADE-GILES PRONUNCIATION IS JOU2

2889 3937 4621 9470
操 蹂 肉 柔

WADE-GILES PRONUNCIATION IS JOU3

6627
糲

WADE-GILES PRONUNCIATION IS JOU4

4614
肉

WADE-GILES PRONUNCIATION IS JO4

947 7370 7501 7632 9871 9872
若 箬 箬 倭 弱 弱

WADE-GILES PRONUNCIATION IS JUAN3

1788 1819 5653 9495
輓 軟 悞 阮

WADE-GILES PRONUNCIATION IS JUI2

967
蕤

WADE-GILES PRONUNCIATION IS JUI3

908 989 1154 1155
蕤 蕤 蕊 蕊

WADE-GILES PRONUNCIATION IS JUI4

226 1066 1067 3217 3219 4175 4176 8254 8255
瑞 芮 芮 睿 蚘 蚘 銳 銳

WADE-GILES PRONUNCIATION IS JUNG2

356 856 874 1022 1023 1145 1894 6302 6303 6315
戎 茸 茸 茸 茸 荣 融 溶 溶 澹
6509 6746 6747 6759 7164 8246 8247 10000
戎 熔 熔 榮 毳 鎔 鎔 絨

WADE-GILES PRONUNCIATION IS JUNG3

5985 6844
冗 冗

WADE-GILES PRONUNCIATION IS JUN4

5536 6283 6470 9676
闰 润 潤 閏

WADE-GILES PRONUNCIATION IS JU2

1370 2095 3704 4141 6113 6925 7598 7666 9607 10032
茹 顙 嚙 蠕 濡 襦 仔 儒 孺 繻
10301
如

WADE-GILES PRONUNCIATION IS JU3

142 2113 6505 8413
辱 辱 汝 乳

WADE-GILES PRONUNCIATION IS JU4

823 942 2573 6007 6114 6912 6926 9361 9997 10033
蓐 蓐 孺 潯 滹 褥 褥 入 綈 綈

WADE-GILES PRONUNCIATION IS K'AI1

322 2599 2604 5537 9677
开 揩 揩 開 開

WADE-GILES PRONUNCIATION IS K'AI3

1500 1514 4654 4656 5568 5700 8172 8176 8221 9709
楷 楷 剴 凱 圜 愷 錯 錯 鎧 闥

WADE-GILES PRONUNCIATION IS K'AI4

4423 5738 5786 5787
嘅 慨 慨 慨

WADE-GILES PRONUNCIATION IS K'ANG1

5000 5714 5715 6603 7277
康 慷 忼 糠 糠

WADE-GILES PRONUNCIATION IS K'ANG2

2517 2527
扛 損

WADE-GILES PRONUNCIATION IS K'ANG3

4027
骯

WADE-GILES PRONUNCIATION IS K'ANG4

2704 5466 6741 7845
抗 亢 炕 伉

WADE-GILES PRONUNCIATION IS K'AN1

AD-A040 795

RCA ADVANCED TECHNOLOGY LABS CAMDEN N J
LANGUAGE MANUAL FOR USE WITH IDEOGRAPHIC COMPOSING MACHINES MOD--ETC(U)
FEB 70

F/G 9/2
DAAG17-68-C-0064
NL

UNCLASSIFIED

2 of 5
ADA040795

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30
31	32	33	34	35	36	37	38	39	40
41	42	43	44	45	46	47	48	49	50
51	52	53	54	55	56	57	58	59	60
61	62	63	64	65	66	67	68	69	70
71	72	73	74	75	76	77	78	79	80
81	82	83	84	85	86	87	88	89	90
91	92	93	94	95	96	97	98	99	100

WADE-GILES PRONUNCIATION IS K'IAN1

163	333	470	828	7909	9335	9386
堯	刊	堪	勘	刊	龕	龕

WADE-GILES PRONUNCIATION IS K'IAN3

700	2270	2021	5542	5543	7798	9681	9682	9924
坎	砍	坎	闕	闕	侃	闕	闕	

WADE-GILES PRONUNCIATION IS K'IAN4

3362	3363	3460	3461	3560	3561	7139
瞰	瞰	瞰	瞰	瞰	瞰	看

WADE-GILES PRONUNCIATION IS K'AD1

9324
尻

WADE-GILES PRONUNCIATION IS K'AD3

603	707	739	1418	1422	2531	2532	2534	3029	6695
考	考	考	拷	拷	拷	拷	拷	攷	烤

6676
烤

WADE-GILES PRONUNCIATION IS K'AD4

7201	7202	7527	8135	8136
靠	靠	犒	鏑	鏑

WADE-GILES PRONUNCIATION IS K'AI

4282

𠵼

WADE-GILES PRONUNCIATION IS KI'ENG1

631 2199 2222 8157 9545

坑 礮 礮 鏗 阮

WADE-GILES PRONUNCIATION IS KI'EN3

3177 3182 3923 8432 8433 9760 9761

齧 肯 啃 墾 懇 垦 忌

WADE-GILES PRONUNCIATION IS KI'EN4

6933 6989

禡 根

WADE-GILES PRONUNCIATION IS K'EI

175 931 1476 1539 1784 2187 2536 3021 3369 3436

珂 苛 柯 棵 軻 磕 搥 𠂔 瞓 顆

4023 4213 5234 5945 7263 7278

髀 蚪 痾 窠 裸 科

WADE-GILES PRONUNCIATION IS K'IE2

663 664 672 4274 5518

壳 殼 壳 咳 欸

WADE-GILES PRONUNCIATION IS K'IE3

1920 6196
可 渴

WADE-GILES PRONUNCIATION IS K'IE4

87	482	1335	1336	1338	1339	1340	1341	1342	1343
騾	垓	克	尅	尅	尅	尅	剋	尅	尅
1424	3096	4285	4832	5517	5769	5929	6037	7174	8194
榼	騾	喀	課	刻	恪	客	溘	氦	鏹

10017
緝

WADE-GILES PRONUNCIATION IS K'IOU1

2361	2596	3378	3390
摳	拏	瞞	瞞

WADE-GILES PRONUNCIATION IS K'IOU3

3347
口

WADE-GILES PRONUNCIATION IS K'IOU4

1110	1111	1112	2628	4435	5846	5847	5848	7943	8187
寇	寇	寇	扣	叩	寇	寇	寇	伺	鈎

WADE-GILES PRONUNCIATION IS K'IOU4

10060

紉

WADE-GILES PRONUNCIATION IS K'UAI3

1241

2267

2570

薊 魄 攤

WADE-GILES PRONUNCIATION IS K'UAI4

550

698

754

1704

1707

4396

4399

5789

6434

6437

卦 塊 块 桧 檜 吟 噲 快 浍 漚

7433

7953

7956

8360

8373

8827

8828

9032

9225

9227

快 佺 會 郇 鄆 鯰 鱠 獾 脍 膾

WADE-GILES PRONUNCIATION IS K'UANG1

9

10

4758

7343

匡 劬 詎 筐

WADE-GILES PRONUNCIATION IS K'UANG2

4936

8951

誑 狂

WADE-GILES PRONUNCIATION IS K'UANG4

612

613

1384

2243

2244

2245

3259

3354

3511

3695

壙 壙 框 矿 礦 礦 卞 瞋 貺 曠

WADE-GILES PRONUNCIATION IS K'UANG4

3696	5132	5135	6220	7065	8232	8233	10058	10099	10100
曠	鄺	鄺	況	況	鑛	鑛	統	續	續

WADE-GILES PRONUNCIATION IS K'UAN1

5054

寬

WADE-GILES PRONUNCIATION IS K'UAN3

423 9942

款 欸

WADE-GILES PRONUNCIATION IS K'UA1

2312 4809

夸 誇

WADE-GILES PRONUNCIATION IS K'UA3

3726 7672

垮 垮

WADE-GILES PRONUNCIATION IS K'UA4

495 3847 4021 9105

垮 跨 髀 胯

WADE-GILES PRONUNCIATION IS K'UEI1

377 2378 3250 4714 5538 5932 7909 9678

亏 盍 虧 歸 闕 窺 傀 闕

WADE-GILES PRONUNCIATION IS K'UEI2

726 948 1281 2319 3553 3767 6650 8048 9341
逵 夔 葵 奎 睽 睽 夔 魁 魁

WADE-GILES PRONUNCIATION IS K'UEI3

2684 3823
揆 跬

WADE-GILES PRONUNCIATION IS K'UEI4

799 1856 3448 4069 5682 5752 6205 7376 7413 8468
贖 匱 贖 喟 憤 愧 潰 簞 簞 饋
8502 10369
餽 餽

WADE-GILES PRONUNCIATION IS K'UEI4

393
贖

WADE-GILES PRONUNCIATION IS K'UNG1

4697 5723 5933 7436 7855
崆 控 空 筊 控

WADE-GILES PRONUNCIATION IS K'UNG3

589 738 9615
恐 恐 孔

WADE-GILES PRONUNCIATION IS KIUNG4

2727

控

WADE-GILES PRONUNCIATION IS KIUN1

34	217	219	449	563	655	3054	3558	3559	3571
髡	琨	琨	髡	坤	壺	髡	昆	鷗	昆
3572	4679	4680	4681	4682	5440	6721	6722	6962	6963
鷗	崑	崑	崑	崑	堃	焜	焜	禪	禪
8797	8799								
鯤	鯤								

WADE-GILES PRONUNCIATION IS KIUN3

2659	5562	5684	9703	10082
捆	閬	困	閬	網

WADE-GILES PRONUNCIATION IS KIUN4

3449	4036
睏	困

WADE-GILES PRONUNCIATION IS KIUD4

2695	2696	2697	5184	5576	6286	6473	9716
扩	擴	擴	廓	闊	濶	潤	閏

WADE-GILES PRONUNCIATION IS K'U1

757 1441 2261 2313 2585 4018 4062 5981
堀 枯 屹 剝 垮 骷 哭 窟

WADE-GILES PRONUNCIATION IS K'U3

879 1434
苦 楷

WADE-GILES PRONUNCIATION IS K'U4

1991 5161 6928 6956 7593 10038
酷 庫 袴 褲 譽 誇

WADE-GILES PRONUNCIATION IS KAI1

633 3514 4865 9546
垓 賅 該 咳

WADE-GILES PRONUNCIATION IS KAI3

9837 9844
改 改

WADE-GILES PRONUNCIATION IS KAI4

781 873 955 1742 1743 6475 6528 8138 9276 9753
丐 蓋 蓋 概 概 溉 盖 鈣 勻 槩

WADE-GILES PRONUNCIATION IS KANG1

WADE-GILES PRONUNCIATION IS KANG1

4457 4610 4611 4692 7120 8216 9078 10089
罍 岡 剛 崗 缸 鋼 肛 綱

WADE-GILES PRONUNCIATION IS KANG3

6053 6055
港 港

WADE-GILES PRONUNCIATION IS KANG4

1403
扛

WADE-GILES PRONUNCIATION IS KAN1

147 120 787 1302 1307 1393 1426 5217 6038 7345
干 玕 甘 乾 乾 杆 柑 疳 泔 竿

9074
肝

WADE-GILES PRONUNCIATION IS KAN3

507 516 526 547 1410 1412 1538 2135 2137 2552
敢 赶 趕 敢 橄 橄 桿 感 感 擻

7231 7261
秆 稈

WADE-GILES PRONUNCIATION IS KAN4

WADE-GILES PRONUNCIATION IS KAN4

1309	1310	3360	5060	5061	5064	6249	6250	6368	10016
幹	幹	肝	顛	顛	顛	瀨	瀨	淦	紺

WADE-GILES PRONUNCIATION IS KAO1

1657	1658	1659	4999	5010	5015	6529	6607	7421	7988
梘	梘	梘	高	高	膏	羔	糕	篙	皋
7992	7994	8067	8484						
皋	皋	皋	糕						

WADE-GILES PRONUNCIATION IS KAO3

1079	1568	2683	3433	5012	7275	10096
藁	稿	搞	杲	藁	稿	稿

WADE-GILES PRONUNCIATION IS KAO4

4897	7200	7206	8265
誥	告	郜	鋁

WADE-GILES PRONUNCIATION IS KAI

9334
咎

WADE-GILES PRONUNCIATION IS KA2

3721	3724
嘎	嘎

WADE-GILES PRONUNCIATION IS KA3

3607

𦵏

WADE-GILES PRONUNCIATION IS KE13

10191

𦵏

WADE-GILES PRONUNCIATION IS KENG1

41 42 3797 5400 5401 6086 6530 6580 7241

耕 耕 𦵏 庚 賡 漚 羹 粳 稷

WADE-GILES PRONUNCIATION IS KENG3

400 479 806 1468 3660 4019 8786 10025

耿 埂 耿 梗 哽 骹 鯁 綆

WADE-GILES PRONUNCIATION IS KENG4

1849

更

WADE-GILES PRONUNCIATION IS KEN1

1744 3940

根 跟

WADE-GILES PRONUNCIATION IS KEN2

WADE-GILES PRONUNCIATION IS KEN2

4425

喂

WADE-GILES PRONUNCIATION IS KEN4

2414 2994 9759

互 互 良

WADE-GILES PRONUNCIATION IS KE1

1921 1922 1923 2715 2904 2956 3623 3906 4030 4803

哥 鵠 歌 摘 擱 戈 噶 跣 髁 訶

5299 5823 8369 9199 9211 10428

疙 割 鵠 肱 胳膊 从

WADE-GILES PRONUNCIATION IS KE2

896 1689 1779 1895 3669 4033 4234 5586 5589 9096

革 格 轄 翮 噶 骼 蛤 尙 尙 膈

9504 9505 9726 9729

隔 隔 閤 閣

WADE-GILES PRONUNCIATION IS KE3

1034 8696 8732 9256

葛 舸 舸 哥

WADE-GILES PRONUNCIATION IS KE4

WADE-GILES PRONUNCIATION IS KE4

2275	4216	7414	7793	7802	8301	8936	9403
硌	蛇	箇	個	佢	銘	各	个

WADE-GILES PRONUNCIATION IS KOU1

2057	6015	6423	8304	8308	9308	9638	10151
拘	溝	沟	鉤	鈎	勾	丿	緱

WADE-GILES PRONUNCIATION IS KOU3

1246	1695	4733	9027
苟	枸	峇	狗

WADE-GILES PRONUNCIATION IS KOU4

323	324	666	705	1395	1699	2510	3487	3533	4546
靚	邁	殼	垢	構	构	構	購	购	购
4925	8598	8863	9265	10262	10381				
話	逅	夠	够	媾	姤				

WADE-GILES PRONUNCIATION IS KUA11

7197
乖

WADE-GILES PRONUNCIATION IS KUA13

1557	2605
拐	拐

WADE-GILES PRONUNCIATION IS KUA14

5783

怪

WADE-GILES PRONUNCIATION IS KUANG1

1529 3292 8180 8872 8895 9125

光 光 銑 觥 觥 觥

WADE-GILES PRONUNCIATION IS KUANG3

5123 5131 5134 8995 8996

广 廣 廣 獮 獮

WADE-GILES PRONUNCIATION IS KUANG4

8952 8954

逛 逛

WADE-GILES PRONUNCIATION IS KUANG1

1043 1601 1610 5266 5267 5577 5889 5991 6555 6824

觀 棺 棺 瘰 瘰 関 官 官 关 冠

7852 7856 8805 8806 9621 9622 9717 9736 9737 9738

倌 倌 鰥 鰥 观 观 関 關 關 關

9739

闕

WADE-GILES PRONUNCIATION IS KUAN3

7434	7435	7437	8115	8116	8476	8477	8478	8479	8533
筧	管	管	館	館	館	館	館	館	館

8534
館

WADE-GILES PRONUNCIATION IS KUAN4

1044	2192	2926	5794	6063	7121	7597	8146	9936
鸛	確	攢	慣	灌	罐	盥	鑪	貫

WADE-GILES PRONUNCIATION IS KUA1

403	809	2767	4166	7217	7223	7449	8687	9348
聒	聒	括	蝸	刮	鵠	筈	瓜	颯

WADE-GILES PRONUNCIATION IS KUA3

4007	4466	5864
劓	罫	寡

WADE-GILES PRONUNCIATION IS KUA4

484	2522	2524	4465	6915	10004
卦	挂	掛	罫	褂	絀

WADE-GILES PRONUNCIATION IS KUEI1

162	230	231	351	455	469	2184	3343	5541	7996
珪	瓌	瓌	規	圭	邨	硅	归	闺	飯

WADE-GILES PRONUNCIATION IS KUEI1

8028	8036	8037	8059	8774	8775	8776	8780	8834	9680
飯	龜	龜	歸	龟	龜	龜	鮭	龜	閏
10349	10376								
媯	媯								

WADE-GILES PRONUNCIATION IS KUEI3

343	1826	3743	3744	4927	5761	5986	7499	8041	9457
軌	軌	畧	畧	詭	愧	宄	簋	鬼	癸

WADE-GILES PRONUNCIATION IS KUEI4

258	1408	1469	3918	3952	8359	8372	8790
瑰	桂	櫃	跪	貴	刽	劓	鰓

WADE-GILES PRONUNCIATION IS KUNG1

381	682	723	748	960	5095	5102	5888	7633	8094
工	攻	功	汞	恭	龔	龔	宮	供	躬
9109	9438	9848							
肱	公	弓							

WADE-GILES PRONUNCIATION IS KUNG3

734	735	1437	2544
巩	鞏	拱	拱

WADE-GILES PRONUNCIATION IS KUNG4

WADE-GILES PRONUNCIATION IS KUNG4

560 931 1414
貢 共 楨

WADE-GILES PRONUNCIATION IS KUN3

1794 1795 3030 5189 5206 6260 6263 8826 10064 10065
輓 輓 | 袞 袞 滾 滾 鯨 鯢 鯢

WADE-GILES PRONUNCIATION IS KUN4

1544 1545
棍 棍

WADE-GILES PRONUNCIATION IS KUO1

2661 4079 4167 5029 8209
搥 囑 蝸 郭 鍋

WADE-GILES PRONUNCIATION IS KUO2

3581 3593 4065 4585 6649 8393 8852
囯 囯 國 幘 馘 號 號

WADE-GILES PRONUNCIATION IS KUO3

1008 1569 1570 3434 4153 5002 8462
菓 桴 櫛 果 螺 裹 餽

WADE-GILES PRONUNCIATION IS KUO4

2495 4008
過 過

WADE-GILES PRONUNCIATION IS KU1

1295	1327	1331	1368	1780	1955	3634	4133	6065	7391
孤	辜	鳩	菇	軀	酤	咕	咕	沽	箍
7490	7637	8882	8905	9610	10274				
孤	估	觚	觚	孤	姑				

WADE-GILES PRONUNCIATION IS KU2

1555

榰

WADE-GILES PRONUNCIATION IS KU3

577	578	587	654	658	659	667	1039	1299	1323
鼓	瞽	鼓	穀	穀	穀	穀	膏	古	嘏
1328	1344	4016	4031	4171	4475	4796	6510	6517	7205
鹽	嘏	骨	鶻	蠱	罟	詁	拈	殺	鵠
7523	8149	8570	9081	9224					
牯	鈷	谷	馱	股					

WADE-GILES PRONUNCIATION IS KU4

1330	1638	2453	2454	2458	2459	4005	5263	7023	7024
故	梏	顧	顧	顧	顧	固	痼	雇	顧
7876	8208								
僱	鋼								

WADE-GILES PRONUNCIATION IS LAI2

958	2049	2363	6126
萊	來	來	來

WADE-GILES PRONUNCIATION IS LAI4

1870	1876	1878	2364	3388	5231	5232	6092	6093	7378
賴	賴	賴	賚	睞	瀨	瀨	瀨	瀨	賴
7379	7678	8615							
賴	徠	徠							

WADE-GILES PRONUNCIATION IS LANG1

4300

郎

WADE-GILES PRONUNCIATION IS LANG2

249	250	1150	1630	4204	4205	5202	5203	7001	7002
瑯	琅	莨	榔	螂	娘	廊	廊	郎	郎
8257	8258	9010	10351						
鄧	銀	狼	鄉						

WADE-GILES PRONUNCIATION IS LANG3

5581	6999	7000	9721
閭	朗	朗	閭

WADE-GILES PRONUNCIATION IS LANG4

6325

浪

WADE-GILES PRONUNCIATION IS LAN2

929	1107	1320	1463	1590	1617	1739	2714	2735	2903
藍	蘭	蘭	婪	欄	栏	欄	攔	拦	攔
4755	4964	5479	5487	5552	6284	6471	6507	6923	6958
嵐	調	嫻	嫻	蘭	濶	濶	兰	檻	襪
6966	7038	7380	9692						
襪	調	籃	闌						

WADE-GILES PRONUNCIATION IS LAN3

1474	1902	2562	5632	5633	10028	10280	10281
攪	覽	攪	懶	懶	纜	嬾	嬾

WADE-GILES PRONUNCIATION IS LAN4

6095	6743	6748	6810
濫	爛	爛	爛

WADE-GILES PRONUNCIATION IS LAO1

2750

撈

WADE-GILES PRONUNCIATION IS LA02

1148 2007 4299 5224 5287 5914 6767
勞 醪 勞 癆 癆 牢 勞

WADE-GILES PRONUNCIATION IS LA03

729 1421 7625
老 佬 佬

WADE-GILES PRONUNCIATION IS LA04

1999 6124 6316 6797 10420
酪 潦 滌 烙 嫪

WADE-GILES PRONUNCIATION IS LA1

607 2686 3771
垃 拉 啦

WADE-GILES PRONUNCIATION IS LA2

1871 2560 3764
刺 刺 晃

WADE-GILES PRONUNCIATION IS LA3

3664
喇

WADE-GILES PRONUNCIATION IS LA4

WADE-GILES PRONUNCIATION IS LA4

16	433	2942	2943	3038	4247	4248	5044	5230	8343
鬚	鬚	攏	攏	鬚	蠟	蠟	辣	痢	蠟
6344	9085	9240	9241	10436	10437				
蠟	腊	臘	臘	邈	邈				

WADE-GILES PRONUNCIATION IS LE12

940	1036	1037	2072	2574	5501	8161	10081	10312
蕾	菑	藁	雷	搗	羸	鐺	縲	嫫

WADE-GILES PRONUNCIATION IS LE13

2209	3955	3956	3958	3959	3995	4759	4895	6207	7114
磊	畠	壘	壘	累	累	誅	誅	潔	耒
7783	9981								
偈	坐								

WADE-GILES PRONUNCIATION IS LE14

1996	1998	2234	2652	6178	6327	6586	6588	9213
爵	爵	礪	搗	汨	淚	类	類	肋

WADE-GILES PRONUNCIATION IS LENG2

1162	1420	4643	7235
稜	稜	嶺	稜

WADE-GILES PRONUNCIATION IS LENG3

WADE-GILES PRONUNCIATION IS LENG3

7087

冷

WADE-GILES PRONUNCIATION IS LENG4

1550

3368

5608

5695

楞 陵 怔 愣

WADE-GILES PRONUNCIATION IS LE1

3616

10445

嘞 ㄌㄛˋ

WADE-GILES PRONUNCIATION IS LE4

916

6455

7939

勒 泐 ㄌㄛˋ

WADE-GILES PRONUNCIATION IS LIANG2

1615

1616

3439

3897

6243

6413

6415

6416

6417

6596

梁 樑 量 踉 涼 梁 梁 梁 梁 糧

6610

7003

7066

7291

粮 良 凉 粮

WADE-GILES PRONUNCIATION IS LIANG3

2024

2026

2037

3679

7661

7664

8043

兩 𩇓 两 𩇔 俩 俩 𩇕

WADE-GILES PRONUNCIATION IS LIANG4

1786	1787	3001	3688	4252	4853	5018	5019
輶	輶	輶	晾	曉	諒	亮	亮

WADE-GILES PRONUNCIATION IS LIAO2

405	822	2350	2351	2587	3518	3731	5238	5333	5866
聊	聊	遼	鷯	撩	瞭	嘹	療	疗	寮
5994	6710	7677	8420	8967	9600	10040			
寥	燎	僚	獠	獠	辽	繚			

WADE-GILES PRONUNCIATION IS LIAO3

1351	3387	8322	9487
蓼	瞭	釧	了

WADE-GILES PRONUNCIATION IS LIAO4

5442	6605	8166
廖	料	獠

WADE-GILES PRONUNCIATION IS LIEH1

3742
咧

WADE-GILES PRONUNCIATION IS LIEH4

36	37	451	452	520	2406	2407	2408	3056	3057
𧈧	𧈧	𧈧	𧈧	𧈧	𧈧	𧈧	𧈧	𧈧	𧈧

WADE-GILES PRONUNCIATION IS LIEH4

3949	3950	6131	7057	9045	9046	9646
躡	躡	冽	冽	獵	獵	劣

WADE-GILES PRONUNCIATION IS LIEN2

174	398	420	421	422	804	842	843	844	892
連	联	聯	聯	聯	联	聯	聯	聯	蓮
1807	2324	2332	2481	4591	4592	5090	5194	5195	5725
連	奩	奩	匱	幪	幪	廉	廉	廉	憐
5780	5950	6083	6252	6261	6922	7423	7426	8229	8235
怜	帘	漣	濂	濂	漣	簾	簾	鍊	鍊
8252	8253	8785	9146	9153					
鍊	鍊	鯁	臙	臙					

WADE-GILES PRONUNCIATION IS LIEN3

9226
臉

WADE-GILES PRONUNCIATION IS LIEN4

1478	2430	4980	5388	6372	6705	6714	6980	8154	8159
棟	殮	戀	恋	澁	煉	煉	檢	鏈	鍊
8365	8366	10030	10052	10242					
敏	飲	練	練	练					

WADE-GILES PRONUNCIATION IS LING1

2376

拎

WADE-GILES PRONUNCIATION IS LING2

302	407	830	870	1274	1483	1484	2074	2094	2101
玲	聆	聆	菱	苓	櫛	櫛	靈	零	霽
3176	3181	4236	4545	6034	6442	6518	7052	7961	8318
齡	齡	齡	囡	凌	冷	鈴	凌	伶	鈴
8442	8443	8444	8446	8724	8760	8781	9500	9740	10015
瓊	瓊	鷄	翎	舠	舠	鯪	陵	灵	綾

WADE-GILES PRONUNCIATION IS LING3

4720 4740 8441
嶺 岭 領

WADE-GILES PRONUNCIATION IS LING4

4375 9416
另 令

WADE-GILES PRONUNCIATION IS LIN2

173	1445	1805	1899	2061	2256	3342	3467	4700	5228
琳	林	隣	臨	霖	磷	临	隣	嶙	淋

WADE-GILES PRONUNCIATION IS LIN2

5413	5415	5429	5431	6076	6618	6619	6752	8445	8815
麇	麟	麇	麟	淋	遴	鄰	燐	郚	鱗
9549	9550								
隣	隣								

WADE-GILES PRONUNCIATION IS LIN3

1571	1573	5185	5186	5707	5708	7067	7068
櫟	櫟	廩	廩	懍	懍	凜	凜

WADE-GILES PRONUNCIATION IS LIN4

1108	1321	3832	3833	5478	5716	7885
蔺	蔺	躡	躡	吝	恪	賃

WADE-GILES PRONUNCIATION IS LIU2

108	239	275	1691	2247	2289	3116	5315	5441	5448
留	琉	瑠	榴	硫	泵	留	瘤	琉	琉
5477	6274	6280	6409	8302	8339	9056	9060	9350	
刘	浏	流	瀏	鋤	鏐	留	劉	颶	

WADE-GILES PRONUNCIATION IS LIU3

1692	10177	10178
柳	絡	絡

WADE-GILES PRONUNCIATION IS LIU4

WADE-GILES PRONUNCIATION IS LIU4

5183	6408	6798	8516	9057
六	溜	溜	溜	溜

WADE-GILES PRONUNCIATION IS LI2

238	252	338	339	340	341	1103	1167	1168	2029
璃	璿	釐	釐	釐	釐	離	藜	藜	鸕
2033	2091	2173	3722	4492	5054	5488	5489	6277	6278
鸕	璿	厘	厘	罹	離	離	離	漓	離
6555	6957	7256	7257	7313	7314	7315	7316	7430	7431
厘	禱	梨	梨	梨	梨	梨	黎	篱	籬
8422	8976	10106							
狸	狸	縞							

WADE-GILES PRONUNCIATION IS LI3

212	1730	1971	2028	2032	3399	3999	4039	5001	6180
理	李	醴	邈	邈	里	豐	哩	裏	涅
6209	6880	6908	6909	6940	7771	8192	8795	9992	10304
澧	禮	礼	礼	裡	俚	鯉	鯉	螽	娒

WADE-GILES PRONUNCIATION IS LI4

29	77	78	424	444	1130	1163	1189	1261	1400
利	驪	驪	隸	隸	蒞	蒞	蒞	蒞	隸

WADE-GILES PRONUNCIATION IS LI4

1498	1662	1812	1893	1919	1937	2027	2030	2031	2034
櫪	櫪	櫪	鬲	吏	栗	麗	鄺	麗	鄺
2035	2066	2129	2130	2142	2143	2206	2265	2281	2381
丽	麗	厲	勵	厉	励	礪	礪	砾	厖
2382	2383	2392	2756	3049	3088	3089	3737	4142	4212
歷	曆	历	揆	鬚	驪	驪	歷	蠣	蛭
4301	4312	4376	4489	5040	5223	5240	5293	5638	6100
唳	唳	叻	詈	立	癘	癘	痢	慄	溧
6128	6358	6583	6599	7005	7055	7255	7382	7422	7662
瀝	泣	糲	粒	戾	凜	利	簞	笠	儷
7663	7681	7889	9011	9068					
儷	例	俐	獒	力					

WADE-GILES PRONUNCIATION IS LOU1

3445	3468	4294
𥇏	𥇏	𥇏

WADE-GILES PRONUNCIATION IS LOU2

1025	1138	1551	1624	3670	4024	4029	4034	4156	4199
蔓	菱	樓	樓	婁	𦵏	𦵏	𦵏	𦵏	𦵏
5180	5193	6637	7782	7865					
𦵏	𦵏	𦵏	𦵏	𦵏					

WADE-GILES PRONUNCIATION IS LOU3

565	649	2644	2743	4684	4701	7411	7441
樓	樓	樓	樓	樓	樓	樓	樓

WADE-GILES PRONUNCIATION IS LOU4

5259	5283	5343	5344	6477	6478	8200	9507
樓	樓	樓	樓	樓	樓	樓	樓

WADE-GILES PRONUNCIATION IS LO2

69	1059	1060	2343	3098	4093	4094	4164	4496	4497
羅	羅	羅	羅	羅	羅	羅	羅	羅	羅
4505	4506	7417	7418	7800	7801	8214			
羅	羅	羅	羅	羅	羅	羅			

WADE-GILES PRONUNCIATION IS LO3

2671	2673	5262	5499	6941	7772
羅	羅	羅	羅	羅	羅

WADE-GILES PRONUNCIATION IS LO4

107	274	701	709	1132	1822	2656	2799	2834	3115
駱	駱	駱	駱	落	輅	擲	擲	擲	駱
3531	4309	6365	6406	6764	8938	10175			
駱	駱	樂	洛	榮	維	絡			

WADE-GILES PRONUNCIATION IS LUAN2

4514	4515	4516	4976	4978	4979	4983	4984	4986	4988
國	國	國	樂	樂	樂	鸞	鸞	鸞	鸞
5382	5385	5386	5390	5391	5392	5394	5397	6235	6264
亦	亦	亦	鸞	鸞	鸞	李	李	灤	灤

WADE-GILES PRONUNCIATION IS LUAN3

9058	9062
卯	卯

WADE-GILES PRONUNCIATION IS LUAN4

7225	8408
乱	亂

WADE-GILES PRONUNCIATION IS LUNG2

233	234	1085	1086	1579	1580	2240	2241	2470	3457
瓏	瓏	龍	龍	櫛	櫛	櫛	櫛	龙	龍
3450	3693	3694	4259	4260	5091	5093	5094	5096	5098
龍	龍	龍	龍	龍	龍	龍	龍	龍	龍
5100	5101	5103	5336	5979	6253	6254	6954	6955	7424
龍	龍	龍	瘡	隆	瀧	瀧	龍	龍	龍
7425	9147	9148	9577						
龍	龍	龍	隆						

WADE-GILES PRONUNCIATION IS LUNG3

610	611	2689	2690	5092	5099	9542	9543
壠	壠	攏	攏	壟	壟	隴	隴

WADE-GILES PRONUNCIATION IS LUN1

2672
掄

WADE-GILES PRONUNCIATION IS LUN2

1828	4542	4737	6438	7957	9269	9391	10193
輪	圀	崙	淪	倫	駮	侖	綸

WADE-GILES PRONUNCIATION IS LUN4

4954
論

WADE-GILES PRONUNCIATION IS LUI

4361
魯

WADE-GILES PRONUNCIATION IS LU2

543	994	1151	1152	1793	2153	3239	3240	3241	3758
壚	盧	芦	芦	轡	廬	盧	顱	鸕	卢
5173	5204	6167	6171	6716	6775	7127	8179	8698	8734
廬	庐	瀘	泸	爐	炉	鑪	鑪	艦	艦

WADE-GILES PRONUNCIATION IS LU2

8793 9116

鱸 臚

WADE-GILES PRONUNCIATION IS LU3

1524 1681 2226 2615 3209 3210 3243 3253 6163 8716

虜 櫓 礪 擄 鹵 鹵 虜 虜 滷 櫓

8752 8794

櫓 魯

WADE-GILES PRONUNCIATION IS LU4

1357 1454 1455 1800 1801 2073 2295 3921 3922 4449

菜 麓 麓 輓 輓 露 碌 路 鷺 噪

5406 5422 6204 6267 6268 6503 6904 6910 7427 7428

鹿 鹿 潞 漉 漉 淥 祿 祿 麓 麓

7465 8102 8206 8331 8340 9494 9499 9747 9917 9918

錄 僂 鏞 錄 錄 陸 陸 录 戮 勳

9993 9995

录 遂

WADE-GILES PRONUNCIATION IS LU1AN2

4981 5389

孃 孃

WADE-GILES PRONUNCIATION IS LU1EH4

2654 2684 3974 3975
撈 掠 略 畧

WADE-GILES PRONUNCIATION IS LU12

85 99 1591 1740 3094 3107 4557 5565 9707
驢 駱 櫚 櫚 驢 駱 駱 閤 閤

WADE-GILES PRONUNCIATION IS LU13

4324 5435 5456 6942 6960 7797 8210 9789 9813 9823
呂 旅 脅 樓 樓 侶 鋁 屢 屢 履
10069
縷

WADE-GILES PRONUNCIATION IS LU14

3242 3248 6168 6169 7192 8672 10206 10221
慮 慮 濾 濾 氣 律 綠 綠

WADE-GILES PRONUNCIATION IS MA12

556
埋

WADE-GILES PRONUNCIATION IS MA13

4487 9447
買 买

WADE-GILES PRONUNCIATION IS MAI4

273	595	1031	1032	1763	2365	2452
麦	賣	邁	勸	卖	麥	迈

WADE-GILES PRONUNCIATION IS MANG2

1104	1129	2193	5496	5718	8147
芒	茫	茫	盲	忙	鋤

WADE-GILES PRONUNCIATION IS MANG3

952	954	4126	4127	6051	6052
莽	莽	蟒	蟒	滂	滂

WADE-GILES PRONUNCIATION IS MAN1

937

顛

WADE-GILES PRONUNCIATION IS MAN2

3370	3830	4834	4977	5384	8466	8801
瞞	蹣	謾	蠻	蛮	饅	鰻

WADE-GILES PRONUNCIATION IS MAN3

6047

滿

WADE-GILES PRONUNCIATION IS MAN4

WADE-GILES PRONUNCIATION IS MAN4

20	566	1027	3675	4584	5677	6194	8201	10071	10308
曼	曼	蔓	曼	慢	慢	漫	鎰	縵	嫵

WADE-GILES PRONUNCIATION IS MAO1

8417	8959
貓	猫

WADE-GILES PRONUNCIATION IS MAO2

28	443	1282	3048	5451	7163	8145	9469	9471	9477
髦	髦	茅	髦	旄	毛	錨	矛	蟲	螫

WADE-GILES PRONUNCIATION IS MAO3

3746	9065
昂	卯

WADE-GILES PRONUNCIATION IS MAO4

220	732	968	1727	3475	3653	4583	5491	8031	8425
瑁	耄	茂	懋	眊	冒	帽	袤	兒	貌
9055									
貿									

WADE-GILES PRONUNCIATION IS MA1

3381	3734	3798	4266	4267	5372	10255	10298	10332
嗎	麼	嗎	嘛	麼	麼	媽	媽	麼

WADE-GILES PRONUNCIATION IS MA2

1093	4129	5143	5144	5157	5229
蔴	蟆	麻	麻	麼	痲

WADE-GILES PRONUNCIATION IS MA3

62	149	183	2170	2223	3073	4107	4148	4555
馬	瑪	瑪	碼	碼	馬	螞	螞	马

WADE-GILES PRONUNCIATION IS MA4

4038	4067	4462	4483
罵	罵	罵	罵

WADE-GILES PRONUNCIATION IS MEI2

253	1176	1177	1428	1644	1645	1647	1749	2087	2088
玫	莓	莓	媒	枚	梅	梅	楣	霉	霉
4745	6495	6697	8635	9893	9894	10271			
岷	湄	煤	徽	眉	郇	媒			

WADE-GILES PRONUNCIATION IS MEI3

6393	6394	6527	7084	7085	7546	7554	8249
浼	浼	美	浼	浼	每	每	鎡

WADE-GILES PRONUNCIATION IS MEI4

3375	5297	5298	5892	8042	10263	10418
昧	痲	痲	寐	魅	妹	媚

WADE-GILES PRONUNCIATION IS MENG2

1033	1056	1144	1440	1527	3282	3373	3429	3430	3629
萌	薨	蒙	檬	檬	蒙	矇	矇	矇	矇
3749	4187	4574	4581	5494	5497	5498	5507	6064	6172
盟	虻	幪	幪	氓	蚩	蚩	氓	濛	濛
8694	8699	8730	8735	9091	9118				
朦	朦	朦	朦	朦	朦				

WADE-GILES PRONUNCIATION IS MENG3

4131	4150	4240	5615	5616	8323	8727	8763	9035
蒙	蠓	螞	懵	夢	鎗	艫	艫	猛

WADE-GILES PRONUNCIATION IS MENG4

1057	1058	1458	9490
瞢	夢	夢	孟

WADE-GILES PRONUNCIATION IS MEN2

2713	2902	5532	7848	8009	9671
扞	扞	们	们	們	門

WADE-GILES PRONUNCIATION IS MEN4

5582	5719	5784	6048	6744	6811	9722
悶	們	們	懣	燭	燭	悶

WADE-GILES PRONUNCIATION IS MIAO1

3624

喵

WADE-GILES PRONUNCIATION IS MIAO2

1035

2547

3372

苗

描

瞄

WADE-GILES PRONUNCIATION IS MIAO3

1213

1737

3556

6188

7324

8426

9653

10063

藐

杪

眇

渺

秒

邈

淼

縹

WADE-GILES PRONUNCIATION IS MIAO4

5141

5182

10406

廟

庙

妙

WADE-GILES PRONUNCIATION IS MIEH1

4289

9920

咩

乜

WADE-GILES PRONUNCIATION IS MIEH4

1054

2052

4130

6117

7416

8068

蔑

灭

蟻

滅

篋

蟻

WADE-GILES PRONUNCIATION IS MIEN2

WADE-GILES PRONUNCIATION IS MIEN2

1660 3567 5821 8008 10148

棉 眠 山 縣 綿

WADE-GILES PRONUNCIATION IS MIEN3

2300 3380 3738 3740 5651 6110 6121 6199 6200 7922

覷 眇 晃 晃 恹 沔 洹 澠 洹 俛

7924 8835 8837 8839 8842 10036

俛 免 勉 免 勉 緬

WADE-GILES PRONUNCIATION IS MIEN4

2299 2302 2367 2368

面 面 麵 麵

WADE-GILES PRONUNCIATION IS MING2

1226 1997 3471 3705 3748 4203 4330 6320 6834 8299

茗 醕 瞋 瞋 明 螟 鳴 溟 冥 銘

8850

名

WADE-GILES PRONUNCIATION IS MING4

9388

命

WADE-GILES PRONUNCIATION IS MIN2

WADE-GILES PRONUNCIATION IS MIN2

236 308 4742 9835 10207
 玟 珉 岷 民 緡

WADE-GILES PRONUNCIATION IS MIN3

2914 3784 3785 4459 5564 5573 5720 5785 6485 7548
 抵 黽 黽 𪔐 𪔐 𪔐 𪔐 𪔐 𪔐 𪔐
 7549 7556 7557 9706 9714 9836
 鰲 敏 鰲 閩 閩 慙

WADE-GILES PRONUNCIATION IS MIU4

4972 10215
 謬 繆

WADE-GILES PRONUNCIATION IS MI1

1985 3465 4293
 醅 眯 咪

WADE-GILES PRONUNCIATION IS MI2

2044 4874 5147 5148 5151 5158 5414 5430 6489 6490
 覩 謎 靡 靡 縻 縻 縻 縻 彌 彌
 6608 6863 6867 9039 9040 9855 9857 9870 9878
 迷 禰 禰 彌 彌 彌 彌 弥 弥

WADE-GILES PRONUNCIATION IS MI3

WADE-GILES PRONUNCIATION IS M13

3466 6571 6613 9850 9853
 謎 米 救 弭 弭

WADE-GILES PRONUNCIATION IS M14

2160 4890 4891 5906 5907 5909 5910 5911 5913 5989
 覓 謚 謚 宓 蜜 密 宓 蜜 密 蜜
 5990 6176 6823 6825 6893 6894 6991 7292 7293 8394
 密 泪 冂 霽 祕 祕 袂 秘 秘 覓

WADE-GILES PRONUNCIATION IS M142

2371 3576 4783 8110 9971
 彛 眸 謀 侔 牟

WADE-GILES PRONUNCIATION IS M143

794 2303
 某 有

WADE-GILES PRONUNCIATION IS M144

9476
 瞽

WADE-GILES PRONUNCIATION IS M15

2546 3346
 摸 冂

WADE-GILES PRONUNCIATION IS MO2

1094	1438	4792	5145	5146	5152	5153	5155	5156	6576
磨	模	謨	磨	磨	摩	摩	魔	魔	模
8454	8474	9089							
饅	饅	膜							

WADE-GILES PRONUNCIATION IS MO3

2511
抹

WADE-GILES PRONUNCIATION IS MO4

336	848	1009	2426	2428	2429	3539	4096	4520	4525
末	茱	莫	歿	歿	歿	眈	墨	默	墨
4528	5222	5852	6016	6061	6404	6421	6431	7233	8070
默	瘼	寞	沫	漠	沒	沒	沒	秣	畝
8073	8416	8419	9193	9207	9512				
畝	貌	貌	脉	脈	陌				

WADE-GILES PRONUNCIATION IS MU2

4308
無

WADE-GILES PRONUNCIATION IS MU3

WADE-GILES PRONUNCIATION IS MU3

2925	2927	4442	4443	5004	5005	7520	9934	9937	10269
拇	拇	母	母	亩	畝	牡	母	母	姥
10424	10425								
姆	姆								

WADE-GILES PRONUNCIATION IS MU4

1001	1010	1011	1012	1013	1014	1015	1016	1018	1019
苜	薦	墓	薦	暮	墓	幕	募	募	慕
1381	3352	3367	4573	6075	7299	7531	8190		
木	目	睦	膜	沐	穆	牧	鉅		

WADE-GILES PRONUNCIATION IS NAI3

2010	2011	8923	10286	10290	10350	10382	10385
迺	迺	乃	孌	孌	妳	妳	奶

WADE-GILES PRONUNCIATION IS NAI4

1398	2306	2311	6996	7188	8926	8927
奈	耐	奈	襪	氣	霽	霽

WADE-GILES PRONUNCIATION IS NANG2

1868	3662
囊	囊

WADE-GILES PRONUNCIATION IS NANG3

WADE-GILES PRONUNCIATION IS NANG3

2559 3685

攘 曩

WADE-GILES PRONUNCIATION IS NANG4

7982

𪔐

WADE-GILES PRONUNCIATION IS NAN1

4561

囡

WADE-GILES PRONUNCIATION IS NAN2

893 1349 1444 1559 3640 3976 4135 9625

難 南 楠 柟 喃 男 螭 难

WADE-GILES PRONUNCIATION IS NAN3

717 721 9092

赧 赧 腩

WADE-GILES PRONUNCIATION IS NAO1

2165

𪔐

WADE-GILES PRONUNCIATION IS NAO2

2523 4456 8131 9034

撓 𪔐 𪔐 𪔐

WADE-GILES PRONUNCIATION IS NA03

319	320	2297	2298	5717	5801	5802	9162	9242	9243
瑙	瑙	惱	惱	惱	惱	惱	腦	腦	腦

WADE-GILES PRONUNCIATION IS NA04

192	3143	5570	9711
鬧	鬧	鬧	鬧

WADE-GILES PRONUNCIATION IS NA2

9387	10402
拿	拏

WADE-GILES PRONUNCIATION IS NA3

4380	4437
哪	哪

WADE-GILES PRONUNCIATION IS NA4

1562	1563	2584	4100	4101	4847	4848	6951	6952	8217
衲	衲	捺	呐	呐	訥	訥	衲	衲	鈉
8218	9230	9919	10091	10092					
鈉	那	那	納	納					

WADE-GILES PRONUNCIATION IS NE14

4613	4615	7179	7180
內	內	氣	氣

WADE-GILES PRONUNCIATION IS NENG2

9974

能

WADE-GILES PRONUNCIATION IS NG1

2460

兀

WADE-GILES PRONUNCIATION IS NIANG2

10326 10352

孃 娘

WADE-GILES PRONUNCIATION IS NIANG4

1976 1989

釀 酿

WADE-GILES PRONUNCIATION IS NIA03

1192 3979 7999 8000 8101 10367 10416

蔦 甥 裊 鳥 鸟 孃 孀

WADE-GILES PRONUNCIATION IS NIA04

9827

尿

WADE-GILES PRONUNCIATION IS NIEH1

WADE-GILES PRONUNCIATION IS NIEH1

2631 2781 2878 9563
捏 捏 捻 隄

WADE-GILES PRONUNCIATION IS NIEH4

58	387	388	791	1201	1202	1203	3377	3582	3608
齧	聶	聶	聶	孽	孽	孽	齧	聶	聶
3022	3828	3913	4715	4716	6181	6348	7975	8129	8130
躡	躡	啮	孽	孽	涅	涅	臬	鑷	鍬
8141	8142	8283	8350	8351					
鑷	鍬	鍬	鍬	鍬					

WADE-GILES PRONUNCIATION IS NIEN1

860
萑

WADE-GILES PRONUNCIATION IS NIEN2

7098 7134 7305 8792 8829
年 年 黏 鮎 鯰

WADE-GILES PRONUNCIATION IS NIEN3

348 2290 2513 2611 2833 2851
輦 碾 攆 拈 撚 撚

WADE-GILES PRONUNCIATION IS NIEN4

WADE-GILES PRONUNCIATION IS NIEN4

785	786	4405	9418
廿	廿	唸	念

WADE-GILES PRONUNCIATION IS NING2

1597	1598	1602	1603	1604	2718	2719	2721	2722	2723
檸	檸	檸	檸	檸	檸	檸	檸	檸	檸
4278	4279	4280	4281	4282	5865	5866	5902	5904	5905
嚀	嚀	嚀	嚀	嚀	寧	寧	寧	寧	寧
5908	5912	7091	9000	9001	9003	9004	9005		
甯	甯	凝	甯	甯	甯	甯	甯		

WADE-GILES PRONUNCIATION IS NING4

6292	6293	6296	6297	6298	7601	7847
凇	凇	凇	凇	凇	倭	倭

WADE-GILES PRONUNCIATION IS NIN2

7874	7921
您	您

WADE-GILES PRONUNCIATION IS NIU1

10417
妞

WADE-GILES PRONUNCIATION IS NIU2

WADE-GILES PRONUNCIATION IS NIU2

7095 7519

牛 牙

WADE-GILES PRONUNCIATION IS NIU3

2918 5792 8337 9041 10212

扭 忸 鈕 犴 紐

WADE-GILES PRONUNCIATION IS NIU4

8076 8077 8078

𩚑 𩚒 𩚓

WADE-GILES PRONUNCIATION IS NI1

9616

𠂔

WADE-GILES PRONUNCIATION IS NI2

1811 2089 3478 4431 5416 5432 5790 6483 7901 8424

輓 霓 睨 呢 甍 甍 怩 泥 倪 貌

8922 9013 9830 10413

鯢 猊 尼 妮

WADE-GILES PRONUNCIATION IS NI3

2678 2900 2930 5463 5902 7873 7920

拟 拟 擬 旆 愜 你 你

WADE-GILES PRONUNCIATION IS NI4

325 3156 3356 3371 3777 4746 6492 6668 9073
匿 怒 暱 暱 昵 嶷 溺 逆 膩

WADE-GILES PRONUNCIATION IS NOU4

40 45
耨 耨

WADE-GILES PRONUNCIATION IS NO2

2805 2846 2923 7631 10387 10421
掇 挪 挪 攤 娜 娜

WADE-GILES PRONUNCIATION IS NO4

2916 4789 5642 6582
搦 諾 懦 糯

WADE-GILES PRONUNCIATION IS NUAN3

3730 6788
暖 煖

WADE-GILES PRONUNCIATION IS NUI3

8505
餒

WADE-GILES PRONUNCIATION IS NUNG2

WADE-GILES PRONUNCIATION IS NUNG2

1446	1452	1970	1972	3998	4001	4070	4071	6208	6210
𣎵	𣎵	醞	醞	農	農	𣎵	𣎵	濃	濃
6841	7267	7268	7791	7792	7984	7985	9134	9135	
农	穰	穰	儂	儂	𣎵	𣎵	膿	膿	

WADE-GILES PRONUNCIATION IS NUNG4

165

弄

WADE-GILES PRONUNCIATION IS NUN4

10278 10279

嫩 嫩

WADE-GILES PRONUNCIATION IS NU2

10397 10398 10399 10404

奴 駕 駕 孖

WADE-GILES PRONUNCIATION IS NU3

10403 10405

努 努

WADE-GILES PRONUNCIATION IS NU4

10401

怒

WADE-GILES PRONUNCIATION IS NU1EH4

3225	3230	3983	3985	4823	4825	5210	5244	5249	5250
虐	虐	嗝	嗝	謔	謔	疟	疟	瘧	瘧

WADE-GILES PRONUNCIATION IS NU13

10254

女

WADE-GILES PRONUNCIATION IS NU14

2307

慝

WADE-GILES PRONUNCIATION IS OU1

1887	1888	1889	1890	1891	1892	2484	2485	2487	2488
甌	甌	歐	鷗	歐	毆	瓠	瓠	鷗	鷗
2489	2490	3766	4801	7035					
欧	毆	呕	謳	讴					

WADE-GILES PRONUNCIATION IS OU3

48	796	3668	7783
耦	藕	嘔	偶

WADE-GILES PRONUNCIATION IS OU4

5635	5657	6094	6134
愜	愜	漚	洳

WADE-GILES PRONUNCIATION IS OI

769

丕

WADE-GILES PRONUNCIATION IS P'AI1

2786

拍

WADE-GILES PRONUNCIATION IS P'AI2

1520	1525	2607	2617	7725	7739	7744	8620	8622
排	排	排	排	牌	俳	俳	徘	徘

WADE-GILES PRONUNCIATION IS P'AI4

6336 6388

湃 派

WADE-GILES PRONUNCIATION IS P'ANG2

2078	2144	2330	2331	2471	4181	5122	5187	5188	6257
雱	厖	龐	龐	虵	螃	旁	龐	龐	滂

7836 8640 9150

傍 傍 膀

WADE-GILES PRONUNCIATION IS P'ANG3

50 4264

𪛗 𪛗

WADE-GILES PRONUNCIATION IS PIANG4

9174

胖

WADE-GILES PRONUNCIATION IS PIAN1

1715 2590 2818 6381

攀 扳 扳 潘

WADE-GILES PRONUNCIATION IS PIAN2

4222 8703 8719 8720 8721 8739 8755 8756 8757

蟠 盤 般 磐 盤 盤 般 磐 盤

WADE-GILES PRONUNCIATION IS PIAN4

3551 3552 3965 3966 6307 6538 6552 6553 6554 6921

盼 盼 畔 畔 泮 叛 判 判 叛 攀

WADE-GILES PRONUNCIATION IS PIAO1

2863 9203

拋 掬

WADE-GILES PRONUNCIATION IS PIAO2

2315 4386 5371 5419 5435 6978 9301

咆 咆 庖 麇 麇 袍 魚

WADE-GILES PRONUNCIATION IS PIAO3

WADE-GILES PRONUNCIATION IS P'AO3

3927

跑

WADE-GILES PRONUNCIATION IS P'AO4

2171 2224 2279 5320 6422 6803 9450

𪔐 𪔐 𪔐 𪔐 𪔐 𪔐 𪔐

WADE-GILES PRONUNCIATION IS P'AI1

3930

𪔐

WADE-GILES PRONUNCIATION IS P'AI2

2865 7161 7395 8680

𪔐 𪔐 𪔐 𪔐

WADE-GILES PRONUNCIATION IS P'AI4

4598 5750

𪔐 𪔐

WADE-GILES PRONUNCIATION IS P'EI1

1978 3719 9103 9104

𪔐 𪔐 𪔐 𪔐

WADE-GILES PRONUNCIATION IS P'EI2

608 3069 3265 3512 9540

𪔐 𪔐 𪔐 𪔐 𪔐

WADE-GILES PRONUNCIATION IS PIEI4

300	1840	2006	2008	2081	2083	4603	5444	5447	6107
珮	響	配	配	霈	霈	帔	旆	旆	沛
6244	7920								
沛	佩								

WADE-GILES PRONUNCIATION IS PIENG1

2202	2571	5023	5641	9249
砵	抨	烹	怦	判

WADE-GILES PRONUNCIATION IS PIENG2

32	447	584	585	1232	1264	1693	2278	3052	4116
翯	翯	彭	蟄	蓬	芄	棚	礪	翯	彭
6030	7475	9082	9214	9215					
澎	蓬	膨	朋	鵬					

WADE-GILES PRONUNCIATION IS PIENG3

2504
捧

WADE-GILES PRONUNCIATION IS PIENG4

2254	2255	2741	2742
碰	碰	撻	撻

WADE-GILES PRONUNCIATION IS P'EN1

3589

噴

WADE-GILES PRONUNCIATION IS P'EN2

9428

盆

WADE-GILES PRONUNCIATION IS P'IAO1

1930 6097 9097

飄 漂 標

WADE-GILES PRONUNCIATION IS P'IAO2

1929 10284

瓢 嫖

WADE-GILES PRONUNCIATION IS P'IAO3

2423 3379 10029

殍 嫖 嫖

WADE-GILES PRONUNCIATION IS P'IAO4

76 1927 1928 3087 5637 7656 8789

驃 票 剽 驃 嫖 嫖 嫖

WADE-GILES PRONUNCIATION IS P'IEH1

WADE-GILES PRONUNCIATION IS P'IEH1

2620 2795 3299 8380
撇 撇 瞥 瞥

WADE-GILES PRONUNCIATION IS P'IEH3

945 7093
芑)

WADE-GILES PRONUNCIATION IS P'IEH1

7015 7444 7875
翩 篇 偏

WADE-GILES PRONUNCIATION IS P'IEH2

94 98 3106 9142 9177
駢 駢 駢 駢 駢

WADE-GILES PRONUNCIATION IS P'IEH3

4888
諱

WADE-GILES PRONUNCIATION IS P'IEH4

100 3108 7699
騙 騙 片

WADE-GILES PRONUNCIATION IS P'ING1

10310
娉

WADE-GILES PRONUNCIATION IS P'ING2

488	489	938	990	1125	1481	2047	2048	4587	4594
坪	坪	苹	蘋	萍	枰	平	平	餅	餅
4607	4608	4807	4808	4994	6547	6548	7047	7048	7062
餅	餅	評	評	瓶	瓶	瓶	憑	憑	憑
7063	7130	7131	7888	9806	9811				
憑	餅	餅	凭	屏	屏				

WADE-GILES PRONUNCIATION IS P'ING4

392
聘

WADE-GILES PRONUNCIATION IS P'IN1

2680	2739	2910	2933	10325	10345
拼	拼	拚	拚	姘	姘

WADE-GILES PRONUNCIATION IS P'IN2

3185	3186	3938	9427
頻	颯	嘖	貧

WADE-GILES PRONUNCIATION IS P'IN3

4073
𠵿
𠵿

WADE-GILES PRONUNCIATION IS P'IN4

798 7542
聘 牝

WADE-GILES PRONUNCIATION IS P'II1

493 2100 2219 2221 2598 2603 2883 9802 10044 10047
坯 霹 砒 砒 批 批 披 劈 紕 紕

WADE-GILES PRONUNCIATION IS P'II2

153 154 693 1507 1513 3809 3810 3811 3812 4333
毘 毘 埤 枇 枇 毗 毘 毗 毘 啤
4504 5330 8427 8428 9201 9448 9565
羆 疲 貔 貔 脾 皮 陴

WADE-GILES PRONUNCIATION IS P'II3

759 2156 2158 2462 5237 5345 7691 7731 9443
圮 丕 邳 匹 痞 癖 仳 仳 疋

WADE-GILES PRONUNCIATION IS P'II4

5594 8052 9734 9778 9779 9792 9798 10370 10371
闢 僻 闕 毘 毘 辟 譬 媿 媿

WADE-GILES PRONUNCIATION IS P'IOU1

5076
剖

WADE-GILES PRONUNCIATION IS P'OU2

2581 2687

杯 培

WADE-GILES PRONUNCIATION IS P'OU3

1577 5073 5075

梧 瓠 瓠

WADE-GILES PRONUNCIATION IS P'OI

743 6449 9449 9592

坡 潑 頗 陂

WADE-GILES PRONUNCIATION IS P'OI2

6447 8027

婆 瞞

WADE-GILES PRONUNCIATION IS P'OI3

1925 7381

匜 匱

WADE-GILES PRONUNCIATION IS P'OI4

255 2285 6359 6614 8016 8026 8032

珀 破 泊 粕 迫 魄 迫

WADE-GILES PRONUNCIATION IS P'UI

WADE-GILES PRONUNCIATION IS PIU1

2618 2619 3257 4004 7746
撲 扑 支 撲 仆

WADE-GILES PRONUNCIATION IS PIU2

203 1083 1123 1244 1958 3859 6353 6934 7745 9248
璞 菩 蒲 葡 酺 蹠 濮 濮 僕 圃

WADE-GILES PRONUNCIATION IS PIU3

487 1526 1528 4097 4872 4873 6105 6106 6568 6570
埔 樸 朴 圃 譜 譜 浦 溥 普 普

WADE-GILES PRONUNCIATION IS PIU4

8114 8160 8532
鋪 鋪 鋪

WADE-GILES PRONUNCIATION IS PAI1

2882 7162
拏 辦

WADE-GILES PRONUNCIATION IS PAI2

7971
白

WADE-GILES PRONUNCIATION IS PAI3

1492 1656 2169 2670 2672 2789 6950 7669
栢 柏 百 摆 擺 捩 襪 佰

WADE-GILES PRONUNCIATION IS PAI4

3526 4043 6616 7135 7298
敗 唄 牌 拜 稗

WADE-GILES PRONUNCIATION IS PANG1

461 462 1635 2761 7158 7159 7620
幫 幫 柳 柳 邦 幫 兵

WADE-GILES PRONUNCIATION IS PANG3

1581 2694 7720 10135
榜 榜 榜 綁

WADE-GILES PRONUNCIATION IS PANG4

1387 2242 4106 4207 4860 8231
棒 磅 蚌 蚌 謗 鎊

WADE-GILES PRONUNCIATION IS PAN1

237 259 2819 2820 5209 5308 5309 8558 8718 8754
斑 班 搬 搬 癡 癡 癡 頒 般 般

WADE-GILES PRONUNCIATION IS PAN3

498 706 1499 1677 5563 7717 7727 9516 9571 9704
坂 坂 板 板 岡 版 版 阪 阪 闊

WADE-GILES PRONUNCIATION IS PAN4

WADE-GILES PRONUNCIATION IS PAN4

2737	2881	5050	5051	6524	6525	7860	7861	9277	10123
拌	扮	辦	辦	半	半	伴	伴	办	絆

WADE-GILES PRONUNCIATION IS PAO1

1262	5169	5175	7779	7780	9069	9220	9298
苞	褻	褻	保	煲	勺	胞	包

WADE-GILES PRONUNCIATION IS PAO2

2093
電

WADE-GILES PRONUNCIATION IS PAO3

1185	2978	5831	5832	5833	5834	6968	7777	7778	8518
葆	鵠	宝	寶	寶	寶	褓	保	堡	飽

10145 10364
綵 嫖

WADE-GILES PRONUNCIATION IS PAO4

638	648	973	2674	2854	3426	3925	6182	6719	8193
報	報	菹	报	抱	暴	趵	瀑	爆	鏹

8307	8431	8825	9300
鉋	豹	鮑	創

WADE-GILES PRONUNCIATION IS PA1

WADE-GILES PRONUNCIATION IS PA1

158	1196	1347	1750	2667	4393	4434	5347	6519	6633
琶	葩	芭	杷	捌	叭	吧	疤	靶	耙
7502	9362	9895							
芭	八	巴							

WADE-GILES PRONUNCIATION IS PA2

2592	3850	8044	8169
拔	跋	魃	鉞

WADE-GILES PRONUNCIATION IS PA3

921	2919	8338
靶	把	鈹

WADE-GILES PRONUNCIATION IS PA4

55	484	490	561	597	1936	2059	4471	4503	6099
耙	壩	壩	埧	埧	霸	霸	罢	罷	灞
6112	8573								
灞	爸								

WADE-GILES PRONUNCIATION IS PE11

1490	2161	2264	2608	3071	3267	8020
杯	盃	碑	搯	悲	悲	卑

WADE-GILES PRONUNCIATION IS PE13

WADE-GILES PRONUNCIATION IS PEI3

3157

北

WADE-GILES PRONUNCIATION IS PEI4

1190	1376	3062	3159	3263	3483	4798	5625	6738	6932
倍	孛	輩	背	輩	貝	諄	悖	焙	裨
6982	7634	7635	7832	7933	8196	8937	8978	10368	
被	備	億	倍	備	貝	備	猥	婢	

WADE-GILES PRONUNCIATION IS PENG1

4732	5317	7665	9863	9866	9879	10093	10094	10125	10181
崩	癩	倅	𦍋	𦍋	𦍋	𦍋	𦍋	𦍋	𦍋

WADE-GILES PRONUNCIATION IS PENG2

2164

甬

WADE-GILES PRONUNCIATION IS PENG4

3874	4995	6549
踴	迸	迸

WADE-GILES PRONUNCIATION IS PEN1

2320	2321	7112	8164
奔	逵	犇	犇

WADE-GILES PRONUNCIATION IS PEN3

1382 2316 9963

本 本 畚

WADE-GILES PRONUNCIATION IS PEN4

7372 9426

笨 分

WADE-GILES PRONUNCIATION IS PIAD1

11 428 1399 1477 2347 2348 2563 3033 3256 8158
 彪 彪 标 標 彪 彪 標 彪 彪 鏢

8238 8239 9157 9158 9345
 鏢 鏢 鏢 鏢 鏢

WADE-GILES PRONUNCIATION IS PIAO3

276 6913 7577 8124 10260
 表 裱 俵 錶 婁

WADE-GILES PRONUNCIATION IS PIEH1

3300 3301 3302 3305 5252 5306 8381 8382 8383 8386
 鼈 鼈 鼈 鰲 鰲 鰲 鼈 鼈 鼈 鰲

8387
 鼈

WADE-GILES PRONUNCIATION IS PIEH2

4381

剔

WADE-GILES PRONUNCIATION IS PIEH3

5303

癩

WADE-GILES PRONUNCIATION IS PIEH4

3304 3306 5667 5755 8385

慙 慙 慙 慙 慙

WADE-GILES PRONUNCIATION IS PIEN1

911 2208 7459 7990 8817 9280 10134

鞭 砭 邊 邊 鰱 边 編

WADE-GILES PRONUNCIATION IS PIEN3

2103 3528 4206 5969 7013

匾 貶 蝙 窆 扁

WADE-GILES PRONUNCIATION IS PIEN4

2661 4982 4985 5000 5045 5048 5053 5393 5395 5702

扌 變 變 卞 辯 辨 辯 变 变 怵

6238 7014 7648 8536 8647 9959 10142

汴 遍 便 采 徧 弁 緋

WADE-GILES PRONUNCIATION IS PING1

7045 7089 7623 7624 9647
 丿 冰 乒 兵 氷

WADE-GILES PRONUNCIATION IS PING3

1480 2036 5034 5038 6708 7544 8472 8486
 柄 丙 稟 稟 炳 秉 餅 餅

WADE-GILES PRONUNCIATION IS PING4

4993 5081 5235 6546 6567 6569 7828 7863
 并 竝 病 并 並 並 併 併

WADE-GILES PRONUNCIATION IS PIN1

1457 1600 1611 1648 2911 3223 5470 5875 5917 5993
 彬 檳 檳 栢 擗 邇 斌 賓 賓 賓
 6160 6294 6299 6304 6347 8559 10116 10120 10340 10341
 瀕 濱 濱 濱 浜 邠 繽 繽 嬪 嬪
 10344
 嬪

WADE-GILES PRONUNCIATION IS PIN4

25 26 30 440 441 445 2415 2416 2417 2720
 鬢 鬢 鬢 鬢 鬢 鬢 殯 殯 殯 擯

WADE-GILES PRONUNCIATION IS PIN4

2724	2731	3045	3046	3050	7851	7854	7857	9165	9166
撰	損	鬚	鬚	髻	儂	俟	儂	臍	膜
9170									
臍									

WADE-GILES PRONUNCIATION IS PI1

1883	7651	9807
逼	偏	質

WADE-GILES PRONUNCIATION IS PI2

579	882	7980
韓	葶	鼻

WADE-GILES PRONUNCIATION IS PI3

2947	2988	3639	6591	6593	7248	7251	7447	7491	8670
比	比	鄙	枇	枇	枇	枇	笔	筆	彼
9938	9961	10293	10296						
匕	鄙	妣	妣						

WADE-GILES PRONUNCIATION IS PI4

86	256	997	1007	1195	1205	1206	1210	1332	2138
驛	碧	蔽	華	萐	萐	萐	蔽	薜	威
2139	2948	2949	2950	2951	2989	2990	2991	2992	3095
威	比	死	必	必	比	死	必	必	驛

WADE-GILES PRONUNCIATION IS P14

3295	3296	3297	3298	3303	3425	3482	3505	3802	3862
敝	弊	弊	弊	幣	畢	脾	鼻	昇	蹕
4032	4042	5167	5168	5261	5304	5555	5744	6332	6333
髀	啤	庇	庇	痺	痺	闭	悞	泌	泌
6971	7031	7032	7408	7463	7464	7908	8096	8259	8260
裨	必	必	筆	篲	篲	俾	币	鈹	鈹
8376	8377	8378	8379	8384	8972	8973	9520	9522	9695
敝	弊	弊	弊	幣	狴	狴	陞	陞	閉
9793	9794	9795	9796	9797	9799	9803	9804	9856	
璧	壁	甃	甃	甃	避	臂	嬖	弼	

WADE-GILES PRONUNCIATION IS P01

304	1133	2806	2885	4288	6446	7122	8152	8456	9994
玻	菠	播	撥	波	波	鉢	鉢	餽	剝

WADE-GILES PRONUNCIATION IS P02

116	598	1124	1243	1377	1378	2194	2569	3123	3877
駁	博	薄	蔔	鵠	勃	礪	搏	駁	陪
5640	6074	7440	7905	8007	8282	8539	8715	8751	9093
博	渤	箔	伯	帛	鉤	鄱	舶	舶	脖
9100									
膊									

WADE-GILES PRONUNCIATION IS P03

3933

跛

WADE-GILES PRONUNCIATION IS P04

5017

毫

7367

簸

9456

火

9801

孽

WADE-GILES PRONUNCIATION IS PU1

2015

逋

8458

舖

WADE-GILES PRONUNCIATION IS PU2

1965

醜

WADE-GILES PRONUNCIATION IS PU3

2568

捕

3289

卜

6924

補

6935

补

WADE-GILES PRONUNCIATION IS PU4

700

埠

2135

不

2304

布

3184

步

3655

曝

5079

部

5652

怖

7439

簿

7671

佈

WADE-GILES PRONUNCIATION IS SAI1

WADE-GILES PRONUNCIATION IS SAI1

3971 8802 9133
頤 鰓 腮

WADE-GILES PRONUNCIATION IS SAI4

5836 5839
塞 賽

WADE-GILES PRONUNCIATION IS SANG1

1375 1884 2361 9633
喪 喪 喪 桑

WADE-GILES PRONUNCIATION IS SANG3

2896 4414 9634
操 噪 顙

WADE-GILES PRONUNCIATION IS SAN1

3 9962
三 叁

WADE-GILES PRONUNCIATION IS SAN3

2060 6635 6636 8453 9410 9424 9433 10018
霰 糝 糝 餓 傘 傘 傘 繖

WADE-GILES PRONUNCIATION IS SAN4

969
散

WADE-GILES PRONUNCIATION IS SA01

118	121	2891	2894	3125	3127	9138	9229	9231	10084
騷	騷	搔	搔	騷	騷	臊	騷	騷	繰

10225
繰

WADE-GILES PRONUNCIATION IS SA03

749	2901	2905	10362
埽	扫	掃	嫂

WADE-GILES PRONUNCIATION IS SA1

1285	1286	2545	7563
薩	薩	撒	仨

WADE-GILES PRONUNCIATION IS SA3

6102	6108	6109
洒	灑	灑

WADE-GILES PRONUNCIATION IS SA4

982	3919	5105
卅	趺	颯

WADE-GILES PRONUNCIATION IS SENG1

7867
僧

WADE-GILES PRONUNCIATION IS SEN1

1451
木
木

WADE-GILES PRONUNCIATION IS SE4

155	156	1374	2360	6125	6156	6414	6418	6424	6425
瑟 必	瑟 必	晉	晉	牆	澁	澁	澁	澁	澁
7245	8922								
穉	色								

WADE-GILES PRONUNCIATION IS SHAI1

7462
師

WADE-GILES PRONUNCIATION IS SHAI3

4034
殷

WADE-GILES PRONUNCIATION IS SHAI4

3451	3452	3453
晒	曬	曬

WADE-GILES PRONUNCIATION IS SHANG1

2421	3319	5119	7892	7895	8881	8904
殤	裳	商	傷	伤	觴	觴

WADE-GILES PRONUNCIATION IS SHANG3

3315 3725

賞 响

WADE-GILES PRONUNCIATION IS SHANG4

3031 3307 3308 7737

上 尚 尚 仕

WADE-GILES PRONUNCIATION IS SHAN1

225 298 991 1265 1676 2758 3870 3926 4578 4641

珊 珊 苫 菱 杉 搨 跚 跚 刪 山

4849 6077 6513 6514 6776 6975 6976 7181 8681 8705

訕 潛 羶 羶 燭 衫 衫 氤 乡 舩

8741 9143 9292 9355 10322 10389

舩 臙 刪 剗 姍 姍

WADE-GILES PRONUNCIATION IS SHAN3

5585 9513 9519 9725

閃 陝 陝 閃

WADE-GILES PRONUNCIATION IS SHAN4

101 2685 3109 3530 4193 4194 4195 5268 6230 6511

駢 擅 駢 贍 蟪 蟪 蟪 疝 汕 善

WADE-GILES PRONUNCIATION IS SHAN4

6515	6526	6887	7026	8480	8481	8483	8804	8812	8813
善	善	禮	扇	饒	饒	饒	鰾	魚善	魚善
8814	9171	9172	9175	10121	10122	10124	10328		
鰾	膳	膳	膳	繕	繕	繕	嬋		

WADE-GILES PRONUNCIATION IS SHAO1

1531	2626	6693	7254	7373	7392	7402	8700	8736
梢	捎	燒	稍	稍	捎	筲	艸	艸

WADE-GILES PRONUNCIATION IS SHAO2

1256	1696	5069	9272
芍	杓	韶	勺

WADE-GILES PRONUNCIATION IS SHAO3

9643
少

WADE-GILES PRONUNCIATION IS SHAO4

4014	9267	9270	10182
哨	劬	邵	紹

WADE-GILES PRONUNCIATION IS SHAI

2288	5278	6462	6463	6465	8314	9375	9378	9379	10202
砂	痧	沙	袞	鯊	殺	杀	殺	殺	紗

WADE-GILES PRONUNCIATION IS SHA2

4395 4408 7952 7963
啥 啥 舍 舍

WADE-GILES PRONUNCIATION IS SHA3

7911 7960
傻 傻

WADE-GILES PRONUNCIATION IS SHA4

2076 3723 7229 7507 7508 8918
霎 嘎 歆 歆 歆 歆

WADE-GILES PRONUNCIATION IS SHE12

4911
誰

WADE-GILES PRONUNCIATION IS SHENG1

760 761 762 3711 5084 7097 7101 7212 7445 7530
声 聲 聲 昇 竝 生 甥 升 笙 牲

9559
陞

WADE-GILES PRONUNCIATION IS SHENG2

10073 10074 10083 10243
繩 繩 繩 繩

WADE-GILES PRONUNCIATION IS SHENG3

7100 9645
省 省

WADE-GILES PRONUNCIATION IS SHENG4

391 394 797 800 2451 2456 3545 7199 9184 9187
聖 聖 聖 聖 盛 盛 晟 剩 賸 勝
9188 9194 9618
勝 胜 圣

WADE-GILES PRONUNCIATION IS SHEN1

247 1135 1193 1354 1356 3579 4051 6321 7176 7776
琛 浸 侵 蔘 蔘 申 呻 深 氤 伸
8086 10006
身 紳

WADE-GILES PRONUNCIATION IS SHEN2

2232 6878 6879
砵 神 神

WADE-GILES PRONUNCIATION IS SHEN3

3677 4869 4958 5883 5921 6301 7157 10342
晒 審 諗 审 審 審 矧 嫵

WADE-GILES PRONUNCIATION IS SHEN4

144 825 876 1910 2115 5620 5621 6499 6502
蜃 甚 甚 腎 蜃 慎 慎 滲 滲

WADE-GILES PRONUNCIATION IS SHE1

2322 3534
奢 賒

WADE-GILES PRONUNCIATION IS SHE2

3525 4192 5545 7213 9371 9634
貼 蛇 閣 舌 佗 閣

WADE-GILES PRONUNCIATION IS SHE3

2867 2880
捨 捨

WADE-GILES PRONUNCIATION IS SHÈ4

718 2133 2518 2521 2538 2541 4951 5417 5433 6159
赦 庫 攝 攝 攝 攝 設 麇 麇 涉

6853 6854 8089 9030 9033 9365 9422
社 社 射 捨 捨 舍 舍

WADE-GILES PRONUNCIATION IS SHIH1

871 3340 4773 5464 6147 6191 6201 7141 8058 9015
著 师 詩 施 溼 濕 濕 失 師 獅

WADE-GILES PRONUNCIATION IS SHIH1

9339 9763 9777 9953
蝨尸屍虱

WADE-GILES PRONUNCIATION IS SHIH2

380 557 1004 2167 2208 2869 3403 3555 5882 5898
十埭蒔石碩拾時时寔实
5995 7607 7710 8448 8471 8796 9421
實什鼯食蝕鮒食

WADE-GILES PRONUNCIATION IS SHIH3

90 2447 3099 4394 7140 7653 9812 10426
駛豕駛史矢使屎始

WADE-GILES PRONUNCIATION IS SHIH4

305 335 345 366 382 545 646 728 976 977
式示𩇛示士𠂔勢勢世貫
1574 1772 1924 2509 2813 2814 2862 3414 3602 4314
柿軾事拭誓逝勢是嗜啞
4763 4825 4875 4957 5039 5116 5607 5876 6849 6876
試識謚諡市適恃室不視
6877 7047 7219 7224 7388 7609 7614 8493 8494 8544
視识适舐筮仕侍飾飾釋

WADE-GILES PRONUNCIATION IS SHIH4

9048 9376
氏 弑

WADE-GILES PRONUNCIATION IS SHOU1

3269 4749 4750
収 收 収

WADE-GILES PRONUNCIATION IS SHOU3

2501 5873 6648 7160
才 守 首 手

WADE-GILES PRONUNCIATION IS SHOU4

130 363 740 2800 4080 5300 6684 7813 8400 9002
寿 壽 壽 授 獸 瘦 兽 售 受 狩
10156
綬

WADE-GILES PRONUNCIATION IS SHUAI1

2710 2711 5003
摔 摔 衰

WADE-GILES PRONUNCIATION IS SHUAI3

9237
甩

WADE-GILES PRONUNCIATION IS SHUA14

3341 4188 4189 5522 5524 5525 8060

帥 蟀 蟀 率 率 率 帥

WADE-GILES PRONUNCIATION IS SHUANG1

2062 2204 7822 9632 10287

霜 礮 雙 双 嫗

WADE-GILES PRONUNCIATION IS SHUANG3

2482

爽

WADE-GILES PRONUNCIATION IS SHUAN1

1703 2866 5533 9672

栓 拴 问 問

WADE-GILES PRONUNCIATION IS SHUAN4

6480

涮

WADE-GILES PRONUNCIATION IS SHUA1

4429 9805

唎 刷

WADE-GILES PRONUNCIATION IS SHUA3

WADE-GILES PRONUNCIATION IS SHUA3

2308

而女

WADE-GILES PRONUNCIATION IS SHUI3

6001 9648 9650

氵 冰 水

WADE-GILES PRONUNCIATION IS SHUI4

3473 4595 7280 7281

睡 悅 稅 稅

WADE-GILES PRONUNCIATION IS SHUN3

1670 4447

楯 吮

WADE-GILES PRONUNCIATION IS SHUN4

3522 3523 7743 8399

瞬 瞬 順 舜

WADE-GILES PRONUNCIATION IS SHUD1

4880 4881

說 說

WADE-GILES PRONUNCIATION IS SHUD4

2748 6670 6672 6786 8287 8310 8358 10388

掬 朔 槲 爍 鑠 銖 銖 鈞

WADE-GILES PRONUNCIATION IS SHU1

1472	1482	1504	1588	1829	1830	2419	2572	2614	2888
樞	樗	枢	梳	輸	輸	殊	樗	攄	抒
8117	8535	9354	9451	9452	9658	9896	10199	10356	
舒	舒	𠂔	疎	疏	書	书	紓	姝	

WADE-GILES PRONUNCIATION IS SHU2

986	3154	3491	5026	5027	5028	6153	7238
菽	叔	贖	孰	塾	熟	淑	秫

WADE-GILES PRONUNCIATION IS SHU3

1053	1074	3410	3411	3420	3674	4469	4470	4500	5302
薯	諸	暑	暑	墅	曙	署	署	蜀	癩
7321	7708	9781	9785	9818					
黍	鼠	屬	屬	属					

WADE-GILES PRONUNCIATION IS SHU4

1415	1613	1735	1869	1907	1909	2380	3663	3671	5137
樹	述	树	束	豎	豎	戍	唳	數	庶
6029	6090	6091	6638	7755	7756	7763	7764	8612	8613
澍	漱	漱	数	倏	倏	倏	倏	術	術
10315									
恕									

WADE-GILES PRONUNCIATION IS SOU1

1198 2782 4320 5358 6349 8277 8499 8714 8750 9349
蒐搜叟瘦洩鍇餽艘艘颶

WADE-GILES PRONUNCIATION IS SOU3

1026 1139 2645 4271 7703
藪藪擻噉隻

WADE-GILES PRONUNCIATION IS SOU4

3665 3666
嗽嗽

WADE-GILES PRONUNCIATION IS SO1

1077 1134 1756 2734 3645 4446 6464 6466 7420 10114
蓑莎梭抄噤唆等娑簑縮
10118
縮

WADE-GILES PRONUNCIATION IS SO3

209 318 1379 4010 8181 8182 8341 8691
瑣瑣索嘖鎖鎖鎖鎖所

WADE-GILES PRONUNCIATION IS SO4

2553
擦

WADE-GILES PRONUNCIATION IS SSU1

817	2126	2539	3611	3970	4220	4452	4454	5130	6041
斯	厮	撕	嘶	思	蛳	絲	噤	厮	漸
7328	7789	8207	9898	9958	10079	10222	10223	10228	10229
私	偲	錕	司	厶	總	絲	驚	糸	絲
10230									
絲									
鳥									

WADE-GILES PRONUNCIATION IS SSU3

2435
死

WADE-GILES PRONUNCIATION IS SSU4

38	49	54	92	453	500	3058	3101	4098	4549
肆	耜	耜	馬	四	肆	寺	肆	馬	四
4752	5107	6227	6486	6905	7503	7808	7970	8111	8527
兕	竢	泗	汜	祀	筭	似	似	俟	飼
8528	9840	9950	9952	10324	10407				
飼	巳	兕	兕	姦	姦				

WADE-GILES PRONUNCIATION IS SUAN1

2009	5351	9043
酸	痠	狻

WADE-GILES PRONUNCIATION IS SUAN4

367 833 7350 7404
 示 蒜 筭 算

WADE-GILES PRONUNCIATION IS SUI1

1214 3480 8932
 萎 睢 夙

WADE-GILES PRONUNCIATION IS SUI2

4020 4085 4086 9508 9510 9515 9967 10158
 髓 虽 雖 隋 隨 隨 雖 綏

WADE-GILES PRONUNCIATION IS SUI4

244 651 2246 3162 3163 4659 4727 4862 5955 6658
 璩 璩 碎 歲 歲 歲 岁 碎 邃 遂
 6753 7240 9552 9927 10024 10129
 燧 穗 隧 崇 總 緣

WADE-GILES PRONUNCIATION IS SUNG1

15 432 883 1721 3037 4647 4693 6082
 鬆 鬆 崧 松 鬆 松 嵩 淞

WADE-GILES PRONUNCIATION IS SUNG3

5052 5631 8661 8662 8663
 竦 悚 聳 聳 慫

WADE-GILES PRONUNCIATION IS SUNG4

4960 4962 5856 6559 8579

訟 誦 宋 送 頌

WADE-GILES PRONUNCIATION IS SUN1

1296 2431 8864 9036 9611 9613

蓀 殮 飧 孫 孫 孫

WADE-GILES PRONUNCIATION IS SUN3

1652 1653 2660 7480 7496

樵 樵 損 筍 笋

WADE-GILES PRONUNCIATION IS SU1

1225 1257 1280 1850 1992 3631 8819

蘇 苏 蔬 甦 酥 蘇 蘇

WADE-GILES PRONUNCIATION IS SU2

7916

俗

WADE-GILES PRONUNCIATION IS SU4

316 1114 1117 1872 1943 3423 4839 4924 5601 5862

素 蓓 蓓 速 粟 噤 謾 訴 憊 宿

5918 6088 6311 6386 6671 6673 6674 7377 8457 8870

宿 涑 溯 沂 塑 溯 愬 簌 餽 鯨

WADE-GILES PRONUNCIATION IS SU4

8893 9075 9332 9668 9669 9670

觥 肱 夙 肅 肅 肅

WADE-GILES PRONUNCIATION IS T'AI1

1355 3729 9239

苔 汰 胎

WADE-GILES PRONUNCIATION IS T'AI2

126 588 1416 1755 2529 2935 3131 9351 9965 9968

駘 臺 檯 桤 擡 抬 駘 颯 台 灸

WADE-GILES PRONUNCIATION IS T'AI4

139 861 2346 2349 6123 9976

泰 臺 太 忒 汰 態

WADE-GILES PRONUNCIATION IS T'ANG1

3861 4011 6185 8183

蹕 啗 湯 鎗

WADE-GILES PRONUNCIATION IS T'ANG2

617 2703 3312 3314 4151 4183 5405 6266 6604 9126

塘 搪 堂 棠 螳 塘 唐 澇 糖 膛

WADE-GILES PRONUNCIATION IS T'ANG3

6173 7747 7750 7751 8090 10400

淌 倘 儻 傥 躺 帑

WADE-GILES PRONUNCIATION IS T'ANG4

523 6187
趙 燙

WADE-GILES PRONUNCIATION IS T'AN1

724 2543 2754 2895 5219 5337 6045 6461 8100 9415
坍 攤 探 攤 癱 癱 灘 灘 他 貪

WADE-GILES PRONUNCIATION IS T'AN2

427 485 559 606 1401 1572 1941 1957 3470 4804
坛 壇 壇 壇 坛 檀 覃 譚 曇 譚
4882 5286 6101 6773 7124 7129 9861 9869
談 痰 潭 郊 譚 譚 彈 彈

WADE-GILES PRONUNCIATION IS T'AN3

553 1988 2662 2749 3153 6938 7168
坦 醢 揮 揮 志 袒 毯

WADE-GILES PRONUNCIATION IS T'AN4

894 2237 3615 4413 4669 4670
歎 碳 嘆 叹 炭 炭

WADE-GILES PRONUNCIATION IS T'AD1

131 364 2802 2852 3790 4377 4918 5757 6003 6020
焘 燾 搯 掏 饕 叨 諂 惱 濤 濤

WADE-GILES PRONUNCIATION IS T'AD1

6035 6376 7761 7768 9881 9890 10143 10144 10157

濤滔條條弢韜縹縹縹

WADE-GILES PRONUNCIATION IS T'AD2

741 1259 1386 1397 1423 1667 1700 4349 4383 4391

燾萄檣檣檣桃桃吽啣吽

6384 6419 6427 8582 8584 8849 9284 9320 9322 9581

洮淘洮鼗逃逃缶鼗逃陶

WADE-GILES PRONUNCIATION IS T'AD3

4815

討

WADE-GILES PRONUNCIATION IS T'AD4

2310 2318 2334

套套套

WADE-GILES PRONUNCIATION IS T'AI1

572 5996 6945 7541 8099 10419

塌它裼牠他她

WADE-GILES PRONUNCIATION IS T'AI3

472

塔

WADE-GILES PRONUNCIATION IS T'IA4

1552	2530	2650	3779	3825	3867	3939	4486	4501	5544
榻	撻	搨	搨	蹠	跖	踏	逌	逌	達
5560	8963	8964	9651	9683	9701				
廟	獺	獺	沓	闕	闕				

WADE-GILES PRONUNCIATION IS T'ENG2

1239	1240	5314	6558	7476	9180	9181	9183	9185	9186
滕	滕	疼	誊	籐	騰	騰	騰	騰	騰
9189									
滕									

WADE-GILES PRONUNCIATION IS T'EI1

3004
厶

WADE-GILES PRONUNCIATION IS T'EI4

326	1373	2104	7521	8162
慝	忒	忒	特	鉞

WADE-GILES PRONUNCIATION IS T'IAQ1

2808	2858	6897	6902
挑	挑	桃	桃

WADE-GILES PRONUNCIATION IS T'IAO2

33	448	1247	3053	4232	4939	7479	7517	7754	7762
髻	髻	茗	髻	蜩	調	筰	条	條	條
7917	7947	8935	9263						
桃	桃	条	迢						

WADE-GILES PRONUNCIATION IS T'IAO3

5970	5976
窈	窈

WADE-GILES PRONUNCIATION IS T'IAO4

3538	3549	3914	3928	8580	8583	9061	9321	9929	9930
眺	眺	跳	跳	顚	顚	顚	顚	巢	糴

WADE-GILES PRONUNCIATION IS T'IEH1

3503
貼

WADE-GILES PRONUNCIATION IS T'IEH3

8133	8134	8175	8263	8356
鐵	鐵	鐔	鉄	鉄

WADE-GILES PRONUNCIATION IS T'IEH4

2433	4579
餐	帖

WADE-GILES PRONUNCIATION IS T' IEN1

347 6018 6343

天 添 添

WADE-GILES PRONUNCIATION IS T' IEN2

473 3793 3973 5549 5741 7215 8205 9688

填 田 畋 圓 恬 甜 鈿 闐

WADE-GILES PRONUNCIATION IS T' IEN3

354 2432 3548 4003 5083 7214 7220 7514 8491 9136

忝 殄 魃 覘 悞 舔 舔 忝 飮 腆

WADE-GILES PRONUNCIATION IS T' IEN4

2515 2776

搯 搯

WADE-GILES PRONUNCIATION IS T' ING1

386 506 546 790 2119 2121 2122 2125 2145 4350

聽 聽 聽 聽 廳 廳 廳 廳 厅 听

5127

廳

WADE-GILES PRONUNCIATION IS T' ING2

2086 3807 4211 5014 5354 7210 7829 10327

霆 町 蜓 亭 庭 廷 停 婷

AD-A040 795

RCA ADVANCED TECHNOLOGY LABS CAMDEN N J

F/G 9/2

LANGUAGE MANUAL FOR USE WITH IDEOGRAPHIC COMPOSING MACHINES MOD--ETC(U)

DAA617-68-C-0064

NL

UNCLASSIFIED

3 of 5

ADA040795



WADE-GILES PRONUNCIATION IS T'ING3

1639 2706 8268 8713 8749

挺 挺 鋌 艇 艇

WADE-GILES PRONUNCIATION IS T'II

1626 3759 3865 8256

梯 剔 踢 鋸

WADE-GILES PRONUNCIATION IS T'II2

558 1967 2633 3415 3416 3718 3844 3879 3916 4263

堤 醍 提 題 鷄 唬 蹕 蹄 蹕 啼

4351 6819 6875 6944 10133

唬 鷄 禔 惕 涕

WADE-GILES PRONUNCIATION IS T'II3

4025 7642 7673

體 体 体

WADE-GILES PRONUNCIATION IS T'II4

349 1159 3469 3643 3644 3706 5680 5732 6317 6817

替 雉 睇 嚏 嚏 嚏 惕 涕 涕 剃

7941 9009 9774 9819

個 逖 屈 屈

WADE-GILES PRONUNCIATION IS T'OU1

7958

偷

WADE-GILES PRONUNCIATION IS T'OU2

1915 2864 4756 5596

頭投 一 头

WADE-GILES PRONUNCIATION IS T'OU4

7310

透

WADE-GILES PRONUNCIATION IS T'OI1

2732 2777 2778 4904 7858 9191 9192

挖 拖 托 託 佗 脱 脱

WADE-GILES PRONUNCIATION IS T'OI2

79 81 97 1866 1984 2251 3090 3092 3105 3890

馱 馱 駝 橐 陀 陀 馱 馱 駝 跔

4081 4082 6305 8001 9548 9561

鼉 鼉 沱 駝 陀 陲

WADE-GILES PRONUNCIATION IS T'OI3

1731 1732 8439

橢 橢 妥

WADE-GILES PRONUNCIATION IS T'U4

972 1671 2582 4307 6334 7393
擇 析 拓 唾 唾 擇

WADE-GILES PRONUNCIATION IS T'UAN1

6232
湍

WADE-GILES PRONUNCIATION IS T'UAN2

2557 4056 4418 5630 6579 6598
搏 團 团 博 搏 糰

WADE-GILES PRONUNCIATION IS T'UI1

2783
推

WADE-GILES PRONUNCIATION IS T'UI2

7318
頽

WADE-GILES PRONUNCIATION IS T'UI3

9233
腿

WADE-GILES PRONUNCIATION IS T'UI4

WADE-GILES PRONUNCIATION IS T'UI4

4201 9757

蛻退

WADE-GILES PRONUNCIATION IS T'UNG1

9463

通

WADE-GILES PRONUNCIATION IS T'UNG2

1560 3456 4564 4691 5059 5697 6248 7803 7833 7934

桐 瞳 同 峒 童 恫 潼 侗 僮 佟

8215 8629 8706 8742 9275 9373

銅 衙 舂 舂 彤 仝

WADE-GILES PRONUNCIATION IS T'UNG3

1724 2886 2887 7419 7489 10108

桶 捅 搗 筒 筩 統

WADE-GILES PRONUNCIATION IS T'UNG4

5332 5743

痛 慟

WADE-GILES PRONUNCIATION IS T'UN1

3686 4255 7511

噉 哼 吞

WADE-GILES PRONUNCIATION IS T'UN2

4550 8520 9029 9108 9314 9772

圉 飣 纯 豚 屯 臀

WADE-GILES PRONUNCIATION IS T'UN4

6426 6988

沌 褪

WADE-GILES PRONUNCIATION IS T'U1

7317

禿

WADE-GILES PRONUNCIATION IS T'U2

1268 2003 2041 3216 3638 4508 4547 4553 4560 5939

荼 醑 凸 凸 𪔐 圖 图 圖 圖 突

6432 6433 8607 9369 9769 9960

涂 塗 徒 途 屠 𪔐

WADE-GILES PRONUNCIATION IS T'U3

383 3580

土 吐

WADE-GILES PRONUNCIATION IS T'U4

1199 1255 8055 9268

菟 菟 兔 兔

WADE-GILES PRONUNCIATION IS TAI1

3647 4653
呆 𪔐

WADE-GILES PRONUNCIATION IS TAI3

2396
歹

WADE-GILES PRONUNCIATION IS TAI4

254	573	750	971	998	2057	2436	5221	6916	7693
玳	戴	埭	帶	帶	𪔐	殆	瘳	襪	代
7694	7695	7696	7697	8604	9748	9749	9969	9970	10219
貸	黛	岱	袋	待	逮	逮	迨	怠	給

WADE-GILES PRONUNCIATION IS TANG1

210	211	3316	3328	4012	4015	6936	6937	8184	8353
璫	瑯	當	当	噹	咘	褱	裆	鎗	铛

WADE-GILES PRONUNCIATION IS TANG3

2622	2623	2625	2627	3317	3321	4829
擋	攔	攬	挡	黨	党	讜

WADE-GILES PRONUNCIATION IS TANG4

1126	1530	1532	5727	5863	6186
蕩	檔	档	憚	宕	盪

WADE-GILES PRONUNCIATION IS TAN1

396	401	802	807	2412	2418	2629	2822	3472	4075
聃	耽	聃	耽	殫	殫	担	擔	眈	單
4077	5264	5285	6681	6682	6947	6961	7415	7443	8091
鄚	癩	癩	单	鄚	禪	禪	簞	簞	眈
9273									
丹									

WADE-GILES PRONUNCIATION IS TAN3

2566	5035	5254	9128	9208
擲	亶	疸	胆	膽

WADE-GILES PRONUNCIATION IS TAN4

3353	3586	3588	4298	4833	4906	4909	5686	6314	6391
旦	噉	噉	啖	誕	誕	誕	憚	淡	澹
7186	7769	9444	9445						
氮	但	蛋	蛋						

WADE-GILES PRONUNCIATION IS TAO1

3345	5771	9070
刂	忉	刀

WADE-GILES PRONUNCIATION IS TAO3

WADE-GILES PRONUNCIATION IS TA03

2503 2516 2535 2788 6653 6851 6852 6857 7735 7998
 持 擣 擣 搗 導 禱 禱 禱 倒 島
 9842
 導

WADE-GILES PRONUNCIATION IS TA04

3008 3910 4568 4570 4572 5664 6390 6651 7079 7303
 到 蹈 憐 憐 憐 悼 盜 道 盜 稻

WADE-GILES PRONUNCIATION IS TA1

2550 3633 3770 6919
 搭 嗒 咭 搭

WADE-GILES PRONUNCIATION IS TA2

635 898 907 1271 2317 2323 2353 3595 5225 5670
 達 韃 韃 荅 奪 奪 達 噎 瘠 怛
 7403 7483 10011 10303
 筴 答 達 姐

WADE-GILES PRONUNCIATION IS TA3

2597
 打

WADE-GILES PRONUNCIATION IS TA4

WADE-GILES PRONUNCIATION IS TA4

2309

大

WADE-GILES PRONUNCIATION IS TENG1

6711 6807 7488 9459

灯 燈 簷 登

WADE-GILES PRONUNCIATION IS TENG3

3708 7358

戔 等

WADE-GILES PRONUNCIATION IS TENG4

1723 2286 3554 3934 8320 9455 9460 9631

橈 磴 瞪 蹬 鐙 鄧 凳 邓

WADE-GILES PRONUNCIATION IS TE1

10446

刀

WADE-GILES PRONUNCIATION IS TE2

6179 8610 8611 8625

得 德 德 得

WADE-GILES PRONUNCIATION IS TIAO1

2277 4438 7086 8430 8823 9120 9122 9123 9124 9922

碉 叨 凋 貂 魚 鯛 剛 雕 鷗 彫 刀

WADE-GILES PRONUNCIATION IS TIAO3

9791
吊

WADE-GILES PRONUNCIATION IS TIAO4

1183	1184	2612	4099	5960	8292	8305	8311	9858
蓀	蓀	掉	吊	寫	鈔	鈞	鈔	吊

WADE-GILES PRONUNCIATION IS TIEH1

8572
爹

WADE-GILES PRONUNCIATION IS TIEH2

471	730	2191	2653	2897	3620	3831	3857	3878	3957
堞	堦	磔	擗	擗	喋	蹀	跼	跼	疊
4128	4145	4149	4790	6995	7150	7715	8688	8764	9635
蝶	蜨	蜨	謀	褶	迭	牒	𧈧	𧈧	疊

10048
經

WADE-GILES PRONUNCIATION IS TIEH4

503
埕

WADE-GILES PRONUNCIATION IS TIEN1

1305 2591 2699 3205 4046 5226 5227 6066

顛 擥 拈 𣪠 巔 癩 癩 滇

WADE-GILES PRONUNCIATION IS TIEN3

2235 3203 3207 4002 4521 4529

碇 𣪠 点 典 點 點

WADE-GILES PRONUNCIATION IS TIEN4

201 280 513 640 2071 2860 3783 5172 5342 5711

玷 𣪠 玷 𣪠 電 𣪠 电 店 癩 𣪠

6289 6476 6640 7383 7786 9258 9771

淀 𣪠 奠 簞 佃 甸 殿

WADE-GILES PRONUNCIATION IS TING1

180 903 1961 2492 3391 3768 5242 6135 7687 8170

汀 𣪠 𣪠 丁 𣪠 𣪠 𣪠 汀 𣪠 釘

WADE-GILES PRONUNCIATION IS TING3

2493 3431 3454

頂 鼎 鼎

WADE-GILES PRONUNCIATION IS TING4

1595 2248 4814 5851 8245

𣪠 𣪠 訂 定 錠

WADE-GILES PRONUNCIATION IS TIU1

315 7211

丟 丟

WADE-GILES PRONUNCIATION IS TI1

4334 6256 6516 7937 9534

啲 滴 抵 低 隄

WADE-GILES PRONUNCIATION IS TI2

596 1235 3969 3990 4262 4373 5118 6354 6355 7221

覲 荻 迪 迪 啗 啾 敵 滌 滌 敵

7412 8230 9008 9411 9412 9912 10331

笛 鐫 狄 采 糴 翟 嫡

WADE-GILES PRONUNCIATION IS TI3

722 1690 2276 2843 4938 5370 7534 8883 8906 9051

坻 砥 砥 砥 砥 底 抵 觥 觥 氏

9053

邸

WADE-GILES PRONUNCIATION IS TI4

767 877 1090 1494 1741 2154 4859 5120 6816 6818

地 蒂 蒂 枳 棣 遞 諦 帝 弟 遞

WADE-GILES PRONUNCIATION IS T14

6888 7500 8029 8616 10098 10348

褖第的遞締娣

WADE-GILES PRONUNCIATION IS T0U1

2790 3587 7460 8030

攪唛範兜

WADE-GILES PRONUNCIATION IS T0U3

2716 4190 5595 9498

抖蚪斗陡

WADE-GILES PRONUNCIATION IS T0U4

184	186	187	188	189	190	191	193	930	1912
鬥	鬥	鬥	鬥	鬥	鬥	鬥	鬥	豆	豆

1917	3135	3137	3138	3139	3140	3141	3142	3144	5233
逗	鬥	鬥	鬥	鬥	鬥	鬥	鬥	鬥	痘

5575	5937
斗	寶

WADE-GILES PRONUNCIATION IS T01

4365 8861

哆多

WADE-GILES PRONUNCIATION IS T02

WADE-GILES PRONUNCIATION IS T02

2333 2357 2698 6985 8211

奪 奪 掇 襍 鐸

WADE-GILES PRONUNCIATION IS T03

8092 8093 8924 9326

躲 躲 乃 朶

WADE-GILES PRONUNCIATION IS T04

713 733 1612 3882 3920 3929 4440 5644 8710 8746
 塢 塢 柁 蹠 蹠 蹠 咄 惰 舵 舵
 8925 9329 9509 9514
 剌 剌 墮 墮

WADE-GILES PRONUNCIATION IS TS'AI1

8953

猜

WADE-GILES PRONUNCIATION IS TS'AI2

615 1506 2500 3500 10166 10167 10168 10169
 裁 材 才 財 纚 纚 纚 纚

WADE-GILES PRONUNCIATION IS TS'AI3

2798 3516 3840 3909 8391 8392 10155
 採 睬 蹠 蹠 采 彩 綵

WADE-GILES PRONUNCIATION IS TSIAI4

1211 1227
菜 蔡

WADE-GILES PRONUNCIATION IS TSIANG1

1275 6443 7962 8725 8761 9420 9435
蒼 滄 傖 艫 艪 倉 包

WADE-GILES PRONUNCIATION IS TSIANG2

970
藏

WADE-GILES PRONUNCIATION IS TSIAN1

125 129 3130 3134 3222 7088 9964 9982 9983
驂 驂 驂 驂 餐 飡 参 参 叅

WADE-GILES PRONUNCIATION IS TSIAN2

1817 2404 2982 5629
慙 殘 蠶 慚

WADE-GILES PRONUNCIATION IS TSIAN3

3221 5603 5660 5797 5800
歺 慥 慥 慘 慘

WADE-GILES PRONUNCIATION IS TSIAN4

WADE-GILES PRONUNCIATION IS TS'AN4

203 6715 6735

璨 燦 灿

WADE-GILES PRONUNCIATION IS TS'AO1

2663 2938 6612

操 搽 糙

WADE-GILES PRONUNCIATION IS TS'AO2

1470 1862 3661 6087

槽 曹 嘈 漕

WADE-GILES PRONUNCIATION IS TS'AO3

1002 9928

草 艸

WADE-GILES PRONUNCIATION IS TS'AO4

9406

肉

WADE-GILES PRONUNCIATION IS TS'AI1

2726 4284

擦 擦

WADE-GILES PRONUNCIATION IS TS'ENG2

9768 9816

层 層

WADE-GILES PRONUNCIATION IS TSIENG4

3896
躋

WADE-GILES PRONUNCIATION IS TSIEN2

4739 6233
岑 岑

WADE-GILES PRONUNCIATION IS TSIE4

2182 4576 5179 5674 6184 7385 7389 7774 9291
廁 冊 廁 惻 測 策 筴 側 冊

WADE-GILES PRONUNCIATION IS TS'IDU4

1770 6005 7049
輦 湊 湊

WADE-GILES PRONUNCIATION IS TS'ID1

2252 2293 2632 2634 2736 2738 3891 3892
磋 磋 撮 撮 搓 搓 蹉 蹉

WADE-GILES PRONUNCIATION IS TS'ID2

3212 3213 4698 4699 5280 5281 7156
𪗇 𪗇 嵯 嵯 瘥 瘥 𪗇

WADE-GILES PRONUNCIATION IS TS'ID4

WADE-GILES PRONUNCIATION IS TS'ID4

2127 2542 2807 8144 8291 8551

厝 措 挫 錯 銑 坐

WADE-GILES PRONUNCIATION IS TS'UAN1

2729 3889 9434

攏 躡 永

WADE-GILES PRONUNCIATION IS TS'UAN4

5948 5959 7405 7406 7582 7586

窰 窰 纂 纂 𪔐 𪔐

WADE-GILES PRONUNCIATION IS TS'UI1

227 1567 2676 4711 7805 10095

璫 壞 摧 崔 催 纓

WADE-GILES PRONUNCIATION IS TS'UI4

1095 4268 5271 5712 6262 6602 6740 7169 7837 9090

萃 啐 瘁 悴 淬 粹 燂 毳 倅 髒

9154 9209 9210 9910

脍 脆 脆 翠

WADE-GILES PRONUNCIATION IS TS'UNG1

106 110 399 404 406 408 805 810 824 1204

聰 聰 聰 聰 聰 聰 聰 聰 聰 蔥

WADE-GILES PRONUNCIATION IS TSIUNG1

1260 3114 3118 8083 8084 9289 9290

葱 聰 驄 囟 忽 匆 忽

WADE-GILES PRONUNCIATION IS TSIUNG2

1449 1450 3275 3276 6288 8548 8549 8660

林 林 叢 叢 淙 从 丛 從

WADE-GILES PRONUNCIATION IS TSIUN1

1505 9313 9316 9978

村 邨 邨 皴

WADE-GILES PRONUNCIATION IS TSIUN2

2166

存

WADE-GILES PRONUNCIATION IS TSIUN3

5658

忖

WADE-GILES PRONUNCIATION IS TSIUN4

2494 3769 6590

寸 吋 村

WADE-GILES PRONUNCIATION IS TSIU1

5412 5428 6595 7532 7533

鹿 鹿 鹿 粗 犷 犷

WADE-GILES PRONUNCIATION IS TS'U4

1100 1924 2150 3876 5032 7429 7790 8958 8997
族 醋 蹙 蹴 就 簇 促 猎 猝

WADE-GILES PRONUNCIATION IS TSAI1

476 594 5901 10438
栽 哉 灾 災

WADE-GILES PRONUNCIATION IS TSAI3

478 4552 4687 5895
載 囡 崽 宰

WADE-GILES PRONUNCIATION IS TSAI4

2012 2016 2152 7613
再 再 在 儼

WADE-GILES PRONUNCIATION IS TSANG1

2461 3493 3498 3513 4017 4544 9077 9196
臧 贓 賊 莊 骨 葬 贓 贓

WADE-GILES PRONUNCIATION IS TSANG3

4624
𡗗

WADE-GILES PRONUNCIATION IS TSANG4

WADE-GILES PRONUNCIATION IS TSANG4

965 966 9088 9151
墓 葬 臟 脏

WADE-GILES PRONUNCIATION IS TSAN1

6620 6621 7353 7398
輅 輅 簪 簪

WADE-GILES PRONUNCIATION IS TSAN2

352 4371 4372 7935 7936 8945 8947
蚕 啫 啫 偈 偈 咎 咎

WADE-GILES PRONUNCIATION IS TSAN3

517 530 1760 2514 7887
趲 趲 撻 撻 儼 儼

WADE-GILES PRONUNCIATION IS TSAN4

350 1818 4768 4898 7209
贇 贇 贇 贇 贇

WADE-GILES PRONUNCIATION IS TSAD1

1863 3837 6581
遭 遭 糟

WADE-GILES PRONUNCIATION IS TSAD3

1128 2021 2023 3397 6215 9485 9624
藻 藻 枣 早 澡 蚤 蚤

WADE-GILES PRONUNCIATION IS TSAO4

3868	4083	4331	4842	5687	5935	5936	6692	6728	7203
躁	噪	噪	躁	燥	竈	竈	灶	燥	造
7448	7979	8004							
造	阜	皂							

WADE-GILES PRONUNCIATION IS TSA1

3680
哂

WADE-GILES PRONUNCIATION IS TSA2

2025	2201	4325	5197	6969	9327	9330
匝	砸	咱	雜	襪	朶	雜

WADE-GILES PRONUNCIATION IS TSE12

3488	3489
賊	賊

WADE-GILES PRONUNCIATION IS TSENG1

653	4493	5731	6687	7149	10132
增	罾	憎	曾	矰	繒

WADE-GILES PRONUNCIATION IS TSENG4

3520	6688	6689
贈	甌	甌

WADE-GILES PRONUNCIATION IS TSEN3

7196

怎

WADE-GILES PRONUNCIATION IS TSEN4

4767

4818

諫
諫

諫
諫

WADE-GILES PRONUNCIATION IS TSE2

213

2609

3406

3504

4569

6223

7336

7351

責 擇 嘖 則 幘 澤 蹟 簣

WADE-GILES PRONUNCIATION IS TSE4

1324

2395

3540

蹟 仄 晨

WADE-GILES PRONUNCIATION IS TSOU1

111

412

413

416

417

834

835

838

839

3119

駟 鄒 鄒 鄒 鄒 鄒 鄒 鄒 鄒 駟

4359

4772

4785

4947

7042

8779

8783

8920

9306

9497

駟 諏 諏 諏 詢 詢 詢 鄒 鄒 鄒

9501

鄒

WADE-GILES PRONUNCIATION IS TSOU3

515

走

WADE-GILES PRONUNCIATION IS TSOU4

63	64	65	66	69	70	71	72	134	2505
馬取	馬取	馬取	馬取	馬取	馬取	馬取	馬取	奏	揍
3074	3075	3076	3077	3080	3081	3082	3083		
馬取	馬取	馬取	馬取	馬取	馬取	馬取	馬取		

WADE-GILES PRONUNCIATION IS TSQ1

4040

4041

嘅 嘅

WADE-GILES PRONUNCIATION IS TSQ2

3709

昨

WADE-GILES PRONUNCIATION IS TSQ3

2117

7607

左 佐

WADE-GILES PRONUNCIATION IS TSQ4

1637	1990	3277	3278	5363	5740	6895	7640	7884	8550
柞	酢	鑿	齒	座	怍	祚	做	作	坐

WADE-GILES PRONUNCIATION IS TSQ4

9195

胙

WADE-GILES PRONUNCIATION IS TSUAN1

2765 3820 3901

攢 躡 躡

WADE-GILES PRONUNCIATION IS TSUAN3

7407 9999 10138

纂 纘 纘

WADE-GILES PRONUNCIATION IS TSUAN4

2771 2840 2841 8126 8177 8267 8352

攢 搭 搭 鑽 鈦 鑽 鈦

WADE-GILES PRONUNCIATION IS TSUI3

3195 3196 3947 3948

觜 觜 嘴 嘴

WADE-GILES PRONUNCIATION IS TSUI4

1003 1006 1654 1980 3400 3424 4482 4485

萁 萁 檣 醉 最 最 罪 罪

WADE-GILES PRONUNCIATION IS TSUNG1

24 114 117 240 439 1594 1710 1720 3044 3121

髻 驤 驤 琮 髻 棕 櫟 櫟 髻 驤

WADE-GILES PRONUNCIATION IS TSUNG1

3124 3888 3917 5849

駿踪蹤宗

WADE-GILES PRONUNCIATION IS TSUNG3

6685 7910 7945 10131 10153

总總總總總

WADE-GILES PRONUNCIATION IS TSUNG4

6606 6623 6625 10111 10160 10165 10248

綜糴糴綜縱縱縱

WADE-GILES PRONUNCIATION IS TSUN1

650 1625 6643 6644 6645 7132

樽樽尊尊遵罇

WADE-GILES PRONUNCIATION IS TSUN3

2745 4295

樽罇

WADE-GILES PRONUNCIATION IS TSU1

7260

租

WADE-GILES PRONUNCIATION IS TSU2

2701 3982 5196 5450 8240

猝足卒族鏃

WADE-GILES PRONUNCIATION IS TSU3

2409 4831 6873 6874 8552 8624 9533 10061

殂 詛 祖 祖 俎 俎 阻 組

WADE-GILES PRONUNCIATION IS TUAN1

5080

端

WADE-GILES PRONUNCIATION IS TUAN3

7144

短

WADE-GILES PRONUNCIATION IS TUAN4

6634 6780 7569 8276 10141 10234

斷 煨 段 鍛 緞 斷

WADE-GILES PRONUNCIATION IS TUI1

686

堆

WADE-GILES PRONUNCIATION IS TUI4

2262 3273 3274 6686 9553 9554 9583 9619

碓 對 懟 兑 隊 隊 队 对

WADE-GILES PRONUNCIATION IS TUNG1

WADE-GILES PRONUNCIATION IS TUNG1

580 1842 3016 4370 7189 8939
𪔐 東 东 咚 氤 冬

WADE-GILES PRONUNCIATION IS TUNG3

1170 5618
董 懂

WADE-GILES PRONUNCIATION IS TUNG4

376 1467 1516 6228 7054 7060 7333 7891 9140
动 棟 栋 洞 凍 冻 動 働 胴

WADE-GILES PRONUNCIATION IS TUN1

603 3895 5024 5703 6737
墩 蹲 敦 惇 燉

WADE-GILES PRONUNCIATION IS TUN3

1029 3546
蔓 盹

WADE-GILES PRONUNCIATION IS TUN4

4387 4388 4389 6804 8309 8588 8589 9107 9312 9315
噸 吨 噸 炖 鈍 盾 遁 遜 頓 頓

WADE-GILES PRONUNCIATION IS TUN1

694 695 3155 3598
都 都 督 嘟

WADE-GILES PRONUNCIATION IS TU2

224	310	311	313	314	1417	2177	2178	4026	4519
讀	毒	壽	毒	壽	櫛	碯	碯	髑	黷
4527	4776	4777	6031	7051	7522	7714	8987	8990	
黷	讀	讀	讀	讀	讀	讀	獨	獨	

WADE-GILES PRONUNCIATION IS TU3

468	690	3364	3492	7346	7399
堵	覩	睹	賭	篤	篤

WADE-GILES PRONUNCIATION IS TU4

1404	1867	5140	6258	8234	9079	10289	10353
杜	蠹	度	渡	鍍	肚	妬	妒

WADE-GILES PRONUNCIATION IS TZ1U1

19	435	3022	3040	3946	5248
髭	髭	𪔐	髭	吡	疵

WADE-GILES PRONUNCIATION IS TZ1U2

1156	1362	1363	1364	2195	2257	3194	4970	6676	6677
次	慈	茲	鷺	磁	磁	雌	詞	慈	茲
6678	6907	7075	7076	7082	7218	8407			
鷺	祠	瓷	瓷	餐	辭	辭			

WADE-GILES PRONUNCIATION IS TZIU3

3187 3836

此 趾

WADE-GILES PRONUNCIATION IS TZIU4

936 2022 3509 7074 8095

刺 刺 賜 次 伺

WADE-GILES PRONUNCIATION IS TZUI

53 528 529 1361 1365 1371 1841 3192 3651 4892

籽 趲 趲 茲 孳 菑 輜 貲 吱 諮

6073 6312 6506 6675 6679 7077 7078 7080 7081 7083

滋 滋 溜 茲 孳 咨 資 次 恣 姿

8342 9491 9609 10226

鎰 子 孜 緇

WADE-GILES PRONUNCIATION IS TZU3

1575 3193 3197 6295 6628 7322 7487 7968 9488 10285

梓 訾 紫 滓 籽 秭 第 仔 子 姊

10329 10392

姊 姊

WADE-GILES PRONUNCIATION IS TZU4

WADE-GILES PRONUNCIATION IS TZU4

3191 3404 5988 6011 7972
眦 眦 字 漬 自

WADE-GILES PRONUNCIATION IS UNG1

9957

厶

WADE-GILES PRONUNCIATION IS WAI1

2157

歪

WADE-GILES PRONUNCIATION IS WAI4

4364 8848

外 外

WADE-GILES PRONUNCIATION IS WANG1

2463 2465 6010 8560 8561

亢 亢 汪 允 尪

WADE-GILES PRONUNCIATION IS WANG2

148 5495

王 亡

WADE-GILES PRONUNCIATION IS WANG3

1394 4460 4612 4616 4617 5698 8046 8639 8648 10090

枉 四 罔 冈 网 惘 魍 往 徃 網

WADE-GILES PRONUNCIATION IS WANG4

3361	5492	5493	5503	5505	5506	5508
旺	望	望	忘	望	望	妄

WADE-GILES PRONUNCIATION IS WAN1

1916	4191	4987	5396	5927	6236	6265
豌	蜿	彎	弯	剗	灣	湾

WADE-GILES PRONUNCIATION IS WAN2

160	325	359	5845	9338	10189
玩	頑	頑	完	丸	紈

WADE-GILES PRONUNCIATION IS WAN3

242	1109	1119	1607	1820	1821	2250	2827	2829	3739
琬	莞	苑	惋	輓	輓	碗	挽	挽	晚
3741	3964	5926	8014	8865	10117	10119	10343	10383	10384
晚	畹	宛	皖	盪	綰	綰	婉	婉	婉

WADE-GILES PRONUNCIATION IS WAN4

1028	2430	5722	5928	9167	9916	9948
萬	万	惋	寗	腕	翫	𠂔

WADE-GILES PRONUNCIATION IS WAI1

465	466	2730	3584	4115	4353	5952	6026	10313
鼃	鼃	挖	蛙	蛙	呱	窪	洼	媧

WADE-GILES PRONUNCIATION IS WA2

10264

娃

WADE-GILES PRONUNCIATION IS WA3

2473	2474	2475	2476	2477	2478	2995	2996	2997	2998
瓦	𪔐	𪔑	𪔒	𪔓	𪔔	瓦	𪔐	𪔑	𪔒
2999	3000	7684	7733						
𪔓	𪔔	𪔕	𪔖						

WADE-GILES PRONUNCIATION IS WA4

6914 6918

袜 襪

WADE-GILES PRONUNCIATION IS WE11

944	2147	3716	4661	7330	7787	8636	8637	9538
歲	威	噦	歲	逄	偎	微	微	隈

WADE-GILES PRONUNCIATION IS WE12

1219	1220	1680	3348	4322	4554	4597	4609	4703	4713
薇	薇	桅	𠵿	唯	圍	帷	幃	巍	嵬
5539	5748	6504	6820	6821	6994	8406	8770	9735	9886
闍	惟	濰	為	为	禕	為	危	闍	韋

WADE-GILES PRONUNCIATION IS WEI2

9889 10146

緯 維

WADE-GILES PRONUNCIATION IS WEI3

309	372	1169	1346	3417	4901	5170	5171	5295	6130
緯	韋	萎	葦	韋	諉	鹽	鹽	痿	洧
6813	7329	8064	8065	8982	9567	9817	10213	10214	10412
煒	委	偉	偉	猥	隈	尾	緯	緯	媿

WADE-GILES PRONUNCIATION IS WEI4

337	467	1329	3435	3808	3978	4068	4163	4838	6206
未	恚	蔚	味	畏	胃	喂	蝟	謂	渭
6727	7331	7831	7870	7871	7913	8467	8492	8675	8676
煨	魏	位	偽	偽	偽	餵	餵	衛	衛
8677	8983	9765	9767	9900					
衛	猓	尉	慰	卫					

WADE-GILES PRONUNCIATION IS WENG1

4410 9441 9442

翁 翁 翁

WADE-GILES PRONUNCIATION IS WENG4

5528 5529 5530 9439 9440

雍 雍 雍 公 公

WADE-GILES PRONUNCIATION IS WEN1

5260 6192 6193 8800

瘟 溫 溫 鯁

WADE-GILES PRONUNCIATION IS WEN2

2079 4185 5469 5540 5547 7516 9679 9686 10105

雯 蚊 文 聞 聞 文 聞 聞 紋

WADE-GILES PRONUNCIATION IS WEN3

4384 7300 7308 9217 9287

吻 穩 穩 脰 刳

WADE-GILES PRONUNCIATION IS WEN4

2646 2706 5490 5556 6273 7581 7585 9697

搵 攪 紊 問 汶 𣵀 𣵀 問

WADE-GILES PRONUNCIATION IS WOI

1038 5947 6212 7890

萬 窩 渦 倭

WADE-GILES PRONUNCIATION IS WO3

7537

我

WADE-GILES PRONUNCIATION IS WO4

WADE-GILES PRONUNCIATION IS WD4

1311	1897	1905	2908	3178	4426	4606	6342	6479
幹	卧	臥	握	齒	屋	喔	幄	沃 渥

WADE-GILES PRONUNCIATION IS WU1

454	1402	2359	4335	4810	6021	6022	6785	8034	8035
圻	朽	巫	鳴	誣	汙	汚	鳩	烏	鄔
8103	8286	9780							
烏	鷄	屋							

WADE-GILES PRONUNCIATION IS WU2

357	1157	1471	1880	2981	3667	4172	4457	7108	9935
无	蕪	梧	吾	无	唔	蜈	吳	無	毋

WADE-GILES PRONUNCIATION IS WU3

206	207	1766	2791	5353	5735	5737	7096	7109	7110
武	鵠	五	搗	廬	忤	憮	午	舞	舞
7524	7644	7879	7897	7899	10259	10355			
悟	伍	忤	侮	侮	斌	嫵			

WADE-GILES PRONUNCIATION IS WU4

696	1502	2092	2096	2097	2448	2464	3450	4844	5634
鳩	机	霧	霧	霧	戊	兀	晤	誤	悟
5692	5893	7111	7535	8942	9286	9474	9475	9478	9479
悞	寤	迂	物	务	勿	驚	驚	驚	務

WADE-GILES PRONUNCIATION IS WU4

9480 9481 9518 9566
婺務阮鵑

WADE-GILES PRONUNCIATION IS YAI2

3382 4660
畦崖

WADE-GILES PRONUNCIATION IS YANG1

908 2413 4088 4340 4348 6217 7271
鞅殃映央鶯決秧

WADE-GILES PRONUNCIATION IS YANG2

1542 2637 5257 6306 6508 6720 6749 7859 8645 9347
楊揚瘍洋羊煬烱佯徉颺
9532 9535
阳陽

WADE-GILES PRONUNCIATION IS YANG3

5279 5282 6543 6544 7184 7938
痒癢養养氧仰

WADE-GILES PRONUNCIATION IS YANG4

1618 1621 5688 6308 6532
样樣快漾恙

WADE-GILES PRONUNCIATION IS YAO1

779	780	3676	4392	4450	4451	4751	6896	7510	8013
坳	均	嚶	么	么	哟	凹	袄	夭	邀
9098	9356	9949	9951	9996	10358				
腰	么	凹	凹	么	妖				

WADE-GILES PRONUNCIATION IS YAO2

262	263	271	299	457	1823	2801	2835	2955	4758
瑶	珧	瑤	珧	堯	輶	搖	搖	尧	嶠
4917	4934	5756	5762	5953	5956	5965	5973	6439	7912
謠	謠	搖	搖	窯	窑	窑	窑	淆	徭
7927	8401	8403	8524	8658	8666	8855	8857	9017	9020
徭	遙	飜	飭	徭	徭	遙	飜	徭	徭
9395	9396	9431	10380	10390					
肴	般	爻	姚	姚					

WADE-GILES PRONUNCIATION IS YAO3

1534	2422	2940	2941	3171	4270	5944	5984	8405
杳	殀	拗	拗	齧	咬	窅	窈	臼

WADE-GILES PRONUNCIATION IS YAO4

1197	1359	1366	1947	8402	8856
藥	药	药	要	鵠	鵠

WADE-GILES PRONUNCIATION IS YA1

1425 2124 2212 2639 2986 3646 3781 6680
 壓 压 壓 押 鴉 鴨 呀 丫

WADE-GILES PRONUNCIATION IS YA2

182 872 978 1512 2120 2983 4146 6115 8614
 琊 芽 芽 𪔐 厓 牙 𪔐 涯 衙

WADE-GILES PRONUNCIATION IS YA3

746 2985 3605 3627 5216
 雅 雅 啞 哑 瘕

WADE-GILES PRONUNCIATION IS YA4

782 1137 1839 2558 2984 4819 7173 8139 10270
 亞 亚 軋 揶 𪔐 𪔐 𪔐 𪔐 𪔐

WADE-GILES PRONUNCIATION IS YEH1

409 2038 3596
 耶 世 噎

WADE-GILES PRONUNCIATION IS YEH2

831 1406 1431 2520 2540 8568 8569 8574
 耶 椰 椰 椰 椰 爺 爺 爷

WADE-GILES PRONUNCIATION IS YEH3

WADE-GILES PRONUNCIATION IS YEH3

1448 3419 7092 9901

埜 野 冶 也

WADE-GILES PRONUNCIATION IS YEH4

878 2181 2213 3270 3271 3272 3774 4835 5174 5177

葉 頁 壓 業 業 業 曳 謁 夜 夜

6259 6698 6718 9152

液 燁 燁 腋

WADE-GILES PRONUNCIATION IS YEN1

483 486 509 510 1101 1960 2214 2335 2337 2338

堙 堙 焉 鄢 菸 醃 愿 剗 奄 剗

4089 4667 5553 5650 6122 6704 6706 6707 6731 9086

咽 崦 庵 懣 淹 煙 煙 煙 烟 燕

9106 9139 9693 10266

腌 胭 閤 媽

WADE-GILES PRONUNCIATION IS YEN2

551 678 1143 1679 1898 2174 2179 4057 4058 4084

盐 盐 严 檐 鹽 研 研 嚴 嚴 岫

4218 4662 4688 4689 4757 5088 5265 5475 5534 5588

蜒 岩 巖 巖 言 顏 癌 顏 闫 阎

WADE-GILES PRONUNCIATION IS YEN2

5592	6429	6754	6795	6802	7454	7473	7627	7730	9673
閤	沿	炎	焰	焰	筵	簷	延	延	閤
9728	9732	10258	10261						
閤	閤	妍	妍						

WADE-GILES PRONUNCIATION IS YEN3

245	2215	2586	2870	3563	4481	5190	6291	6755	6866
琰	魘	掩	揜	眼	罨	兗	演	剡	猷
7709	7711	7794	7795	8643	8985	8986	9381		
鼠	鼠	儼	儼	衍	獫	獫	弇		

WADE-GILES PRONUNCIATION IS YEN4

56	112	115	481	926	927	1854	1973	1974	2141
艷	驗	驗	堰	燕	鶯	郾	醞	醞	厭
2211	2216	2231	2385	2386	2387	2388	3065	3066	3067
厭	饜	硯	雁	贗	鴈	贗	豔	豔	艷
3120	3122	3617	3699	3700	4000	4249	4788	4824	4856
驗	驗	燕	晏	鸚	鸚	言	讌	讌	諺
4864	5087	5474	5886	5999	6152	6756	7115	7649	8868
諺	彦	彦	宴	鸚	豔	焱	艷	偃	燄
9285	10272								
召	燄	燄							

WADE-GILES PRONUNCIATION IS YING1

171	214	1050	1541	2636	3427	3506	3507	3508	4045
瑛	瓔	英	櫻	櫻	映	嬰	嬰	鸚	嬰
5191	5360	5361	5362	6765	6766	10062			
应	應	鷹	膺	營	鶯	纓			

WADE-GILES PRONUNCIATION IS YING2

1147	1688	2018	4160	4161	4168	5500	5502	6279	6757
營	楹	迎	蠅	蠅	蠅	羸	羸	羸	螢
6758	6760	6761	6762	6763	6771	8929	9066		
瑩	營	螢	營	螢	縈	盈	迎		

WADE-GILES PRONUNCIATION IS YING3

3690	5256	9939	9945	9946
影	癭	穎	穎	穎

WADE-GILES PRONUNCIATION IS YING4

2198	3672	9190
硬	映	媵

WADE-GILES PRONUNCIATION IS YIN1

1051	4257	4341	5057	5269	6098	6104	6949	7178	8689
茵	噤	因	音	瘖	湮	湮	裊	氤	殷

WADE-GILES PRONUNCIATION IS YIN1

8690	9580	9584	9586	9589	9590	10316	10363	10377
慇	阴	陰	陰	陰	陰	姻	嫻	嫻

WADE-GILES PRONUNCIATION IS YIN2

751	891	2084	2085	3174	4342	4403	5569	5858	6373
垠	鄞	霽	霽	齒	吟	吟	閭	寅	淫
6375	8332	8654	8991	9710	10372	10375			
淫	銀	夤	狔	閭	姪	姪			

WADE-GILES PRONUNCIATION IS YIN3

4243	5335	6630	8507	8508	9486	9569	9575	9742	9859
蚓	癰	糲	飲	飲	又	隱	隱	尹	引

WADE-GILES PRONUNCIATION IS YIN4

1288	1289	1290	1291	5376	5377	5378	5379	5951	7599
蔭	蔭	蔭	蔭	廕	廕	廕	廕	審	印
9357									
胤									

WADE-GILES PRONUNCIATION IS YUNG1

616	634	5316	5352	5402	5526	5527	5531	5713	7842
壙	壙	痾	癰	庸	雍	壅	養	慵	傭
8237	9163	10434	10435						
鏞	雍	邕	雝						

WADE-GILES PRONUNCIATION IS YUNG2

1118	1140	1606	1609	4055	4702	5922	5978
蓉	蓉	榕	榕	噶	嶸	容	容

WADE-GILES PRONUNCIATION IS YUNG3

744	2712	2845	3935	3936	4239	4302	4889	6330	6450
埔	擁	拥	踊	踴	蛹	咏	詠	泳	涌
6451	6452	7028	7967	9462	9465	9466			
滬	湧	永	俑	甬	兪	勇			

WADE-GILES PRONUNCIATION IS YUNG4

7940	9113
佣	用

WADE-GILES PRONUNCIATION IS YU1

46	2205	4273	4453	4753	5421	5437	5656	7670	7683
穰	憂	唷	呦	幽	麀	麀	忧	優	优
7753	7757								
攸	悠								

WADE-GILES PRONUNCIATION IS YU2

1234	1806	2468	3794	3991	4162	4184	5241	5461	6203
猶	輜	尤	由	邨	蚰	蝓	疣	遊	油

WADE-GILES PRONUNCIATION IS YU2

6270 6641 7105 8204 8404 8791 8858 8970 9006 9007
游 猷 郵 鈞 繇 魷 繇 犹 猶 猶

WADE-GILES PRONUNCIATION IS YU3

1166 1950 2393 2438 4534 4537 6539
莠 酉 有 友 黝 黝 羨

WADE-GILES PRONUNCIATION IS YU4

1554 2168 4354 4900 5869 6864 6865 7668 7680 7712
柚 右 囿 誘 宥 祐 祐 佑 侑 鼯
7721 8538 9617 10227
牖 糅 又 幼

WADE-GILES PRONUNCIATION IS YU1AN1

2954 5923 5924 6351 6380 6838 6839 8867
鳶 冤 冤 淵 淵 冤 冤 鴛

WADE-GILES PRONUNCIATION IS YU1AN2

358 360 361 477 593 831 1758 1776 2389 2797
元 黿 黿 垣 袁 堇 緣 轅 原 援
3762 4044 4511 6019 6129 8390 8955 9016 10205 10220
園 員 圓 沅 源 爰 猿 援 緣 緣
10373
媛

WADE-GILES PRONUNCIATION IS YUIAN3

362 592 3961
远 遠 園

WADE-GILES PRONUNCIATION IS YUIAN4

260 1228 2390 2391 2939 8866 9547
瑗 苑 願 愿 掾 怨 院

WADE-GILES PRONUNCIATION IS YUIEH1

3350 3843 4103 10185
曰 噦 噦 約

WADE-GILES PRONUNCIATION IS YUIEH4

521	539	1411	1790	3291	3294	3775	3780	3903	3941
越	趯	越	軌	耀	耀	曜	曜	跃	躍
3945	4731	5580	5729	5730	6436	6814	7484	7619	8038
躍	嶽	閱	悅	悅	滌	耀	籥	岳	樂
8080	8171	8303	8315	8357	9071	9127	9317	9382	9719
粵	鉞	鉤	鑰	鉤	月	刖	乐	龠	閱
9720									
閱									

WADE-GILES PRONUNCIATION IS YUINI

WADE-GILES PRONUNCIATION IS YUIN1

7177
氫

WADE-GILES PRONUNCIATION IS YUIN2

44	373	855	939	2055	3753	7234	7360	9282	10002
耘	云	芸	雲	雲	昀	耘	筠	勻	紆

WADE-GILES PRONUNCIATION IS YUIN3

2236	2411	9044	9539	9979
碩	殞	狃	隕	允

WADE-GILES PRONUNCIATION IS YUIN4

374	1127	1358	1951	1968	3703	5066	5070	5676	5733
运	蒨	蘊	酖	醞	暈	韻	韵	愠	憚
6724	6827	6830	8928	9766	9888	10070			
焜	運	鄚	孕	熨	韞	緼			

WADE-GILES PRONUNCIATION IS YUI1

370	3684	5272	6271	10001
迂	愚	瘀	淤	紆

WADE-GILES PRONUNCIATION IS YUI2

301	368	369	425	1182	1708	2058	2873	2875	3245
瑜	于	盂	圩	萸	榆	雩	揄	於	虞

WADE-GILES PRONUNCIATION IS YU12

3681	3931	4685	4908	5465	5778	5779	6392	6440	7356
禺	踰	嶧	誤	於	愉	愉	漁	渝	筭
7566	7575	7606	7702	7705	8374	8375	8523	8777	9200
輿	與	與	昇	臾	覲	鼯	餘	魚	腴
9366	9367	9398	9467	9536	10319	10394			
余	畚	俞	予	隅	娛	好			

WADE-GILES PRONUNCIATION IS YU13

2017	2019	3023	3167	3967	4074	4337	4800	5301	5359
雨	雨	与	齒	吾	圉	圉	噢	語	庾
5850	5971	7570	7602	7652	7686	8049	9903	9904	10444
宇	窳	與	與	偃	佝	禹	羽	羽	与

WADE-GILES PRONUNCIATION IS YU14

119	228	480	854	1633	1716	1717	1718	1853	2394
馭	玉	域	芋	鬱	鬱	鬱	鬱	彘	郁
3126	3682	3691	3804	4139	4401	4721	4955	4956	5181
馭	遇	昱	畝	蛾	喻	峪	諭	諭	厲
5324	5325	5513	5551	5809	5885	6382	6453	6725	6973
瘉	癒	育	國	譽	寓	浴	瀕	煜	裕
7467	7547	7555	7573	7604	8123	8362	8495	8553	8554
籲	毓	毓	譽	譽	鉦	顙	飫	欲	慾

WADE-GILES PRONUNCIATION IS YU14

8649	8650	8651	8652	8992	9399	9400	9468	9472	9473
御	禦	御	禦	獄	逾	愈	預	裔	鵠
9463	9658	9690	9868	10282	10292				
豫	聿	闕	嚮	姬	姬				

CHINESE PINYIN PRONUNCIATION

PINYIN PRONUNCIATION IS A11

773 2491 2936 3028 3632 4253 4445 5020 9973
埃 历 挨 历 哎 嚷 唉 哀 欸

PINYIN PRONUNCIATION IS A12

2577 8010
捱 皀

PINYIN PRONUNCIATION IS A13

127 1075 2075 3132 7152
駢 藹 靄 駢 矮

PINYIN PRONUNCIATION IS A14

261 1266 2056 2230 2292 3392 3521 3732 4346 8397
璦 艾 爰 碍 礙 尋 曖 曖 曖 爰
8398 9551 10374
愛 隘 嫒

PINYIN PRONUNCIATION IS ANG1

9160
肮

PINYIN PRONUNCIATION IS ANG2

3747
昂

PINYIN PRONUNCIATION IS ANG4

4344

盜

PINYIN PRONUNCIATION IS AN1

909 953 2336 2339 4854 5165 5997 7183 8248 9897
鞍 菴 鵠 鵠 諳 庵 安 氨 鉸 弓

PINYIN PRONUNCIATION IS AN3

3727 7675
啞 俺

PINYIN PRONUNCIATION IS AN4

2733 3692 4523 4531 4658 5571 5998 9712
按 暗 黯 黯 岸 啇 案 闇

PINYIN PRONUNCIATION IS A02

286	287	288	289	291	292	293	294	295	296
敖	鰲	敖	鰲	鰲	鰲	敖	敖	敖	敖
297	619	620	621	622	624	625	626	627	628
敖	敖	敖	敖	敖	敖	敖	敖	敖	敖
629	630	3413	3594	5124	5129	5418	5434	7989	7993
敖	敖	敖	敖	敖	敖	敖	敖	敖	敖

PINYIN PRONUNCIATION IS A02

7995

翱

PINYIN PRONUNCIATION IS A03

6966 6912 10307

袄 襖 媼

PINYIN PRONUNCIATION IS A04

5754 6367 6787 7579 7621 8082 9568

懊 澳 燠 傲 傲 奥 奥

PINYIN PRONUNCIATION IS A1

4411 10252

啊 丫

PINYIN PRONUNCIATION IS A4

9506

阿

PINYIN PRONUNCIATION IS BA11

2862 7162

拏 掰

PINYIN PRONUNCIATION IS BA12

7971

白

PINYIN PRONUNCIATION IS BAI3

1492 1656 2169 2670 2672 2789 6950 7669

栢 柏 百 摆 擺 裨 襪 佰

PINYIN PRONUNCIATION IS BAI4

3526 4043 6616 7135 7298

敗 嘅 稗 拜 稗

PINYIN PRONUNCIATION IS BANG1

461 462 1635 2761 7158 7159 7620

幫 幫 梆 梆 邦 幫 兵

PINYIN PRONUNCIATION IS BANG3

1581 2694 7720 10135

榜 榜 榜 綁

PINYIN PRONUNCIATION IS BANG4

1387 2242 4106 4207 4860 8231

棒 磅 蚌 蚌 謗 鎊

PINYIN PRONUNCIATION IS BAN1

237 239 2819 2820 5209 5308 5309 8558 8718 8754

斑 班 搬 搬 癩 癩 癩 頒 般 般

PINYIN PRONUNCIATION IS BAN3

PINYIN PRONUNCIATION IS BAN3

498 706 1499 1677 5563 7717 7727 9516 9571 9704

坂 坂 板 板 阪 版 版 阪 阪 阪

PINYIN PRONUNCIATION IS BAN4

2737 2881 5050 5051 6524 6525 7860 7861 9277 10123

拌 扮 辦 辦 半 半 伴 伴 办 絆

PINYIN PRONUNCIATION IS BAQ1

1262 5169 5175 7779 7780 9069 9220 9298

苞 褓 褓 保 煲 勺 胞 包

PINYIN PRONUNCIATION IS BAQ2

2093

雹

PINYIN PRONUNCIATION IS BAQ3

1185 2978 5831 5832 5833 5834 6968 7777 7778 8518

葆 鵠 宝 寶 寶 寶 裸 保 堡 飽

10145 10364

縹 嫖

PINYIN PRONUNCIATION IS BAQ4

638 648 973 2674 2854 2920 3426 3925 6719 8193

報 報 抱 抱 報 暴 趵 爆 鏹

PINYIN PRONUNCIATION IS BA04

8307 8431 8825 9300

鮑 豹 鮑 包

PINYIN PRONUNCIATION IS BA1

158 1196 1347 1750 2667 4393 4434 5347 6519 6633

琶 葩 芭 杷 捌 叭 吧 疤 靶 粑

7502 9362 9895

笆 八 巴

PINYIN PRONUNCIATION IS BA2

2592 3850 8044 8169

拔 跋 魃 鉞

PINYIN PRONUNCIATION IS BA3

921 2919 8338

靶 把 鈹

PINYIN PRONUNCIATION IS BA4

55 484 490 561 597 1936 2059 4471 4503 6099

耙 壩 壩 埧 坝 霸 霸 罢 罷 灞

6112 8573

霸 爸

PINYIN PRONUNCIATION IS BE11

PINYIN PRONUNCIATION IS BEI1

1490 2161 2264 2608 3071 3267 8020

杯 盃 碑 搯 悲 悲 卑

PINYIN PRONUNCIATION IS BEI3

3157

北

PINYIN PRONUNCIATION IS BEI4

1190 1376 3062 3159 3263 3483 4798 5625 6738 6932

倍 孛 輩 背 輩 貝 諄 悖 焙 褻

6982 7634 7635 7832 7933 8196 8937 8978 10368

被 備 憊 倍 備 銀 备 狽 婢

PINYIN PRONUNCIATION IS BENG1

4732 5317 7663 9863 9866 9879 10093 10094 10125 10181

崩 癩 倅 弅 弅 弅 繃 絳 絳 繃

PINYIN PRONUNCIATION IS BENG2

2164

甬

PINYIN PRONUNCIATION IS BENG4

3674 4995 6549

踴 迸 迸

PINYIN PRONUNCIATION IS BEN1

2320 2321 7112 8164
奔 逵 犇 銍

PINYIN PRONUNCIATION IS BEN3

1382 2316 9963
本 夲 畚

PINYIN PRONUNCIATION IS BEN4

7372 9426
笨 仝

PINYIN PRONUNCIATION IS BIAN1

911 2268 7459 7990 8817 9280 10134
鞭 砭 邊 邊 鰱 边 編

PINYIN PRONUNCIATION IS BIAN3

2103 3528 4206 5969 7013
匾 貶 蝙 窵 扁

PINYIN PRONUNCIATION IS BIAN4

2681 4982 4985 5000 5045 5048 5053 5393 5395 5702
抃 變 變 卞 辯 辯 辯 变 变 忤
6238 7014 7648 8536 8647 9959 10142
汴 遍 便 采 徧 弁 緋

PINYIN PRONUNCIATION IS BIA01

11	428	1399	1477	2347	2348	2563	3033	3256	8158
髡	髡	标	標	焱	飊	標	髡	彪	鏢
8238	8239	9157	9158	9345					
鏢	鏢	廳	廳	飊					

PINYIN PRONUNCIATION IS BIA03

276	6913	7577	8124	10260
表	裱	俵	錶	婁

PINYIN PRONUNCIATION IS BIE1

3300	3301	3302	3305	5252	5306	8381	8382	8383	8386
鼉	鼉	鼉	鰲	瘵	瘵	鼉	鼉	鼉	鰲
6387									
鰲									

PINYIN PRONUNCIATION IS BIE2

4361
別

PINYIN PRONUNCIATION IS BIE3

5303
癰

PINYIN PRONUNCIATION IS BIE4

3304 3306 5667 5755 8385
憊 憊 憊 憊 憊

PINYIN PRONUNCIATION IS BING1

7045 7089 7623 7624 9647
冰 冰 兵 兵 冰

PINYIN PRONUNCIATION IS BING3

1480 2036 5034 5038 6708 7544 8472 8486
柄 丙 稟 稟 炳 秉 餅 餅

PINYIN PRONUNCIATION IS BING4

4993 5081 5235 6546 6567 6569 7828 7863
并 竝 病 并 並 並 併 併

PINYIN PRONUNCIATION IS BIN1

1457 1600 1611 1648 2911 3223 5470 5875 5917 5993
彬 檳 檳 檳 擗 邇 斌 賓 賓 賓

6160 6294 6299 6304 6347 8559 10116 10120 10340 10341
瀕 濱 濱 濱 浜 邠 繽 繽 嬪 嬪

10344

嬪

PINYIN PRONUNCIATION IS BIN4

25	26	30	440	441	445	2415	2416	2417	2720
鬚	鬚	鬚	鬚	鬚	鬚	殯	殯	殯	擯
2724	2731	3045	3046	3050	7851	7854	7857	9165	9166
揆	擯	鬚	鬚	鬚	儗	儗	儗	臚	臚
9170									
臚									

PINYIN PRONUNCIATION IS B11

1883	7651	9807
逼	偏	戾

PINYIN PRONUNCIATION IS B12

579	882	7980
聾	葶	鼻

PINYIN PRONUNCIATION IS B13

2947	2988	3639	6591	6593	7248	7251	7447	7491	8670
比	比	鄙	粃	粃	粃	粃	笔	筆	彼
9938	9961	10293	10296						
匕	鄙	妣	妣						

PINYIN PRONUNCIATION IS B14

PINYIN PRONUNCIATION IS 814

86	256	997	1007	1195	1205	1206	1210	1332	2138
驛	碧	蔽	華	萐	萐	萐	蔽	辟	甯
2139	2948	2949	2950	2951	2989	2990	2991	2992	3095
甯	比	比	必	必	比	比	必	必	驛
3295	3296	3297	3298	3303	3425	3482	3505	3802	3862
敝	敝	弊	敝	幣	畢	睥	鼻	鼻	蹕
4032	4042	5167	5168	5261	5304	5555	5744	6332	6333
髀	啤	庇	庇	痺	痺	閉	悞	泌	泌
6971	7031	7032	7408	7463	7464	7908	8096	8259	8260
裨	必	必	篳	篳	篳	俾	巾	鈹	鈹
8376	8377	8378	8379	8384	8972	8973	9520	9522	9695
敝	弊	弊	斃	幣	狴	狴	陞	陞	閉
9793	9794	9795	9796	9797	9799	9803	9804	9856	
壁	壁	壁	壁	壁	避	臂	嬖	弼	

PINYIN PRONUNCIATION IS 801

304	1133	2806	2885	4288	6446	7122	8152	8456	9994
玻	波	播	撥	波	波	鉢	鉢	餽	剝

PINYIN PRONUNCIATION IS 802

116	598	1124	1243	1377	1378	2194	2569	3123	3877
駁	博	薄	蔔	鵠	勃	礪	搏	駁	踣

PINYIN PRONUNCIATION IS BU2

3640 6074 7440 7905 8007 8282 8539 8715 8751 9093
博 渤 箔 伯 帛 鉞 鄱 舶 舶 膊
9100
膊

PINYIN PRONUNCIATION IS BU3

3933
跛

PINYIN PRONUNCIATION IS BU4

5017 7367 9456 9801
亳 簸 夬 擘

PINYIN PRONUNCIATION IS BU1

2015 8458
逋 舖

PINYIN PRONUNCIATION IS BU2

1965
醜

PINYIN PRONUNCIATION IS BU3

2568 3289 6924 6935
捕 卜 補 补

PINYIN PRONUNCIATION IS BU4

700 2135 2304 3184 3655 5079 5652 7439 7671
埠 不 布 步 曝 部 怖 簿 佈

PINYIN PRONUNCIATION IS CAI1

8953

猜

PINYIN PRONUNCIATION IS CAI2

615 1506 2500 3500 10166 10167 10168 10169
裁 材 才 財 纔 纔 纔 纔

PINYIN PRONUNCIATION IS CAI3

2798 3516 3840 3909 8391 8392 10155
採 睬 跽 踩 采 彩 綵

PINYIN PRONUNCIATION IS CAI4

1211 1227

菜 蔡

PINYIN PRONUNCIATION IS CANG1

1275 6443 7962 8725 8761 9420 9435

蒼 滄 傖 艙 倉 倉 倉

PINYIN PRONUNCIATION IS CANG2

PINYIN PRONUNCIATION IS CANG2

970

藏

PINYIN PRONUNCIATION IS CAN1

125 129 3130 3134 3222 7088 9964 9982 9983
 駢 駢 駢 駢 餐 餐 參 參 叅

PINYIN PRONUNCIATION IS CAN2

352 1817 2404 2982 5629
 蚕 慙 殘 蠶 慚

PINYIN PRONUNCIATION IS CAN3

3221 5603 5660 5797 5800
 粲 懣 懣 慘 慘

PINYIN PRONUNCIATION IS CAN4

203 6715 6735
 璨 燦 灿

PINYIN PRONUNCIATION IS CA01

2663 2938 6612
 操 搽 糙

PINYIN PRONUNCIATION IS CA02

1470 1862 3661 6087
 槽 曹 嘈 漕

PINYIN PRONUNCIATION IS CAQ3

1002 9928

草 𦰩

PINYIN PRONUNCIATION IS CAQ4

9406

肉

PINYIN PRONUNCIATION IS CA1

2726 4284

擦 𦰩

PINYIN PRONUNCIATION IS CENG2

9768 9816

层 層

PINYIN PRONUNCIATION IS CENG4

3896

蹭

PINYIN PRONUNCIATION IS CEN2

4739 6233

岑 岑

PINYIN PRONUNCIATION IS CE4

PINYIN PRONUNCIATION IS CE4

2182	4576	5179	5674	6184	7385	7389	7774	9291
廁	冊	廁	惻	測	策	筴	側	冊

PINYIN PRONUNCIATION IS CHAI1

2612	8321	8324
拆	釵	釵

PINYIN PRONUNCIATION IS CHAI2

3189	7835	7846	8421	8971
柴	儕	儕	豺	豺

PINYIN PRONUNCIATION IS CHAI4

1030
蔓

PINYIN PRONUNCIATION IS CHANG1

1024	3652	5559	7564	7610	7738	8980	9700	10306
菖	昌	昌	佺	佺	佺	猖	閻	娼

PINYIN PRONUNCIATION IS CHANG2

8	426	793	857	983	3032	3311	3313	3318	4013
長	長	萇	萇	萇	長	尝	嘗	常	嘗
7543	7748	7749	8623	9129	10300				
长	偿	償	倘	腸	嫦				

PINYIN PRONUNCIATION IS CHANG3

562	677	2105	2163	3309	3310	3322	3860	5176	5668
場	場	厂	廠	敞	斃	嘗	跄	廠	惆
7029									
昶									

PINYIN PRONUNCIATION IS CHANG4

3637	4053	5598	5606	5662	7781	9409
暢	唱	悵	悵	悵	倡	𪔐

PINYIN PRONUNCIATION IS CHAN1

904	915	2823	2824	2825	2826	2828	2830	2934	2937
𪔐	𪔐	攬	攬	攬	攬	挽	挽	摻	摻
4078	4601								
𪔐	𪔐								

PINYIN PRONUNCIATION IS CHAN2

2176	3846	3884	4169	4200	4224	4357	4358	4359	4360
𪔐	𪔐	𪔐	蟬	蟬	蟬	𪔐	𪔐	𪔐	𪔐
4723	4724	4725	4726	4928	4929	4930	4931	4932	4933
𪔐	𪔐	𪔐	𪔐	𪔐	𪔐	𪔐	𪔐	𪔐	𪔐
5178	6482	6892	7040	7041	8295	8296	8297	8298	8509
𪔐	𪔐	𪔐	𪔐	𪔐	𪔐	𪔐	𪔐	𪔐	𪔐

PINYIN PRONUNCIATION IS CHAN2

8510 8511 8512 8513 8514 8576 8577 9825 10035 10101
 饒 饒 饒 饒 饒 饒 饒 孺 纏 纏
 10102 10245 10314 10347
 纏 纏 嬋 嬋

PINYIN PRONUNCIATION IS CHAN3

949 2958 4935 4945 5083 5085 5086 5472 5473 5579
 蔵 剗 詔 詔 产 産 剗 産 剗 闡
 6683 6883 8228 8243 9705
 輾 禪 鏟 鏟 闡

PINYIN PRONUNCIATION IS CHAN4

4922 4923 5739 5758 5759 9809
 讖 讖 忤 懺 懺 羴

PINYIN PRONUNCIATION IS CHAO1

533 2899
 超 抄

PINYIN PRONUNCIATION IS CHAO2

1308 3446 3447 3636 3735 3763 4797 6067 10430
 朝 鼃 鼃 嘲 晁 晁 潮 潮 巢

PINYIN PRONUNCIATION IS CHAO3

PINYIN PRONUNCIATION IS CHA03

4417 6808

吵 炒

PINYIN PRONUNCIATION IS CHA04

8325

鈔

PINYIN PRONUNCIATION IS CHA1

1729 1736 2768 2772 2773 2890 2893 9484 9623

杈 杈 插 插 插 杈 杈 叉 叉

PINYIN PRONUNCIATION IS CHA2

1270 1453 1535 1619 1622 2549 5925 7123 8270 8274

茶 楂 查 槎 槎 搽 察 蹇 鍤 鐮

8275 8860

鍤 簣

PINYIN PRONUNCIATION IS CHA3

3834

躋

PINYIN PRONUNCIATION IS CHA4

4124 4808 6454 6460 6521 6534 6983 6984 7853 9377

蜡 詫 汊 汊 差 差 衩 衩 佗 刹

PINYIN PRONUNCIATION IS CHA4

9429

岔

PINYIN PRONUNCIATION IS CHENG1

2621

2624

3432

4113

4114

4120

4121

7244

7290

7302

撐

撐

瞠

螳

螳

螳

螳

稱

称

稱

7306

称

PINYIN PRONUNCIATION IS CHENG2

499

555

590

1383

1407

1722

1966

1975

2455

3398

城

埕

埕

枳

枳

橙

醒

醒

成

呈

4309

4813

6231

6448

6939

6948

7262

7269

8606

8632

呈

誠

澈

澄

程

程

程

程

懲

懲

9182

9489

9602

滕

承

丞

PINYIN PRONUNCIATION IS CHENG3

88

3097

3409

4311

騁

騁

逞

逞

PINYIN PRONUNCIATION IS CHENG4

7198

7243

乘

秤

PINYIN PRONUNCIATION IS CHEN1

1462 2638 2657 3635

郴 揶 揶 嗔

PINYIN PRONUNCIATION IS CHEN2

141 1283 1284 1519 1896 2112 3357 3474 4784 5407

辰 陳 陈 楨 臣 辰 晨 晨 諶 塵

5423 5734 5827 5861 6322 6323 9503 9524 9640

塵 忱 宸 宸 沈 沉 陳 陈 尘

PINYIN PRONUNCIATION IS CHEN3

2238 2293 2294

磳 磳 磳

PINYIN PRONUNCIATION IS CHEN4

527 531 536 1576 3179 6930 6953

趄 趄 趄 觀 齟 衬 襯

PINYIN PRONUNCIATION IS CHE1

1769

車

PINYIN PRONUNCIATION IS CHE3

2609

扯

PINYIN PRONUNCIATION IS CHE4

704	1774	1775	1777	1778	1802	2708	6281	7118	8617
圻	輒	輒	輒	輒	輒	輒	輒	輒	輒
8618	8642	9931							
徹	徹	𪛗							

PINYIN PRONUNCIATION IS CHIANG2

8697	8733
𪛗	𪛗

PINYIN PRONUNCIATION IS CHIANG3

10209	10211
𪛗	𪛗

PINYIN PRONUNCIATION IS CHI1

3376	3542	3600	4102	4186	4317	4441	4651	7504	8047
喫	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗
9052	9394	9932	10194	10323	10423				
𪛗	𪛗	𪛗	𪛗	𪛗	𪛗				

PINYIN PRONUNCIATION IS CHI2

124	752	753	2525	3129	3418	3899	5290	5350	6496
𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗

PINYIN PRONUNCIATION IS CHI2

7387 7400 7471 9783 9787 9808 9880
 麓 麓 麓 遲 遲 迟 弛

PINYIN PRONUNCIATION IS CHI3

390 402 792 808 1914 3166 3180 4432 6629 6927
 耻 耻 耻 耻 鼓 齒 齿 呖 粃 褓
 6974 7929 9831
 褓 侈 尺

PINYIN PRONUNCIATION IS CHI4

714 1765 1874 1877 2372 3853 4444 5121 7928 8496
 赤 翅 敕 勅 勅 跽 叱 啻 僚 飭
 8592 8601
 斥 彳

PINYIN PRONUNCIATION IS CHONG1

138 2506 5514 5681 5709 6202 7064 8653
 春 椿 充 忡 憧 冲 冲 衝

PINYIN PRONUNCIATION IS CHONG2

4105 4170 4696 7265
 虫 蟲 崇 种

PINYIN PRONUNCIATION IS CHONG3

PINYIN PRONUNCIATION IS CHONG3

5896 5897 6835 6836
寵 寵 寵 寵

PINYIN PRONUNCIATION IS CHONG4

2770 8244
撞 銃

PINYIN PRONUNCIATION IS CHOU1

2651 2838 2856 5349
抽 搗 搗 瘰

PINYIN PRONUNCIATION IS CHOU2

1932	1986	3795	3799	3801	3814	3821	3826	3827	5772
酉	酉	畴	畴	畴	畴	畴	畴	畴	惆
7286	7312	7347	7355	7363	7567	7596	7626	7815	7821
愁	稠	筹	筹	筹	俦	俦	俦	讎	讎
7949	10075	10180							
仇	紬	綢							

PINYIN PRONUNCIATION IS CHOU3

1995 3476 3477 3568 9884
醜 眇 眇 丑 丑

PINYIN PRONUNCIATION IS CHOU4

PINYIN PRONUNCIATION IS CHOU4

7978

臭

PINYIN PRONUNCIATION IS CHUA11

2580 2816

攄 攄

PINYIN PRONUNCIATION IS CHUA13

2675

揣

PINYIN PRONUNCIATION IS CHUA14

3873

踹

PINYIN PRONUNCIATION IS CHUANG1

5326 5329 5949 5962 5963 5983 7726

瘡 瘡 窓 窗 窓 窓 牕

PINYIN PRONUNCIATION IS CHUANG2

4589 4626 5142 5207

幢 牀 床 𦵏

PINYIN PRONUNCIATION IS CHUANG3

5567 9674 9696

闖 闖 闖

PINYIN PRONUNCIATION IS CHUANG4

4996 5781 6550 6551 8447

創 倉 創 并 創

PINYIN PRONUNCIATION IS CHUAN1

5942 7736 10429

穿 川 川

PINYIN PRONUNCIATION IS CHUAN2

1757 4605 7647 8717 8726 8753 8762

橡 端 傳 船 舩 船 舩

PINYIN PRONUNCIATION IS CHUAN3

4104 8846

喘 舩

PINYIN PRONUNCIATION IS CHUAN4

4066 8278

串 釧

PINYIN PRONUNCIATION IS CHUI1

4355 6792

吹 炊

PINYIN PRONUNCIATION IS CHUI2

PINYIN PRONUNCIATION IS CHUI2

1651 1664 2759 2792 7104 7446 8261 8288 9557
椎 槌 捶 搥 垂 簞 錘 鎚 陲

PINYIN PRONUNCIATION IS CHUN1

135 1389
春 椿

PINYIN PRONUNCIATION IS CHUN2

143 145 922 1360 1977 2001 2114 2116 5025 6239
唇 脣 蓴 純 醇 醅 唇 脣 鶉 瀋
6242 10188
淳 純

PINYIN PRONUNCIATION IS CHUN3

136
春 虫

PINYIN PRONUNCIATION IS CHUO1

6000 6997 8684 9913
之 彳 辵 戲

PINYIN PRONUNCIATION IS CHUO4

1834 2005 3169 4415 9636 10056
輟 醜 齟 啮 歎 綽

PINYIN PRONUNCIATION IS CHU1

3175 6977 9926
齣 初 出

PINYIN PRONUNCIATION IS CHU2

47 1263 1485 1487 1583 1584 2123 2134 3829 3841
勸 藟 櫛 櫛 櫛 櫛 廚 廚 踳 踳
3842 3880 3883 4233 5128 5162 6456 8189 8198 8916
踳 踳 踳 蛛 廚 廚 滁 鉏 鋤 刍
9302 9303 9304 9585
芻 雛 鷄 除

PINYIN PRONUNCIATION IS CHU3

1419 1461 1631 2196 2291 6917 7826
楮 楚 杵 礎 础 褚 儲

PINYIN PRONUNCIATION IS CHU4

365 1301 2709 3252 4533 4536 5521 5626 8874 8875
亍 矗 搖 處 黠 黠 畜 怵 觸 觸
8897 8898 8943 10217
觸 觸 处 絀

PINYIN PRONUNCIATION IS CI1

PINYIN PRONUNCIATION IS C11

19 435 3022 3040 3946 5248
 此 此 𠂔 𠂔 𠂔 疵

PINYIN PRONUNCIATION IS C12

1156 1362 1363 1364 2195 2257 3194 4970 6676 6677
 次 慈 鷓 鷓 磁 磁 此 詞 慈 鷓
 6678 6907 7075 7076 7082 7218 8407
 鷓 祠 瓷 瓷 資 辭 辭

PINYIN PRONUNCIATION IS C13

3187 3856
 此 趾

PINYIN PRONUNCIATION IS C14

936 2022 3509 7074 8095
 刺 刺 賜 次 伺

PINYIN PRONUNCIATION IS CONG1

106 110 399 404 406 408 805 810 824 1204
 聰 聰 聰 聰 聰 聰 聰 聰 聰 聰
 1260 3114 3118 8083 8084 9289 9290
 葱 聰 聰 𠂔 𠂔 𠂔 𠂔

PINYIN PRONUNCIATION IS CONG2

PINYIN PRONUNCIATION IS CONG2

1449	1450	3275	3276	6288	8548	8549	8660
林取	林取	叢	叢	淙	从	丛	從

PINYIN PRONUNCIATION IS COU4

1770	6005	7049
輦	湊	湊

PINYIN PRONUNCIATION IS CUAN1

2729	3889	9434
攏	躡	𡗗

PINYIN PRONUNCIATION IS CUAN4

5948	5959	7405	7406	7582	7586
窰	窰	篡	篡	𡗗	𡗗

PINYIN PRONUNCIATION IS CUI1

227	1567	2676	4711	7805	10095
璀	攘	摧	崔	催	縋

PINYIN PRONUNCIATION IS CUI4

1095	4268	5271	5712	6262	6602	6740	7169	7837	9090
萃	啐	瘁	悴	淬	粹	粹	毳	倅	腓
9154	9209	9210	9910						
醉	脆	脆	翠						

PINYIN PRONUNCIATION IS CUN1

1505 9313 9316 9978

村 邨 邨 皴

PINYIN PRONUNCIATION IS CUN2

2166

存

PINYIN PRONUNCIATION IS CUN3

5658

忖

PINYIN PRONUNCIATION IS CUN4

2494 3769 6590

寸 吋 糲

PINYIN PRONUNCIATION IS CUO1

2252 2253 2632 2634 2736 2738 3891 3892

磋 磋 撮 撮 搓 搓 蹉 蹉

PINYIN PRONUNCIATION IS CUO2

3212 3213 4698 4699 5280 5281 7156

𪗇 𪗇 𪗇 𪗇 𪗇 𪗇 𪗇

PINYIN PRONUNCIATION IS CUO4

PINYIN PRONUNCIATION IS CU04

2127 2542 2807 8144 8291 8551

厝 措 挫 錯 銕 坐

PINYIN PRONUNCIATION IS CU1

5412 5428 6595 7532 7533

鹿 鹿 鹿 鹿 粗 犄 犄

PINYIN PRONUNCIATION IS CU4

1100 1954 2150 3876 5032 7429 7790 8958 8997

簇 醋 蹙 蹴 蹙 簇 促 猎 猝

PINYIN PRONUNCIATION IS DAI1

3647 4633

呆 豨

PINYIN PRONUNCIATION IS DAI3

573 2396

戴 歹

PINYIN PRONUNCIATION IS DAI4

254 750 971 998 2057 2436 5221 6916 7693 7694

玳 埭 帶 帶 逮 殆 瘳 襪 代 貸

7695 7696 7697 8604 9748 9749 9969 9970 10219

黛 岱 袋 待 逮 迨 怠 給

PINYIN PRONUNCIATION IS DANG1

210	211	3316	3328	4012	4015	6936	6937	8184	8353
璫	珰	當	当	噹	𠵽	襠	裆	鎗	鎗

PINYIN PRONUNCIATION IS DANG3

2622	2623	2625	2627	3317	3321	4829
擋	攔	攪	挡	黨	党	讜

PINYIN PRONUNCIATION IS DANG4

1126	1530	1532	5727	5863	6186
蕩	檔	档	憚	宕	盪

PINYIN PRONUNCIATION IS DAN1

396	401	802	807	2412	2418	2629	2822	3472	4075
聃	耽	聃	耽	殫	殫	担	擔	眈	單
4077	5264	5285	6681	6682	6947	6961	7415	7443	8091
鄚	癰	痺	单	鄚	禪	禪	簞	簞	眈
9273									
丹									

PINYIN PRONUNCIATION IS DAN3

2566	5035	5254	9128	9208
譚	亶	疸	胆	膽

PINYIN PRONUNCIATION IS DAN4

3353	3586	3588	4298	4833	4906	4909	5686	6314	6391
旦	噉	噉	啖	誕	誕	誕	憚	淡	澹
7186	7769	9444	9445						
氮	但	蛋	蛋						

PINYIN PRONUNCIATION IS DAO1

3345	5771	9070
刂	怗	刀

PINYIN PRONUNCIATION IS DAO3

2503	2516	2535	2788	6653	6851	6852	6857	7735	7998
擣	擣	擣	搗	導	禱	禱	禱	倒	島
9842									
導									

PINYIN PRONUNCIATION IS DAO4

3008	3910	4568	4570	4572	5664	6390	6651	7079	7303
到	蹈	憐	憐	憐	悼	盜	道	盜	稻

PINYIN PRONUNCIATION IS DA1

2550	3633	3770	6919
搭	嗒	叮	搭

PINYIN PRONUNCIATION IS DA2

635	898	907	1271	2317	2323	2353	3595	5225	5670
達	韃	韃	荅	奪	奪	迭	達	瘩	怛
7403	7483	10011	10303						
筴	答	達	旦						

PINYIN PRONUNCIATION IS DA3

2597
打

PINYIN PRONUNCIATION IS DA4

2309
大

PINYIN PRONUNCIATION IS DENG1

6711	6807	7488	9459
灯	燈	登	登

PINYIN PRONUNCIATION IS DENG3

3708	7358
戔	等

PINYIN PRONUNCIATION IS DENG4

1723	2286	3554	3934	8320	9455	9460	9631
檣	磴	瞪	蹬	鐙	鄧	凳	邳

PINYIN PRONUNCIATION IS DE1

10446

力

PINYIN PRONUNCIATION IS DE2

6179 8610 8611 8625

得 德 德 得

PINYIN PRONUNCIATION IS DIAN1

1305 2551 2699 3205 4646 5226 5227 6066

顛 搥 掂 戙 巔 瘡 癩 滇

PINYIN PRONUNCIATION IS DIAN3

2235 3203 3207 4002 4921 4529

碘 卓 点 典 點 點

PINYIN PRONUNCIATION IS DIAN4

201 280 513 640 2071 2860 3783 5172 5342 5711

玷 靛 玷 塾 電 塾 电 店 癥 惦

6289 6476 6640 7383 7786 9258 9771

淀 澱 奠 簞 佃 甸 殿

PINYIN PRONUNCIATION IS DIAO1

2277 4438 7086 8430 8823 9120 9122 9123 9124 9922

碉 刁 凋 貂 鯛 周 雕 鵠 彫 刁

PINYIN PRONUNCIATION IS DIAO3

9791

吊

PINYIN PRONUNCIATION IS DIAO4

1183

條

1184

條

2612

掉

4099

吊

5960

寫

8292

鈔

8305

鈔

8311

鈔

9858

吊

PINYIN PRONUNCIATION IS DIE1

8572

爹

PINYIN PRONUNCIATION IS DIE2

471

堞

730

堞

2191

堞

2653

堞

2897

堞

3620

堞

3831

堞

3857

堞

3898

堞

3957

堞

4128

蝶

4145

蝶

4149

蝶

4790

蝶

6995

蝶

7150

蝶

7715

蝶

8688

蝶

8784

蝶

9635

蝶

10048

經

PINYIN PRONUNCIATION IS DIE4

503

堞

PINYIN PRONUNCIATION IS DING1

180 903 1961 2492 3391 3768 5242 6135 7687 8170
玎 荳 酏 丁 叮 疔 汀 仃 釘

PINYIN PRONUNCIATION IS DING3

2493 3431 3454
頂 鼎 鼎

PINYIN PRONUNCIATION IS DING4

1595 2248 4814 5851 8245
掟 碇 訂 定 錠

PINYIN PRONUNCIATION IS DIU1

315 7211
丟 丟

PINYIN PRONUNCIATION IS DI1

4334 6256 6516 7937 9534
啲 滴 氐 低 隄

PINYIN PRONUNCIATION IS DI2

596 1235 3969 3990 4262 4373 5118 6354 6355 7221
覲 荻 迪 迪 滴 啾 敵 滌 滌 敵
7412 8230 9008 9411 9412 9912 10331
笛 鐫 狄 采 糴 翟 嫡

PINYIN PRONUNCIATION IS D13

722	1690	2276	2843	4938	5370	7534	8883	8906	9051
抵	抵	砥	抵	詆	底	抵	觥	觥	氏

9053
邸

PINYIN PRONUNCIATION IS D14

767	877	1090	1494	1741	2154	4859	5120	6816	6818
地	蒂	蒂	狄	棣	遞	諦	帝	弟	遞

6888	7500	8029	8616	10098	10348
諦	第	的	遞	締	娣

PINYIN PRONUNCIATION IS DONG1

580	1842	3016	4370	7189	8939
鼗	東	东	咚	氡	冬

PINYIN PRONUNCIATION IS DONG3

1170	5618
董	懂

PINYIN PRONUNCIATION IS DONG4

376	1467	1516	6228	7054	7060	7333	7891	9140
动	棟	栋	洞	凍	冻	動	働	胴

PINYIN PRONUNCIATION IS DOU1

2790 3587 7460 8030
攪 走 筲 兜

PINYIN PRONUNCIATION IS DOU3

2716 4190 5595 9498
抖 蚪 斗 陡

PINYIN PRONUNCIATION IS DOU4

184	186	187	188	189	190	191	193	930	1912
鬥	鬥	鬥	鬥	鬥	鬥	鬥	鬥	苙	豆
1917	3135	3137	3138	3139	3140	3141	3142	3144	5233
逗	鬥	鬥	鬥	鬥	鬥	鬥	鬥	鬥	痘
5575	5937								
闢	竇								

PINYIN PRONUNCIATION IS DUAN1

5080
端

PINYIN PRONUNCIATION IS DUAN3

7144
短

PINYIN PRONUNCIATION IS DUAN4

6634 6780 7569 8276 10141 10234

斷 煅 段 鍛 緞 斷

PINYIN PRONUNCIATION IS DUI1

686

堆

PINYIN PRONUNCIATION IS DUI4

2262 3273 3274 6686 9553 9554 9583 9619

碓 對 懟 兑 隊 隊 队 对

PINYIN PRONUNCIATION IS DUN1

603 3895 5024 5703 6737

墩 蹲 敦 惇 燉

PINYIN PRONUNCIATION IS DUN3

1029 3546

躉 吨

PINYIN PRONUNCIATION IS DUN4

4387 4388 4389 6804 8309 8588 8589 9107 9312 9315

噸 吨 噸 炖 鈍 盾 遁 遜 頓 屯 頓

PINYIN PRONUNCIATION IS DUO1

PINYIN PRONUNCIATION IS DU01

4365 8861

哆 多

PINYIN PRONUNCIATION IS DU02

2333 2357 2898 6985 8211

夺 奪 掇 襍 鐸

PINYIN PRONUNCIATION IS DU03

8092 8093 8924 9326

躲 躲 朶 朶

PINYIN PRONUNCIATION IS DU04

713 733 1612 3882 3920 3929 4440 5644 8710 8746

垛 垛 柁 踱 蹂 蹂 咄 惰 舵 舵

8925 9329 9509 9514

剝 剝 墮 墮

PINYIN PRONUNCIATION IS DU1

694 695 3155 3598

都 都 督 嘟

PINYIN PRONUNCIATION IS DU2

224 310 311 313 314 1417 2177 2178 4026 4519

匱 毒 壽 毒 壽 櫛 碯 碯 髑 黠

PINYIN PRONUNCIATION IS DU2

4527 4776 4777 6031 7051 7522 7714 8987 8990
黷 讀 讀 瀆 瀆 犢 牘 独 獨

PINYIN PRONUNCIATION IS DU3

468 690 3364 3492 7346 7399
堵 覩 睹 賭 篤 篤

PINYIN PRONUNCIATION IS DU4

1404 1867 5140 6258 8234 9079 10289 10353
杜 蠱 度 渡 鍍 肚 妬 妒

PINYIN PRONUNCIATION IS EI1

10251

ㄣ

PINYIN PRONUNCIATION IS EI3

3761

ㄣ

PINYIN PRONUNCIATION IS EN1

4090 4343 10442 10443
恩 恩 ㄣ ㄣ

PINYIN PRONUNCIATION IS EN4

2664

摠

PINYIN PRONUNCIATION IS ER2

2305 4321 7707 9047 9311 9318
而 兒 兒 儿 儿 儿

PINYIN PRONUNCIATION IS ER3

161 166 384 788 2042 2045 2051 2341 2344 6025
耳 耳 耳 耳 爾 爾 爾 爾 爾 耳
6039 6845 6846 8449 8451 8766 8767
耳 尔 尔 餌 餌 尔 尔

PINYIN PRONUNCIATION IS ER4

2 61 146
二 貳 式

PINYIN PRONUNCIATION IS E1

768 5334 9826 10396
古 痾 厨 阿

PINYIN PRONUNCIATION IS E2

1175 4215 4315 4706 4707 4884 4914 4919 5930 7538
我 蛾 哦 峨 峨 譌 訛 譌 額 鵝
7539 7896 10361
鵞 俄 娥

PINYIN PRONUNCIATION IS E3

10305

嫫

PINYIN PRONUNCIATION IS E4

783	784	1040	1142	1789	1881	2457	2593	2746	3170
堊	惡	萼	惡	輓	噩	厄	扼	搯	齧
3220	3755	3760	4047	4048	4049	4841	5572	5685	7027
𪛗	遏	呃	顎	鶚	鄂	諤	𪛗	愕	庀
8497	8498	8787	8803	9137	9517	9713			
餓	餓	鯉	鰐	鰐	阨	闕			

PINYIN PRONUNCIATION IS FANG1

1099	1586	5439	10336
芳	枋	方	妨

PINYIN PRONUNCIATION IS FANG2

618	7017	8810	9139	9544
坊	房	魴	肪	防

PINYIN PRONUNCIATION IS FANG3

23	438	3043	3697	4863	7843	7844	8641	8707	8743
髻	髻	髻	昉	訪	仿	倣	徬	舫	舫

AD-A040 795

RCA ADVANCED TECHNOLOGY LABS CAMDEN N J
LANGUAGE MANUAL FOR USE WITH IDEOGRAPHIC COMPOSING MACHINES MOD--ETC(U)
FEB 70

F/G 9/2

DAAG17-68-C-0064

NL

UNCLASSIFIED

4 of 5
ADA040795



PINYIN PRONUNCIATION IS FANG3

10104

紡

PINYIN PRONUNCIATION IS FANG4

5459

放

PINYIN PRONUNCIATION IS FAN1

1131

4599

4600

4602

5453

8537

8540

8541

8542

8543

藩

幡

帆

帆

旂

番

翻

翻

飛

飛

10159

繙

PINYIN PRONUNCIATION IS FAN2

702

1215

1459

1713

1714

2283

3912

6709

6791

1220

藩

蕃

梵

樊

樊

矾

蹯

煩

燔

繁

7558

8764

9204

9337

繁

凡

藩

凡

PINYIN PRONUNCIATION IS FAN3

2437

2439

8685

8686

反

返

反

返

PINYIN PRONUNCIATION IS FAN4

PINYIN PRONUNCIATION IS FAN4

1136	3497	3529	6383	6389	6430	6498	7375	8459	8460
范	販	販	泛	汎	汎	汎	範	飯	飯
8506	9042								
飯	犯								

PINYIN PRONUNCIATION IS FA1

7698	9461	9933
伐	發	发

PINYIN PRONUNCIATION IS FA2

1649	4490	4491	5583	7453	8575	9723
伐	討	討	伐	筏	乏	闕

PINYIN PRONUNCIATION IS FA3

18	434	3039	6036
髮	髮	髮	法
友	友		

PINYIN PRONUNCIATION IS FA4

164	243	2186
珐	珐	砧

PINYIN PRONUNCIATION IS FEI1

2067	2068	3059	3260	3796	3997	7008	7009	9954	9955
霏	霏	非	非	啡	啡	扉	扉	飞	飛
非	非								

PINYIN PRONUNCIATION IS FEI1

9956 10054 10057 10414 10422

飛 緋 緋 妃 妃

PINYIN PRONUNCIATION IS FEI2

6410 9115 9117 9234

淝 腓 腓 肥

PINYIN PRONUNCIATION IS FEI3

385 789 984 995 1405 1427 3061 3063 3070 3072

匪 匪 菲 菲 榧 榧 斐 蜚 斐 翬

3262 3264 3266 3268 4822 4827 5663 5665 7357 7365

斐 蜚 斐 翬 誹 誹 悱 悱 篴 篴

PINYIN PRONUNCIATION IS FEI4

935 1080 3728 5247 5251 5331 5346 5374 6493 9101

蒂 蒂 吠 痲 痲 癢 癩 廢 沸 肺

9144 9875

肺 費

PINYIN PRONUNCIATION IS FENG1

5 460 859 1702 3064 3068 4231 4729 4730 5321

丰 封 葑 楓 豐 豐 蜂 峯 峰 瘋

6151 6796 7094 8300 8934 9344 9352

豐 烽 丰 鋒 逢 風 风

PINYIN PRONUNCIATION IS FENG2

7046 7061 8933 10172
馮 馮 逢 縫

PINYIN PRONUNCIATION IS FENG3

3386

噤

PINYIN PRONUNCIATION IS FENG4

132 4950 7568 9331 9353
奉 諷 俸 鳳 凤

PINYIN PRONUNCIATION IS FEN1

1277 1278 2095 4409 7187 9425 10197
芬 荼 霽 吩 氛 分 紛

PINYIN PRONUNCIATION IS FEN2

463 632 681 1456 1460 1712 6444
墳 坟 坟 焚 焚 粉 汾

PINYIN PRONUNCIATION IS FEN3

6624

粉

PINYIN PRONUNCIATION IS FEN4

PINYIN PRONUNCIATION IS FEN4

549	2340	2358	5609	6575	6597	7615	7965	9430
賁	奮	奮	憤	糞	糞	債	份	忿

PINYIN PRONUNCIATION IS FOU3

2159	7119	7125	7126
否	缶	鈺	鈺

PINYIN PRONUNCIATION IS FO2

8063
佛

PINYIN PRONUNCIATION IS FU1

159	270	346	2366	3244	3819	7588	8125	8410	8411
珙	馱	夫	馱	膚	趺	佚	鈇	鄒	鄒
9059	9063	9076							
孚	孚	肤							

PINYIN PRONUNCIATION IS FU2

35	450	850	1180	1181	1212	1238	1242	1666	1698
髻	髻	芙	茯	苻	苻	菰	菰	桴	枹
1783	2014	2512	2917	3055	3281	4111	4140	4221	4480
輻	敷	扶	拂	髻	黻	蚨	蝠	蜉	罌
5791	6246	6377	6861	6862	6967	7191	7452	7676	7914
拂	涪	浮	福	福	袱	氟	符	伏	俘

PINYIN PRONUNCIATION IS FU2

8002	8409	8412	8674	9141	9235	9247	9874	9876	9887
鳧	孚	鄆	拂	服	服	匐	弗	艱	鞞
10031	10041	10210							
縛	紱	紉							

PINYIN PRONUNCIATION IS FU3

1755	2013	2702	2760	2780	3280	3678	4575	5356	5357
輔	甫	拊	撫	拊	黼	哺	幅	府	腐
7304	7840	8567	8571	9099	9156				
簠	俯	釜	斧	脯	腑				

PINYIN PRONUNCIATION IS FU4

103	522	685	1287	1882	1944	1946	3111	3486	3494
駙	赴	坳	蔀	副	霈	覆	駙	賦	膊
3907	4214	4319	4828	5859	6868	6965	7264	7335	7060
跗	蝮	咐	訃	富	袂	複	馥	復	傅
7688	8057	8566	8654	8771	8772	8821	9198	9562	10408
付	阜	父	復	負	負	鮒	腹	附	婦
10411									
婦									

PINYIN PRONUNCIATION IS GAI1

PINYIN PRONUNCIATION IS GAI1

633 3514 4865 9546
咳 賅 該 咳

PINYIN PRONUNCIATION IS GAI3

9837 9844
改 改

PINYIN PRONUNCIATION IS GAI4

781 873 955 1742 1743 6475 6528 8138 9276 9753
丐 蓋 蓋 概 概 溉 盖 鈣 匄 槩

PINYIN PRONUNCIATION IS GANG1

4467 4610 4611 4692 7120 8216 9078 10089
罡 岡 剛 崗 缸 鋼 肛 綱

PINYIN PRONUNCIATION IS GANG3

6053 6055
港 港

PINYIN PRONUNCIATION IS GANG4

1403
杠

PINYIN PRONUNCIATION IS GAN1

147 150 787 1302 1307 1393 1426 5217 6038 7348
干 杆 甘 乾 乾 杆 柑 疳 甘 竿

PINYIN PRONUNCIATION IS GAN1

9074

肝

PINYIN PRONUNCIATION IS GAN3

507	516	526	547	1410	1412	1538	2135	2137	2552
敢	赶	趕	敢	橄	橄	桿	感	感	擰
7231	7261								
杆	桿								

PINYIN PRONUNCIATION IS GAN4

1309	1310	3360	5060	5061	5064	6249	6250	6368	10016
幹	榦	盱	贛	贛	贛	瀆	瀆	淦	紺

PINYIN PRONUNCIATION IS GAO1

1657	1658	1659	4999	5010	5015	6529	6607	7421	7963
桿	桿	桿	高	高	膏	羔	糕	篙	皋
7992	7994	8067	8484						
皋	皋	皐	皐						

PINYIN PRONUNCIATION IS GAO3

1079	1568	2683	3433	5012	7275	10096
藁	稿	搞	杲	藁	稿	縞

PINYIN PRONUNCIATION IS GAO4

PINYIN PRONUNCIATION IS GA04

4897 7200 7206 8265
誥 告 郜 鎬

PINYIN PRONUNCIATION IS GA1

9334
𠂔 𠂔

PINYIN PRONUNCIATION IS GA2

3721 3724
𠂔 𠂔

PINYIN PRONUNCIATION IS GA3

3607
𠂔

PINYIN PRONUNCIATION IS GE13

10191
𠂔

PINYIN PRONUNCIATION IS GENG1

41 42 3797 5400 5401 6086 6530 6580 7241
耕 耕 𠂔 庚 賡 𠂔 羹 粳 梗

PINYIN PRONUNCIATION IS GENG3

400 479 806 1468 3660 4019 8786 10025
耿 埂 耿 梗 哽 鯁 鯁 鯁

PINYIN PRONUNCIATION IS GENG4

1049

更

PINYIN PRONUNCIATION IS GEN1

1744 3940

根 跟

PINYIN PRONUNCIATION IS GEN2

4425

根

PINYIN PRONUNCIATION IS GEN4

2414 2994 9759

互 互 艮

PINYIN PRONUNCIATION IS GE1

1921 1922 1923 2715 2904 2956 3623 3906 4030 4803

哥 鵠 歌 摘 擱 戈 噶 跔 骷 訶

5299 5823 8369 9199 9211 10428

疙 割 鴿 肱 胳膊

PINYIN PRONUNCIATION IS GE2

896 1689 1779 1895 3669 4033 4234 5586 5589 9096

革 格 轄 鬲 噎 骼 蛤 囧 囧 膈

PINYIN PRONUNCIATION IS GE2

9504 9505 9726 9729
隔 隔 閣 閣

PINYIN PRONUNCIATION IS GE3

1034 8696 8732 9256
葛 舸 舸 哿

PINYIN PRONUNCIATION IS GE4

2275 4216 7414 7793 7802 8301 8936 9403
咯 蛇 箇 個 佢 銘 各 个

PINYIN PRONUNCIATION IS GONG1

381 682 723 748 960 4238 5095 5102 5888 7633
工 攻 功 汞 恭 蚣 龔 龔 宮 供
8094 9109 9438 9848
躬 肱 公 弓

PINYIN PRONUNCIATION IS GONG3

734 735 1437 2544
巩 鞏 拱 拱

PINYIN PRONUNCIATION IS GONG4

560 951 1414
貢 共 楨

PINYIN PRONUNCIATION IS GOU1

2857 6015 6423 8304 8308 9308 9638 10151

拘 溝 沟 鉤 鈎 勾 丨 綰

PINYIN PRONUNCIATION IS GOU3

1246 1695 4733 9027

苟 枸 岫 狗

PINYIN PRONUNCIATION IS GOU4

323 324 666 705 1395 1699 2510 3487 3533 4546

覷 溝 馱 垢 構 构 搆 購 购 购

4925 8598 8863 9265 10262 10381

詬 逅 夠 够 媾 姤

PINYIN PRONUNCIATION IS GUAI1

7197

乖

PINYIN PRONUNCIATION IS GUAI3

1557 2665

拐 拐

PINYIN PRONUNCIATION IS GUAI4

5783

怪

PINYIN PRONUNCIATION IS GUANG1

3292 8180 8872 8895 9125

光 銑 觥 觥 肱

PINYIN PRONUNCIATION IS GUANG3

5123 5131 5134 8995 8996

广 廣 廣 獷 獷

PINYIN PRONUNCIATION IS GUANG4

8952 8954

逛 逛

PINYIN PRONUNCIATION IS GUAN1

1043 1601 1610 5266 5267 5577 5889 5991 6555 6824

觀 棺 棺 療 療 関 官 官 关 冠

7852 7856 8805 8806 9621 9622 9717 9736 9737 9738

官 官 鰓 鰓 覓 覓 関 関 関 關

9739

關

PINYIN PRONUNCIATION IS GUAN3

7434 7435 7437 8115 8116 8476 8477 8478 8479 8533

筧 管 管 館 館 館 館 館 館 館

PINYIN PRONUNCIATION IS GUAN3

8534
館

PINYIN PRONUNCIATION IS GUAN4

1044	2192	2926	5794	6063	7121	7597	8146	9936
鵲	礮	攢	慣	灌	罐	盥	鑊	貫

PINYIN PRONUNCIATION IS GUA1

403	809	2767	4166	7217	7223	7449	8687	9348
聒	聒	括	蝸	刮	鵠	筈	瓜	颯

PINYIN PRONUNCIATION IS GUA3

4007	4406	5864
刮	卦	寡

PINYIN PRONUNCIATION IS GUA4

464	2522	2524	4465	6915	10004
卦	挂	掛	罍	褂	絀

PINYIN PRONUNCIATION IS GUI1

162	230	231	351	455	469	2184	3343	5541	7996
珪	瓌	瓌	規	圭	邨	砗	归	闺	飯
8028	8036	8037	8059	8774	8775	8776	8780	8834	9680
飯	龜	龜	歸	龟	龜	龜	鮭	龜	閏

PINYIN PRONUNCIATION IS GUI1

10349 10376

媽 媽

PINYIN PRONUNCIATION IS GUI3

343 1826 3743 3744 4927 5761 5986 7499 8041 9457

軌 軌 晷 晷 詭 愧 宄 簋 鬼 癸

PINYIN PRONUNCIATION IS GUI4

258 1408 1469 3918 3952 8359 8372 8790

瑰 桂 櫃 跪 貴 刽 劓 鯪

PINYIN PRONUNCIATION IS GUN3

1794 1795 3030 5189 5206 6260 6263 8826 10064 10065

輓 輓 | 袞 袞 滾 滾 鯨 鯢 鯢

PINYIN PRONUNCIATION IS GUN4

1544 1545

棍 棍

PINYIN PRONUNCIATION IS GUO1

2661 4079 4167 5029 8209

搥 國 蝨 郭 鍋

PINYIN PRONUNCIATION IS GUO2

3581 3593 4065 4585 6649 8393 8852

国 国 國 帼 酋 虢 虢

PINYIN PRONUNCIATION IS GU03

1008	1569	1570	3434	4153	5002	8462
菓	惇	櫛	果	螺	裹	餽

PINYIN PRONUNCIATION IS GU04

2495	4008
過	過

PINYIN PRONUNCIATION IS GU1

1295	1327	1331	1368	1780	1955	3634	4133	6065	7391
菰	辜	鴣	菇	軀	酤	咕	蛄	沽	箍
7490	7637	8882	8905	9610	10274				
孤	估	觚	觚	孤	姑				

PINYIN PRONUNCIATION IS GU2

1555
骨

PINYIN PRONUNCIATION IS GU3

577	578	587	654	658	659	667	1039	1299	1323
鼓	瞽	鼓	穀	穀	穀	穀	膏	古	馱
1328	1344	4016	4031	4171	4475	4796	6510	6517	7205
鹽	馱	骨	鵠	鹽	罟	詬	拏	殺	鵠

PINYIN PRONUNCIATION IS GU3

7523 8149 8570 9081 9224
牯 鈷 谷 虂 股

PINYIN PRONUNCIATION IS GU4

1330 1638 2453 2454 2458 2459 4005 5263 7023 7024
故 梏 顧 頤 頤 頤 固 痼 雇 顧
7676 8208
僱 鈷

PINYIN PRONUNCIATION IS HAI1

4286 4287
嗨 嗨

PINYIN PRONUNCIATION IS HAI2

4028 5516 9608
骸 頰 孩

PINYIN PRONUNCIATION IS HAI3

1959 6344 6346
醃 海 海

PINYIN PRONUNCIATION IS HAI4

96 3104 4276 5515 5822 7182
駭 駭 噓 亥 害 氦

PINYIN PRONUNCIATION IS HANG1

2379

夯

PINYIN PRONUNCIATION IS HANG2

1587 1675 4272 5467 8708 8744

杭 桁 吭 頔 航 航

PINYIN PRONUNCIATION IS HANG4

6272

沆

PINYIN PRONUNCIATION IS HAN1

257 508 548 1953 4119 7981

干 𦵏 𦵏 𦵏 𦵏 𦵏

PINYIN PRONUNCIATION IS HAN2

342 852 980 981 1292 1293 1313 3026 3027 4404

𦵏 𦵏 𦵏 𦵏 𦵏 𦵏 韓 函 函 𦵏

5843 6149 6150 6457 6458 7515 9414 9454 9598 9599

寒 函 函 函 函 𦵏 含 函 函 函

9601

函

PINYIN PRONUNCIATION IS HAN3

3712 6842
喊 罕

PINYIN PRONUNCIATION IS HAN4

1312	2508	2578	2579	2630	3359	5535	5645	5646	5671
翰	扞	撼	撼	捍	旱	閑	憾	憾	悍
6009	6044	6069	6459	6699	6717	8122	8191	8415	8440
汗	漢	瀚	汊	爌	焊	鉦	鉨	豸	頤
8950	8975	9675							
犴	犴	閑							

PINYIN PRONUNCIATION IS HAO1

1078	1367	1369	3625
蒿	姁	姁	噁

PINYIN PRONUNCIATION IS HAO2

602	3385	4180	4251	4327	4328	4329	5013	5016	6241
壕	昊	螯	豪	嗥	嗥	嗥	豪	毫	濠

PINYIN PRONUNCIATION IS HAO3

720	10395
郝	好

PINYIN PRONUNCIATION IS HA04

51	52	3689	3710	3788	3789	6195	6338	6364	8011
耗	耗	顥	皓	号	號	灝	浩	浩	皛
8021	8022	8023	8024	8224					
皓	皛	皛	皛	鎬					

PINYIN PRONUNCIATION IS HA1

4397
哈

PINYIN PRONUNCIATION IS HE11

4095 4524
嘿 黑

PINYIN PRONUNCIATION IS HENG1

4254 5021
哼 亨

PINYIN PRONUNCIATION IS HENG2

264	1221	1433	1436	5628	5655	5661	8665	10277
珩	衡	橫	橫	恒	恆	恆	衡	姁

PINYIN PRONUNCIATION IS HENG4

4778
諱

PINYIN PRONUNCIATION IS HEN2

5340
痕

PINYIN PRONUNCIATION IS HEN3

8673 9038
很 狠

PINYIN PRONUNCIATION IS HEN4

5738
恨

PINYIN PRONUNCIATION IS HE1

3673 4064 4802
呵 喝 訶

PINYIN PRONUNCIATION IS HE2

772	1179	1589	1945	3172	3604	3754	3756	5519	5546
盍	荷	核	覈	齧	嗑	曷	鵠	劓	闔
5574	6096	6211	6943	7230	7258	7654	8363	8429	9380
𠵿	河	涸	褐	禾	和	何	龢	貉	合
9384	9685	9715	10140						
盒	盍	闕	紇						

PINYIN PRONUNCIATION IS HE4

716 3218 3601 5920 6837 9260
 赫 壑 嚇 鶴 鶴 賀

PINYIN PRONUNCIATION IS HONG1

1055 1761 1833 3003 4304 6700 9274
 薨 轟 𨔵 𨔶 𨔷 烘 訶

PINYIN PRONUNCIATION IS HONG2

4112 4771 5055 5554 5871 6033 6050 6494 7590 7591
 虹 訢 竝 宏 宏 鴻 洪 泓 鬢 鬢
 9694 9882 10003 10042
 閎 弘 紅 紘

PINYIN PRONUNCIATION IS HONG3

3619

哄

PINYIN PRONUNCIATION IS HONG4

185 3136 5548 9687
 𨔵 𨔶 𨔷 𨔸

PINYIN PRONUNCIATION IS HOU1

7986 7987
 𨔵 𨔶

PINYIN PRONUNCIATION IS HOU2

4336 5305 6617 7461 8050 8503 8768 9014
 喉 癰 糗 篸 候 餵 彐 猴

PINYIN PRONUNCIATION IS HOU3

4412 9037
 吼 吼

PINYIN PRONUNCIATION IS HOU4

699 2217 7796 8597 8678
 垢 厚 候 后 後

PINYIN PRONUNCIATION IS HUI2

1663 3863 5648 5649 5705 5706 6356
 槐 踝 怀 恠 懷 懷 淮

PINYIN PRONUNCIATION IS HUI4

492 604 605
 坏 壞 壞

PINYIN PRONUNCIATION IS HUANG1

1105 5504 5617
 荒 育 慌

PINYIN PRONUNCIATION IS HUANG2

PINYIN PRONUNCIATION IS HUANG2

168	170	849	928	2189	2190	4123	4125	4219	5218
璜	璜	黃	黃	磺	磺	蟻	蟻	蝗	瘡
5220	5751	6043	6046	6361	6783	7368	7369	7458	7906
瘡	惶	潢	潢	湟	煌	簧	簧	篁	徨
7973	7974	8655	9342	9564					
皇	惶	徨	凰	隍					

PINYIN PRONUNCIATION IS HUANG3

3642	4582	4794	5666	5675	5690	6723
晃	幌	謊	恍	愧	悅	煨

PINYIN PRONUNCIATION IS HUANG4

2642

晃

PINYIN PRONUNCIATION IS HUANI

74	1045	3085	4793	5614	8418	8960	9629
驩	歡	驩	謹	懽	獾	獾	歡

PINYIN PRONUNCIATION IS HUAN2

21	176	223	436	1466	2162	3041	4479	4512	5566
鬟	环	環	鬟	桓	还	鬟	還	園	園
5891	8212	9708	10087	10321					
寰	環	闌	纒	嬛					

PINYIN PRONUNCIATION IS HUAN3

6068 6287 10154

澣 浣 緩

PINYIN PRONUNCIATION IS HUAN4

2331 2832 4072 4362 4363 5311 5860 5890 5992 6214

換 換 患 喚 喚 換 宦 迨 迨 湊

6395 6556 6793 8843 10231

渙 泰 煥 奐 幻

PINYIN PRONUNCIATION IS HUA1

1207 1279 3612 4604

花 花 嘩 幘

PINYIN PRONUNCIATION IS HUA2

73 846 1432 2960 3084 4786 6213 8105 8143 8984
馬 華 桦 划 驊 譁 滑 华 鐸 猾

PINYIN PRONUNCIATION IS HUA4

1859 1860 4399 4937 8104 9661 9662 9663

画 画 話 詬 化 畫 劃 畫

PINYIN PRONUNCIATION IS HUI1

2376 2377 2751 2752 2803 3290 3293 3702 4722 4811

灰 灰 搗 揮 搗 輝 輝 暉 徽 誼

PINYIN PRONUNCIATION IS HUI1

5154	5654	6774	8638	9511	9911
麾	恢	輝	徽	隳	翬

PINYIN PRONUNCIATION IS HUI2

1052	1091	1068	4173	4174	4177	4461	4463	4464	4507
茴	茴	茴	蛔	蛔	蛔	回	迴	迴	回
4509	4510	4618	4619	4620	5693	5696	5699	6222	6225
迴	迴	回	迴	迴	恹	恹	恹	洵	洵
6229	6627	8628	8630						
洵	徊	徊	徊						

PINYIN PRONUNCIATION IS HUI3

2467	4907	5745	5747	6781	7701	8563
虺	毀	悔	悔	燬	毀	虺

PINYIN PRONUNCIATION IS HUI4

6	7	511	544	923	1269	1272	1847	2046	2301
慧	慧	卉	卉	蕙	荟	薈	惠	匯	賁
2410	3496	3714	3715	4138	4448	4902	4903	4969	5561
賁	賁	晦	晦	噍	噍	誨	誨	諱	賁
6118	6143	6805	6806	7253	7272	7273	9372	9390	9649
匯	匯	烜	燿	穢	穢	秒	會	會	類

PINYIN PRONUNCIATION IS HUI4

9702 9991 10077 10190 10192 10250

𨵿 彙 績 繪 繪 绘

PINYIN PRONUNCIATION IS HUN1

246 1146 3543 5590 5770 9049 9730 10386

琿 葦 昏 齋 昏 昏 閤 婚

PINYIN PRONUNCIATION IS HUN2

375 6318 8464 8465 8488

魂 渾 餽 餽 餽

PINYIN PRONUNCIATION IS HUN3

6189 6190

混 混

PINYIN PRONUNCIATION IS HUN4

4374 4885 6218

𨵿 譚 涿

PINYIN PRONUNCIATION IS HUO1

1188 5824

割 豁

PINYIN PRONUNCIATION IS HUO2

6340

活

PINYIN PRONUNCIATION IS HUO3

3438 5803 6691 7868
夥 伙 火 伙

PINYIN PRONUNCIATION IS HUO4

941 1233 1236 1848 1851 1852 2090 2575 3630 4132
藿 获 获 惑 或 惑 霍 擢 噉 蝮
3236 6881 6882 7142 7236 8107 8148 8961 9102
癯 禍 禍 獲 穫 貨 鑊 獲 臙

PINYIN PRONUNCIATION IS HUI

3224 3231 3988 4347 4385 5774 6170 8547 9288
庑 虐 嘍 呼 惚 惚 滹 乎 忽

PINYIN PRONUNCIATION IS HU2

14 172 431 660 661 668 669 880 1229 1230
鬍 瑚 鬍 鬍 鬍 壺 壺 葫 斛 斛
1333 1334 1684 1686 1956 3036 4134 4366 4367 4548
胡 胡 櫛 櫛 酤 鬍 蚰 蚰 蚰 囫
6072 6577 6701 8455 8609 8876 8899 8962 9019 9877
湖 糊 煑 餬 餬 斛 斛 猢 狐 弧

PINYIN PRONUNCIATION IS HU3

PINYIN PRONUNCIATION IS HU3

205	3234	3255	3989	4826	6234
琥	虎	虎	唬	詭	許

PINYIN PRONUNCIATION IS HU4

1048	1076	1160	1165	1208	2314	2755	3015	4645	4795
護	護	獲	獲	鑊	瓠	护	互	岫	護
5619	6326	6328	6329	6860	7004	7012	7018	7481	
怙	沪	滬	滄	枯	户	扈	庠	笏	

PINYIN PRONUNCIATION IS JIANG1

900	925	1913	1918	2402	3337	3338	4630	4634	4635
疆	薑	缸	降	殭	将	浆	將	漿	將
4639	6024	6545	7650	9852	10026				
將	江	姜	僵	疆	疆				

PINYIN PRONUNCIATION IS JIANG3

43	1070	1071	3334	3336	4631	4633	4636	4638	4764
耑	蔣	蔣	浆	奖	漿	獎	漿	獎	誼
4765	7033								
講	讲								

PINYIN PRONUNCIATION IS JIANG4

2384	3335	4632	4637	6600	6631	6632	7932	9576	9578
匠	醬	醬	醬	鏡	糶	糶	倭	降	降

PINYIN PRONUNCIATION IS JIANG4

10174

絳

PINYIN PRONUNCIATION IS JIAN1

895	1116	1121	1488	1901	1906	2420	2424	2425	2466
艱	菅	菅	械	監	堅	歼	殲	殲	艦
2469	2957	3283	3285	5557	6310	6661	6664	6666	6667
兀	戔	監	堅	间	湔	煎	鵝	兼	兼
7025	7396	8562	8564	8788	9637	9641	9698	10034	10130
肩	箋	鑑	謙	鯁	艱	尖	間	緘	縑
10257	10427								
奸	姦								

PINYIN PRONUNCIATION IS JIAN3

491	1047	1064	1065	1141	1543	1705	1948	2207	2284
城	蚩	繭	繭	戩	覘	檢	東	碱	硷
2567	2606	2871	3014	3214	3215	3816	3818	4876	4877
揀	拣	撿	戩	鹵	鹵	趺	趺	謫	謫
5040	5841	6116	6662	6663	7056	7410	7432	7494	7718
蹇	蹇	減	剪	翦	減	筧	筧	簡	戕
7954	8329	8355							
儉	鋤	鉤							

PINYIN PRONUNCIATION IS JIAN4

946	1098	1473	1903	3284	3501	3547	3851	4551	4805
荐	薦	檻	鑒	鑑	賤	見	踐	見	諫
6085	6119	6183	6285	6472	7170	7442	7540	7589	7729
漸	洊	濺	洵	澗	趵	箭	捷	僭	僭
7878	7976	8156	8326	8364	8367	8368	8461	8695	8701
件	健	鑑	鍵	劍	劒	劒	餞	艦	靦
8704	8731	8737	8740	9232	9657				
靦	艦	靦	靦	腭	建				

PINYIN PRONUNCIATION IS JIAO1

102	1096	1186	1521	1836	2263	3110	3885	4182	4323
驕	茭	蕉	椒	轆	礁	驕	趵	蛟	礁
4558	5198	5201	6027	6782	7816	7818	7903	8809	9155
驕	交	郊	澆	焦	焦	焦	焦	焦	焦
9236	9560	10334	10359	10360					
膠	鞣	姣	嬌	娇					

PINYIN PRONUNCIATION IS JIAO2

4345
嚼

PINYIN PRONUNCIATION IS JIA03

2774	2775	2779	7153	7154	7612	7838	7907	8012	8025
橋	桥	攪	矯	矫	僥	佼	儼	皎	皦
8236	8285	8475	8656	8869	8892	8998	9084	9205	10103
鉸	鉸	餃	徼	角	角	狡	脚	腳	絞
10149	10431	10432	10433						
繳	剿	剿	勦						

PINYIN PRONUNCIATION IS JIA04

712	1799	1810	1952	1994	3002	3813	4275	4439	5958
教	較	轎	酵	醪	轿	叫	叫	叫	窖
9397									
教									

PINYIN PRONUNCIATION IS JIA1

284	570	586	1021	1322	1694	2050	2374	2375	3924
珈	嘉	嘉	葭	葭	枷	夹	郊	夾	跣
5318	5870	7478	7611	7849	7942	9251	9261	9262	
痂	家	笳	佳	傢	伽	加	袈	迦	

PINYIN PRONUNCIATION IS JIA2

959	2172	2203	2373	4143	6127	6929	6979	8168
莢	戛	戛	頰	蛺	浹	袂	袷	銖

PINYIN PRONUNCIATION IS JIA3

1942	3577	4087	4683	5258	5341	7775	8039	8199	8702
賈	甲	罈	岬	痂	痂	假	假	鉀	舛
8738	9130								
舛	舛								

PINYIN PRONUNCIATION IS JIA4

1599	7279	7659	9254	9255	9259	10339
稼	稼	價	駕	架	駕	嫁

PINYIN PRONUNCIATION IS JIE1

501	502	2647	2691	2952	2993	3773	3782	5273	5296
揩	揩	揭	接	皆	皆	揩	揩	痂	癰
5348	7249	7252	8603	9521	9523	9591			
疔	楷	楷	街	階	階	階			

PINYIN PRONUNCIATION IS JIE2

687	771	774	775	776	777	1348	1413	1592	1641
截	刮	刮	劫	劫	劫	节	桔	杰	櫛
2233	2526	2528	2601	2616	3389	3396	3421	4760	4775
碣	拈	擷	捷	捷	映	睫	睫	訐	詰
5071	6002	6028	6512	7397	7401	7497	7498	7784	7925
竭	潔	洁	謁	筴	筴	節	節	偈	傑

PINYIN PRONUNCIATION IS JIE2

7926 8847 9606 9899 9921 10008 10294 10299
傑 桀 孑 卞 巳 結 婕 婕

PINYIN PRONUNCIATION IS JIE3

8877 8885 8888 8900 8908 8911 10302
解 解 解 解 解 解 姐

PINYIN PRONUNCIATION IS JIE4

334 795 1276 2472 3980 4237 4766 5327 7629 7964
戒 藉 芥 尬 界 蚧 誠 疥 借 价
6565 9423 9764 9770 9790
尬 介 屈 屈 届

PINYIN PRONUNCIATION IS JING1

845 847 1250 1252 3355 3659 5030 5449 5704 6148
菁 荊 驚 驚 晴 晶 京 旌 惊 涇
6572 6573 8807 10053
精 精 鯨 經

PINYIN PRONUNCIATION IS JING3

221 321 1253 3018 3687 5678 5931 7636 9493
璟 井 警 剋 景 憬 甯 儆 阱

PINYIN PRONUNCIATION IS JING4

PINYIN PRONUNCIATION IS JING4

279	281	609	979	1249	1337	3017	3019	3020	3854
靚	靜	境	莖	敬	競	頸	逕	勁	踉
5041	5042	5072	5077	5078	5245	6378	7050	7071	8227
靖	靖	竟	竟	競	瘥	淨	清	淨	鏡
6619	8994	9112							
徑	獍	脛							

PINYIN PRONUNCIATION IS JIN1

4565	6407	6920	6981	7477	8118	8586	8884	8907	9413
巾	津	襟	衿	筋	金	斤	觔	觔	今
9482	10195								
矜	矜								

PINYIN PRONUNCIATION IS JIN3

189	887	888	1435	1904	1911	2128	3286	4787	5133
瑾	堇	覲	槿	緊	緊	厖	紧	謹	厖
7630	7969	8005	8056	8284	9604				
僅	仅	儘	佟	錦	叁				

PINYIN PRONUNCIATION IS JIN4

330	914	1140	1316	1447	2399	2548	2605	3013	3536
迸	靳	晉	蓋	禁	殓	搢	搢	晉	贐

PINYIN PRONUNCIATION IS JIN4

3648	5899	6474	6809	6812	7053	7819	8452	8593	9666
噤	寢	浸	燼	炆	灤	進	饅	近	賁
9667	9834	10020	10051	10391					
盡	尽	縉	縉	矜					

PINYIN PRONUNCIATION IS JIONG1

599	4562
垌	冂

PINYIN PRONUNCIATION IS JIONG3

4605	5980	6733	6734	7016	8098	10088
迴	窘	炯	炯	局	迥	絢

PINYIN PRONUNCIATION IS JIU1

195	196	197	198	199	200	540	2769	3146	3147
𪚩	𪚩	𪚩	𪚩	𪚩	𪚩	𪚩	𪚩	𪚩	𪚩
3148	3149	3150	3151	4313	5977	6341	7287	9343	9923
𪚩	𪚩	𪚩	𪚩	𪚩	𪚩	𪚩	𪚩	𪚩	𪚩
10055	10216	10218							
糾	糾	糾							

PINYIN PRONUNCIATION IS JIU3

272	985	996	3060	3261	6103	8930	8941	9325
玖	韭	韭	韭	韭	酒	久	灸	九

PINYIN PRONUNCIATION IS JIU4

1187	1500	1650	2449	2499	3287	5031	5033	5313	5404
舊	柩	柏	厖	救	旧	就	驚	疚	廐
7700	7704	7830	8944	8946					
臼	舅	僦	咎	咎					

PINYIN PRONUNCIATION IS JI1

215	317	344	813	819	1087	1088	1701	1759	1837
勳	璣	击	基	碁	薤	薤	机	機	擊
1005	2296	2327	2328	2362	3208	3590	3610	3805	3817
賈	磯	敲	剝	賈	乚	咭	噍	畸	蹟
3078	3887	4424	4455	4472	4473	4474	4989	5112	5113
躋	躋	唧	噤	羈	羈	羈	譏	齋	齋
5114	5292	6363	7232	7246	7247	7270	7349	7352	7366
齋	癩	激	積	嵇	稽	积	筭	筭	箕
7526	8436	8437	8521	8522	8531	8578	8871	8894	9223
犄	雞	鷄	飢	飢	饑	饥	觭	觭	肌
9324	9626	9627	9628	9820	9998	10232	10275		
几	鷄	鸡	鸡	屐	績	畿	姬		

PINYIN PRONUNCIATION IS JI2

552	710	1097	1231	1518	1547	1548	1549	1550	1687
吉	圾	蒺	芟	極	楫	檝	楫	檝	极

PINYIN PRONUNCIATION IS JI2

1733	2020	2405	2434	3025	4241	4728	5277	5288	5289
極	棘	殛	殛	亟	唧	岌	瘠	瘠	疾
5804	5877	6403	7072	7344	7345	7474	7616	7812	7930
鵲	寂	汲	鵲	籍	籍	笈	佶	集	伋
8915	8917	9597	9755	9756	10170				
及	急	亟	即	即	級				

PINYIN PRONUNCIATION IS JI3

1306	2692	2707	3200	4246	5160	5420	5436	5805	7073
戟	擠	挤	戟	蟻	庋	麕	麕	脊	脊
9838	10233								
己	幾								

PINYIN PRONUNCIATION IS JI4

12	84	429	884	1089	1102	1223	1796	1797	1933
髻	鬣	髻	艾	薺	薺	薺	輯	輯	羈
1934	1935	2077	2080	2555	3034	3093	3158	3583	3609
羈	羈	霽	霽	技	髻	驥	翼	戢	戢
3086	3944	4655	4770	4967	5110	5294	5387	5482	5485
跡	跽	覬	計	記	劑	瘳	迹	剂	剂
5627	5742	5867	6255	6275	6276	6360	7266	7323	7643
忒	悸	寄	濟	濟	濟	洎	稷	季	伎

PINYIN PRONUNCIATION IS JI4

8832	8859	9496	9573	9655	9751	9752	9754	9843	9984
鯽	祭	际	際	𠂇	既	既	暨	忌	𠂇
10127	10208	10224	10246	10276	10335	10415			
繼	紀	繼	继	妓	嫉	媿			

PINYIN PRONUNCIATION IS JUAN1

2666	4379	6219	6657	8222	8280	8281	10317
捐	鵠	涓	蠲	鐫	鐫	鐫	娟

PINYIN PRONUNCIATION IS JUAN3

1623	2740	8250	8487
捲	捲	鏇	餽

PINYIN PRONUNCIATION IS JUAN4

3464	4488	5689	6557	6566	7864	8988	8989	10085
睽	胃	惛	眷	卷	倦	狷	獮	絹

PINYIN PRONUNCIATION IS JUE1

3733	4290	4291
噉	嗟	嗟

PINYIN PRONUNCIATION IS JUE2

151	307	956	1496	1687	1685	2354	2355	2356	2588
玕	玦	蕨	榷	桷	桷	剮	厥	槩	擻

PINYIN PRONUNCIATION IS JUE2

2635	2909	2912	3444	3849	3864	3984	4741	4963	4965
攫	抉	掘	矍	蹶	蹶	噉	崛	譎	訣
5284	5782	5816	5818	6481	6789	7090	7592	8003	8054
癩	慄	覺	覺	決	燬	決	覺	馱	倔
8167	8195	8334	8395	8396	8891	8914	8968	8977	9605
鋤	鏤	缺	爵	爵	觖	觖	獷	獲	子
9814	10171								
鳩	絕								

PINYIN PRONUNCIATION IS JUN1

725	4540	5409	5425	6826	6829	8306	9743
均	困	麇	麇	軍	鞞	鈞	君

PINYIN PRONUNCIATION IS JUN3

932	1062
葦	菌

PINYIN PRONUNCIATION IS JUN4

128	3133	3994	4747	5108	6164	6501	7806	7807	7814
駿	駿	駿	峻	竣	濬	浚	僞	僞	僞
7823	7902	7904	8112	8530	9746				
隼	僞	僞	俊	餽	郡				

PINYIN PRONUNCIATION IS JU1

109	525	919	1000	2229	2442	2848	3117	3479	5253
駒	趯	鞠	苴	硃	𦵏	拘	駒	睢	疽
6990	7770	8974	9775						
裾	俱	狙	居						

PINYIN PRONUNCIATION IS JU2

918	1258	1728	2849	2850	3943	4944	8053	9279	9828
鞠	菊	橘	掬	掬	跼	詢	侷	菊	局

PINYIN PRONUNCIATION IS JU3

1049	1465	1511	3168	3908	4037	5808	6177	7143	7145
茗	柜	柜	齒	踣	咀	举	沮	矩	矩
7571	7572	7574	7603	7605					
舉	舉	舉	舉	舉					

PINYIN PRONUNCIATION IS JU4

411	414	415	418	554	833	836	837	840	885
聚	聚	聚	聚	埧	聚	聚	聚	聚	苴
975	1767	1964	2556	2602	2613	2907	2973	3228	3229
苴	巨	釁	拒	拒	據	据	巨	劇	遽
3383	3836	3852	3942	4799	4817	5672	5673	5884	5900
具	距	距	踞	詎	詎	惧	懼	宴	宴

PINYIN PRONUNCIATION IS JU4

5946	5954	6578	6592	6702	6713	7239	7250	8051	8153
窠	窠	𪔐	𪔐	炬	炬	𪔐	𪔐	倨	鉅
8174	8178	8333	9252	9346	9776	9822			
鉅	鏐	鋸	句	颶	剧	屨			

PINYIN PRONUNCIATION IS KAI1

322	2599	2604	5537	9677
开	揩	揩	開	開

PINYIN PRONUNCIATION IS KAI3

1508	1514	4654	4656	5568	5700	8172	8176	8221	9709
楷	楷	剗	凱	圜	愷	鎋	鎋	鎋	闔

PINYIN PRONUNCIATION IS KAI4

4423	5738	5786	5787
慨	慨	慨	慨

PINYIN PRONUNCIATION IS KANG1

5403	5714	5715	6603	7277
康	慷	忼	糠	糠

PINYIN PRONUNCIATION IS KANG2

2517	2527
扛	擯

PINYIN PRONUNCIATION IS KANG3

4027

骯

PINYIN PRONUNCIATION IS KANG4

2704 5466 6741 7845

抗 亢 炕 伉

PINYIN PRONUNCIATION IS KAN1

163 333 470 828 7509 9385 9386

𠂔 刊 堪 勘 刊 龕 龕

PINYIN PRONUNCIATION IS KAN3

708 2270 2821 5542 5543 7798 9681 9682 9924

坎 砍 坎 𡩇 𡩇 侃 闕 闕 𠂔

PINYIN PRONUNCIATION IS KAN4

3362 3363 3460 3461 3560 3561 7139

瞰 瞰 𡩇 𡩇 𡩇 𡩇 看

PINYIN PRONUNCIATION IS KAO1

9024

尻

PINYIN PRONUNCIATION IS KAO3

PINYIN PRONUNCIATION IS KAO3

603 707 739 1418 1422 2531 2532 2534 3029 6695

考 考 考 拷 拷 拷 拷 拷 攷 烤
6093
烤

PINYIN PRONUNCIATION IS KAO4

7201 7202 7527 8135 8136

靠 靠 搞 銚 銚

PINYIN PRONUNCIATION IS KAI

4382

咖

PINYIN PRONUNCIATION IS KENG1

631 2199 2222 8157 9545

坑 硯 硯 鋸 阮

PINYIN PRONUNCIATION IS KEN3

3177 3182 3923 8432 8433 9760 9761

齧 肯 啃 墾 懇 垦 恳

PINYIN PRONUNCIATION IS KEN4

6933 6989

禡 根

PINYIN PRONUNCIATION IS KE1

175	931	1476	1539	1784	2187	2536	3021	3369	3436
珂	苛	柯	棵	軻	磕	搯	𠂔	瞌	顆
4023	4213	5234	5945	7263	7278				
髁	蝌	痾	窠	棵	科				

PINYIN PRONUNCIATION IS KE2

663	664	672	4274	5518
壳	殼	壳	咳	欬

PINYIN PRONUNCIATION IS KE3

1920	6196
可	渴

PINYIN PRONUNCIATION IS KE4

87	482	1335	1336	1338	1339	1340	1341	1342	1343
馬	𡵓	克	尅	𡵓	𡵓	尅	剋	尅	尅
1424	3096	4285	4832	5517	5769	5929	6037	7174	8194
榼	𡵓	喀	課	刻	恪	客	溘	氙	鏹
10017									
緯									

PINYIN PRONUNCIATION IS KONG1

PINYIN PRONUNCIATION IS KONG1

4697 5723 5933 7436 7855

崆 控 空 筌 倥

PINYIN PRONUNCIATION IS KONG3

589 738 9615

恐 恐 孔

PINYIN PRONUNCIATION IS KONG4

2727

控

PINYIN PRONUNCIATION IS KOU1

2561 2596 3378 3390

搆 拒 瞞 眈

PINYIN PRONUNCIATION IS KOU3

3347

口

PINYIN PRONUNCIATION IS KOU4

1110 1111 1112 2628 4435 5846 5847 5848 7943 8187

蔻 蔻 蔻 扣 叩 寇 寇 寇 佻 鉤

10060

紉

PINYIN PRONUNCIATION IS KUA13

1241 2267 2570
 剗 碓 攤

PINYIN PRONUNCIATION IS KUA14

550	698	754	1704	1707	4396	4399	5789	6434	6437
卦	塊	块	桧	檜	吟	噲	快	浍	澮
7433	7953	7956	8360	8373	8827	8828	9032	9225	9227
筷	佺	儺	郚	鄒	鯀	鱣	獮	脍	膾

PINYIN PRONUNCIATION IS KUANG1

9 10 1529 4758 7343
 匡 勐 枕 誑 筐

PINYIN PRONUNCIATION IS KUANG2

4936 8951
 誑 狂

PINYIN PRONUNCIATION IS KUANG4

612	613	1384	2243	2244	2245	3259	3354	3511	3695
壙	壙	框	矿	礦	礦	卅	眶	覓	曠
3696	5132	5135	6220	7065	8232	8233	10058	10099	10100
曠	廩	廩	況	況	鑛	鑛	統	續	續

PINYIN PRONUNCIATION IS KUAN1

5054

寬

PINYIN PRONUNCIATION IS KUAN3

423 9942

款 欸

PINYIN PRONUNCIATION IS KUA1

2312 4809

夸 誇

PINYIN PRONUNCIATION IS KUA3

3726 7672

夸 誇

PINYIN PRONUNCIATION IS KUA4

495 3847 4021 9105

垮 跨 胯 跨

PINYIN PRONUNCIATION IS KUI1

377 2378 3250 4714 5538 5932 7909 9678

亏 盍 虧 歸 規 窺 傀 闕

PINYIN PRONUNCIATION IS KUI2

PINYIN PRONUNCIATION IS KUI2

726	948	1281	2319	3553	3767	6650	8048	9341
逵	蘊	葵	奎	睽	睽	夔	魁	馗

PINYIN PRONUNCIATION IS KUI3

2684	3823
揆	跬

PINYIN PRONUNCIATION IS KUI4

393	799	1856	3448	4069	5682	5752	6205	7376	7413
聵	聵	匱	聵	喟	憤	愧	潰	簞	簞
8468	8502	10369							
饋	餽	媿							

PINYIN PRONUNCIATION IS KUN1

34	217	219	449	563	655	3054	3558	3559	3571
髡	琨	琨	髡	坤	壺	髡	昆	鷗	昆
3572	4679	4680	4681	4682	5440	6721	6722	6962	6963
鷗	崑	崑	崑	崑	堦	焜	焜	禪	禪
8797	8799								
鯤	鯤								

PINYIN PRONUNCIATION IS KUN3

2659	5562	5684	9703	10082
捆	阌	困	閫	綑

PINYIN PRONUNCIATION IS KUN4

3449 4036

困 困

PINYIN PRONUNCIATION IS KUO4

2695 2696 2697 5184 5576 6286 6473 9716

扩 擴 擴 廓 阔 濶 濶 闊

PINYIN PRONUNCIATION IS KU1

757 1441 2261 2313 2585 4018 4062 5981

堀 枯 矻 剝 垮 骷 哭 窟

PINYIN PRONUNCIATION IS KU3

879 1434

苦 枯

PINYIN PRONUNCIATION IS KU4

1991 5161 6928 6956 7593 10038

酷 庫 垮 褲 嚮 誇

PINYIN PRONUNCIATION IS LAI2

958 2049 2363 6126

萊 来 來 涑

PINYIN PRONUNCIATION IS LAI4

PINYIN PRONUNCIATION IS LAI4

1870	1876	1878	2364	3388	5231	5232	6092	6093	7378
賴	賴	賴	賚	睞	癩	癩	瀨	瀨	籟
7379	7678	8615							
籟	徠	徠							

PINYIN PRONUNCIATION IS LANG1

4300

郎

PINYIN PRONUNCIATION IS LANG2

249	250	1150	1630	4204	4205	5202	5203	7001	7002
郎	琅	菱	榔	螂	螂	廊	廊	郎	郎
8257	8258	9010	10351						
鄧	銀	狼	娘						

PINYIN PRONUNCIATION IS LANG3

5581	6999	7000	9721
閻	朗	朗	閻

PINYIN PRONUNCIATION IS LANG4

6325

浪

PINYIN PRONUNCIATION IS LAN2

PINYIN PRONUNCIATION IS LAN2

929	1107	1320	1463	1590	1617	1739	2714	2735	2903
藍	蘭	蘭	婪	欄	栏	欄	攔	拦	攔
4735	4964	5479	5487	5552	6284	6471	6507	6923	6958
嵐	譚	嫻	嫻	蘭	瀾	瀾	兰	檻	襴
6906	7038	7380	9692						
襴	譚	籃	闌						

PINYIN PRONUNCIATION IS LAN3

1474	1902	2562	5632	5633	10028	10280	10281
攪	覽	攪	懶	懶	纜	嬾	嬾

PINYIN PRONUNCIATION IS LAN4

6095	6743	6748	6810
濫	爛	爛	爛

PINYIN PRONUNCIATION IS LAO1

2750
撈

PINYIN PRONUNCIATION IS LAO2

1148	2007	4299	5224	5287	5914	6767
勞	醪	勞	癆	癆	牢	勞

PINYIN PRONUNCIATION IS LAO3

PINYIN PRONUNCIATION IS LA03

729 1421 7625

老 栲 佬

PINYIN PRONUNCIATION IS LA04

1999 6124 6316 6797 10420

酪 潦 滂 烙 嫪

PINYIN PRONUNCIATION IS LA1

607 2686 3771

垃 拉 啦

PINYIN PRONUNCIATION IS LA2

1871 2500 3764

刺 掬 晃

PINYIN PRONUNCIATION IS LA3

3664

喇

PINYIN PRONUNCIATION IS LA4

16	433	2942	2943	3038	4247	4248	5044	5230	8343
鬚	鬚	搯	搯	鬚	蠟	蠟	辣	痢	蠟
8344	9085	9240	9241	10436	10437				
蠟	腊	臘	臘	蠟	蠟				

PINYIN PRONUNCIATION IS LEI2

940	1036	1037	2072	2574	5501	8161	10081	10312
蕾	蕾	藜	雷	擂	羸	鐳	縲	嫫

PINYIN PRONUNCIATION IS LEI3

2209	3955	3956	3958	3959	3995	4759	4895	6207	7114
石	田	壘	壘	累	累	誅	誅	潔	耒
7768	9981								
佃	垚								

PINYIN PRONUNCIATION IS LEI4

1996	1998	2234	2652	6178	6327	6586	6588	9213
酹	酹	礪	搥	泪	淚	类	類	肋

PINYIN PRONUNCIATION IS LENG2

1162	1420	4643	7235
稜	稜	陵	稜

PINYIN PRONUNCIATION IS LENG3

7087
冷

PINYIN PRONUNCIATION IS LENG4

1558	3368	5608	5695
楞	陵	怔	愣

PINYIN PRONUNCIATION IS LE1

3616 10445

嘞 力

PINYIN PRONUNCIATION IS LE4

916 6455 7939

勒 渤 仂

PINYIN PRONUNCIATION IS LIANG2

1615 1616 3439 3897 6243 6413 6415 6416 6417 6596

樑 樑 量 踉 涼 梁 梁 梁 梁 糧

6610 7003 7066 7291

粮 良 凉 粮

PINYIN PRONUNCIATION IS LIANG3

2024 2026 2037 3679 7661 7664 8043

兩 兩 兩 兩 倆 倆 鬼兩

PINYIN PRONUNCIATION IS LIANG4

1786 1787 3001 3688 4252 4853 5018 5019

輓 輓 輛 晾 亮 諒 亮 亮

PINYIN PRONUNCIATION IS LIAN2

398 420 421 422 804 842 843 844 892 1807

联 聯 聯 聯 联 聯 聯 聯 蓮 蓮

PINYIN PRONUNCIATION IS LIAN2

2524	2332	2481	4591	4592	5090	5194	5195	5725	5780
𡗗	𡗗	𡗗	𡗗	𡗗	𡗗	𡗗	𡗗	𡗗	𡗗
5950	6083	6252	6261	6922	7423	7426	8229	8235	8252
帘	漣	濂	濂	漣	簾	簾	鑣	鑣	鑣
8253	8785	9146	9153						
鑣	鯉	𡗗	𡗗						

PINYIN PRONUNCIATION IS LIAN3

9226

臉

PINYIN PRONUNCIATION IS LIAN4

1478	2430	4980	5388	6372	6705	6714	6980	8154	8159
棟	殮	戀	恋	澣	煉	煉	殮	鍾	鍊
8365	8366	10030	10052	10242					
斂	斂	練	練	练					

PINYIN PRONUNCIATION IS LIAO2

405	822	2350	2351	2587	3518	3731	5238	5333	5868
聊	聊	遼	鷯	撩	瞭	嘹	療	疗	寮
5994	6710	7677	8420	8967	9600	10040			
寥	燎	僚	獠	獠	辽	繚			

PINYIN PRONUNCIATION IS LIAO3

1351 3387 8322 9487

蓼 瞭 鈔 了

PINYIN PRONUNCIATION IS LIAO4

5442 6605 8166

廖 料 鏢

PINYIN PRONUNCIATION IS LIEN2

174

璉

PINYIN PRONUNCIATION IS LIE1

3742

咧

PINYIN PRONUNCIATION IS LIE4

36	37	451	452	520	2406	2407	2408	3056	3057
𪚩	𪚩	𪚩	𪚩	𪚩	𪚩	𪚩	𪚩	𪚩	𪚩
3949	3950	6131	7057	9045	9046	9646			
𪚩	𪚩	𪚩	𪚩	𪚩	𪚩	𪚩			

PINYIN PRONUNCIATION IS LING1

2876

拎

PINYIN PRONUNCIATION IS LING2

302	407	830	870	1274	1483	1484	2074	2094	2101
玲	聆	聆	菱	苓	櫛	櫛	靈	零	霽
3176	3181	4236	4545	6034	6442	6518	7052	7961	8318
齡	齡	齡	囹	凌	冷	鈴	凌	伶	鈴
8442	8443	8444	8446	8724	8760	8781	9300	9740	10015
瓊	瓊	鴿	翎	舠	舠	鯨	陵	灵	綾

PINYIN PRONUNCIATION IS LING3

4720	4740	8441
嶺	岭	領

PINYIN PRONUNCIATION IS LING4

4375	9416
另	令

PINYIN PRONUNCIATION IS LIN2

173	1445	1805	1899	2061	2256	3342	3467	4700	5228
琳	林	麟	臨	霖	磷	临	瞞	嶙	淋
5413	5415	5429	5431	6076	6618	6619	6752	8445	8815
麇	麇	麇	麇	淋	遴	鄰	煉	郚	鱗
9549	9550								
隣	隣								

PINYIN PRONUNCIATION IS LIN3

1571 1573 5185 5186 5707 5708 7067 7068
 標 標 廩 廩 懍 懍 凜 凜

PINYIN PRONUNCIATION IS LIN4

1108 1321 3832 3833 5478 5716 7885
 蔺 蔺 躡 躡 吝 恪 賃

PINYIN PRONUNCIATION IS LIU2

108 239 275 1691 2247 2289 3116 5315 5441 5448
 留 琉 瑠 榴 硫 泵 留 瘤 琉 旒
 5477 6274 6280 6409 8302 8339 9056 9060 9350
 刘 浏 流 瀏 鎢 鏐 留 劉 颶

PINYIN PRONUNCIATION IS LIU3

1692 10177 10178
 柳 絡 絡

PINYIN PRONUNCIATION IS LIU4

5183 6408 6798 8516 9057
 六 溜 熘 餹 遛

PINYIN PRONUNCIATION IS LI2

238 252 338 339 340 341 1103 1167 1168 2029
 璃 璆 璆 璆 璆 璆 璆 璆 璆 璆

PINYIN PRONUNCIATION IS L12

2033	2091	2173	3722	4492	5054	5488	5489	6277	6278
鸛	鸛	厘	哩	罹	喱	离	離	漓	漓
6585	6957	7256	7257	7313	7314	7315	7316	7430	7431
厘	禰	梨	犁	黎	黎	黎	黎	篱	籬
8422	8976	10106							
狸	狸	縈							

PINYIN PRONUNCIATION IS L13

212	1730	1971	2028	2032	3399	3999	4039	5001	6180
理	李	醴	灑	灑	里	豐	哩	裏	裡
6209	6880	6908	6909	6940	7771	8192	8795	9992	10304
澧	禮	礼	礼	裡	俚	鋁	鯉	螽	婁

PINYIN PRONUNCIATION IS L14

29	77	78	424	444	1130	1163	1189	1261	1400
鬚	驪	驪	隸	鬚	蒞	蒞	蒞	蒞	隸
1498	1662	1812	1893	1919	1937	2027	2030	2031	2034
櫪	櫪	櫪	鬲	吏	栗	麗	麗	麗	麗
2035	2066	2129	2130	2142	2143	2206	2265	2281	2381
麗	麗	厲	勵	厉	励	礪	礪	砾	麻
2382	2383	2392	2756	3049	3088	3089	3737	4142	4212
歷	曆	历	挨	鬚	驪	驪	歷	蠣	蚧

PINYIN PRONUNCIATION IS L14

4301	4312	4376	4489	5040	5223	5240	5293	5638	6100
唳	唳	叻	罍	立	癰	癰	痢	慄	漂
6128	6358	6583	6599	7005	7055	7255	7382	7422	7662
瀝	泣	糲	粒	戾	漂	利	策	笠	儼
7663	7681	7889	9011	9068					
儼	例	俐	獠	力					

PINYIN PRONUNCIATION IS LONG

1580

櫟

PINYIN PRONUNCIATION IS LONG2

233	234	1085	1086	1579	2240	2241	2470	3457	3458
瓏	瓏	龕	龕	櫟	礪	礪	龙	曠	曠
3693	3694	4259	4260	5091	5093	5094	5096	5098	5100
曠	曠	曠	曠	龕	龕	龕	龕	龕	龕
5101	5103	5336	5979	6253	6254	6954	6955	7424	7425
龕	龕	龕	龕	龕	龕	龕	龕	龕	龕
9147	9148	9577							
龕	龕	隆							

PINYIN PRONUNCIATION IS LONG3

PINYIN PRONUNCIATION IS LONG3

610	611	2689	2690	5092	5099	9542	9543
壟	壟	攏	攏	壘	壘	隴	隴

PINYIN PRONUNCIATION IS LOU1

3445	3468	4294
𥇏	𥇏	𥇏

PINYIN PRONUNCIATION IS LOU2

1025	1138	1551	1624	3670	4024	4029	4054	4156	4199
婁	婁	樓	樓	婁	𦵑	𦵑	𦵑	𦵑	𦵑
5180	5193	6637	7782	7865					
𦵑	𦵑	𦵑	𦵑	𦵑					

PINYIN PRONUNCIATION IS LOU3

565	649	2644	2743	4684	4701	7411	7441
𦵑	𦵑	𦵑	𦵑	𦵑	𦵑	𦵑	𦵑

PINYIN PRONUNCIATION IS LOU4

5259	5283	5343	5344	6477	6478	8200	9507
𦵑	𦵑	𦵑	𦵑	𦵑	𦵑	𦵑	𦵑

PINYIN PRONUNCIATION IS LUAN2

4514	4515	4516	4976	4978	4979	4983	4984	4986	4988
𦵑	𦵑	𦵑	𦵑	𦵑	𦵑	𦵑	𦵑	𦵑	𦵑

PINYIN PRONUNCIATION IS LUAN2

5382 5385 5386 5390 5391 5392 5394 5397 6235 6264
𪛗 𪛘 𪛙 𪛚 𪛛 𪛜 𪛝 𪛞 𪛟 𪛠

PINYIN PRONUNCIATION IS LUAN3

9058 9062
卯 卯

PINYIN PRONUNCIATION IS LUAN4

7225 8408
𪛡 𪛢

PINYIN PRONUNCIATION IS LUE4

2654 3974 3975
𪛣 𪛤 𪛥

PINYIN PRONUNCIATION IS LUN1

2872
𪛦

PINYIN PRONUNCIATION IS LUN2

1828 4542 4737 6438 7957 9269 9391 10193
𪛧 𪛨 𪛩 𪛪 𪛫 𪛬 𪛭 𪛮

PINYIN PRONUNCIATION IS LUN4

4954
論

PINYIN PRONUNCIATION IS LU02

89	1039	1060	2343	3098	4093	4094	4164	4496	4497
馬累	萝	蘿	爾見	馬累	囉	囉	螺	罗	邏
4505	4506	7417	7418	7800	7801	8214			
羅	邏	萝	籬	囉	囉	羅			

PINYIN PRONUNCIATION IS LU03

2671	2673	5262	5499	6941	7772
撈	擢	療	羸	裸	倮

PINYIN PRONUNCIATION IS LU04

107	274	701	709	1132	1822	2656	2799	2834	3115
駱	珞	埒	埒	落	輅	掣	掣	掣	駱
3531	4369	6365	6406	6764	8938	10175			
賂	咯	樂	洛	榮	雒	絡			

PINYIN PRONUNCIATION IS LU1

4361
嚕

PINYIN PRONUNCIATION IS LU2

543	994	1151	1152	1793	2153	3239	3240	3241	3258
壚	蘆	芦	芦	轡	廬	盧	廬	廬	卢

PINYIN PRONUNCIATION IS LU2

5173	5204	6167	6171	6716	6775	7127	8179	8698	8734
廬	庐	瀘	泸	爐	炉	鑪	鑪	鑪	鑪
8793	9116								
鱸	鱸								

PINYIN PRONUNCIATION IS LU3

1524	1681	2226	2615	3209	3210	3243	3253	6163	8716
擄	櫓	礪	擄	鹵	鹵	虜	虜	滷	艘
6752	8794								
艘	魯								

PINYIN PRONUNCIATION IS LU4

1357	1454	1455	1800	1801	2073	2295	3921	3922	4449
萊	麓	麓	輓	輓	露	碌	路	鷺	喙
5406	5422	6204	6267	6268	6503	6904	6910	7427	7428
鹿	鹿	潞	漉	漉	淥	祿	祿	麓	麓
7465	8102	8206	8331	8340	9494	9499	9747	9917	9918
錄	僂	鏞	錄	錄	陆	陸	录	戮	戮
9993	9995								
录	录								

PINYIN PRONUNCIATION IS LU1AN2

PINYIN PRONUNCIATION IS LU1AN2

4961 5389
變 亦
手 手

PINYIN PRONUNCIATION IS LU1E4

2684
掠

PINYIN PRONUNCIATION IS LU12

85 99 1591 1740 3094 3107 4557 5565 9707
驢 馱 櫚 櫚 驢 馱 馱 閭 閭

PINYIN PRONUNCIATION IS LU13

4324 5455 5456 6942 6960 7797 8210 9789 9813 9823
呂 旅 脅 褸 褸 侶 鋁 屢 屢 履

10069
縷

PINYIN PRONUNCIATION IS LU14

3242 3248 6168 6169 7192 8672 10206 10221
慮 慮 濾 濾 氣 律 綠 綠

PINYIN PRONUNCIATION IS MA12

556
埋

PINYIN PRONUNCIATION IS MAI3

4487 9447

買 买

PINYIN PRONUNCIATION IS MAI4

273 595 1031 1032 1763 2365 2452

麦 賣 邁 勸 卖 麥 迈

PINYIN PRONUNCIATION IS MANG2

1104 1129 2193 5496 5718 8147

芒 茫 茫 盲 忙 鋳

PINYIN PRONUNCIATION IS MANG3

952 954 4126 4127 6051 6052

莽 莽 蟒 蟒 莽 莽

PINYIN PRONUNCIATION IS MAN1

937

顛

PINYIN PRONUNCIATION IS MAN2

3370 3830 4834 4977 5384 8466 8801

瞞 蹣 謾 蠻 蛮 饅 鰻

PINYIN PRONUNCIATION IS MAN3

PINYIN PRONUNCIATION IS MAN3

6047

滿

PINYIN PRONUNCIATION IS MAN4

20 566 1027 3675 4584 5677 6194 8201 10071 10308
曼 蔓 蔓 曼 慢 慢 漫 鎰 縵 嫵

PINYIN PRONUNCIATION IS MAO1

8417 8959

貓 猫

PINYIN PRONUNCIATION IS MAO2

28 443 1282 3048 5451 7163 8145 9469 9471 9477
髦 髦 茅 髦 旄 毛 錨 矛 矛 螞 螞

PINYIN PRONUNCIATION IS MAO3

3746 9065

昂 卯

PINYIN PRONUNCIATION IS MAO4

220 732 968 1727 3475 3653 4583 5491 8031 8425
瑁 耄 茂 懋 眊 冒 帽 袤 兒 貌
9055
匍 匍

PINYIN PRONUNCIATION IS MA1

3381	3734	3798	4266	4267	5372	10255	10298	10332
嗎	麥	嗎	嘛	麼	麼	媽	媽	麼

PINYIN PRONUNCIATION IS MA2

1093	4129	5143	5144	5157	5229
麻	蟆	麻	麻	麼	痲

PINYIN PRONUNCIATION IS MA3

62	149	183	2170	2223	3073	4107	4148	4555
馬	瑪	瑪	碼	碼	馬	螞	螞	馬

PINYIN PRONUNCIATION IS MA4

4038	4067	4462	4483
罵	罵	罵	罵

PINYIN PRONUNCIATION IS ME12

253	1176	1177	1428	1644	1645	1647	1749	2087	2088
玫	莓	莓	媒	枚	梅	梅	楣	霉	霉
4745	6495	6697	8635	9893	9894	10271			
媚	湄	煤	徽	眉	郇	媒			

PINYIN PRONUNCIATION IS ME13

6393	6394	6527	7084	7085	7546	7554	8249
浼	浼	美	浼	浼	每	每	鎡

PINYIN PRONUNCIATION IS MEI4

3375 5297 5298 5892 8042 10263 10418

昧 痲 痲 寐 魅 妹 媚

PINYIN PRONUNCIATION IS MENG2

1033 1056 1144 1440 1527 3282 3373 3429 3430 3629

萌 蔓 蒙 檬 檬 蒙 蒙 蒙 蒙 蒙

3749 4187 4574 4581 5494 5497 5498 5507 6064 6172

盟 虻 蒙 蒙 氓 蚩 蚩 氓 濛 濛

8694 8699 8730 8735 9091 9118

蒙 蒙 蒙 蒙 蒙 蒙

PINYIN PRONUNCIATION IS MENG3

4131 4150 4240 5615 5616 8323 8727 8763 9035

蒙 蒙 螞 懵 夢 鎂 艦 艦 猛

PINYIN PRONUNCIATION IS MENG4

1057 1058 1458 9490

瞢 夢 夢 孟

PINYIN PRONUNCIATION IS MEN2

2713 2902 5532 7848 8009 9671

扞 扞 们 们 們 們

PINYIN PRONUNCIATION IS MEN4

5582 5719 5784 6048 6744 6811 9722

悶 怕 們 懣 炯 燭 悶

PINYIN PRONUNCIATION IS MIAN2

1660 3567 5821 8008 10148

棉 眠 𠂔 縣 綿

PINYIN PRONUNCIATION IS MIAN3

2300 3380 3738 3740 5651 6110 6121 6199 6200 7922

覷 眇 冕 冕 恹 沔 湏 湏 俛

7924 8835 8837 8839 8842 10036

俛 兔 勉 兔 勉 緬

PINYIN PRONUNCIATION IS MIAN4

2299 2302 2367 2368

面 面 麪 麵

PINYIN PRONUNCIATION IS MIAO1

3624

喵

PINYIN PRONUNCIATION IS MIAO2

1035 2547 3372

苗 描 瞄

PINYIN PRONUNCIATION IS MIAO3

1213 1737 3556 6188 7324 8426 9653 10063

藐 杪 眇 渺 秒 邈 淼 縹

PINYIN PRONUNCIATION IS MIAO4

5141 5182 10406

廟 庙 妙

PINYIN PRONUNCIATION IS MIE1

4289 9920

咩 乜

PINYIN PRONUNCIATION IS MIE4

1054 2052 4130 6117 7416 8068

蔑 灭 蟻 滅 箴 蟻

PINYIN PRONUNCIATION IS MING2

1226 1997 3471 3705 3748 4203 4330 6320 6834 8299

茗 酪 暝 暝 明 螟 鳴 溟 冥 銘

8850

名

PINYIN PRONUNCIATION IS MING4

9388

命

PINYIN PRONUNCIATION IS MIN2

236 308 4742 9835 10207
玟 珉 岷 民 緡

PINYIN PRONUNCIATION IS MIN3

2914 3784 3785 4459 5564 5573 5720 5785 6485 7548
抿 黽 黽 𪔐 𪔐 𪔐 𪔐 𪔐 𪔐 𪔐
7549 7556 7557 9706 9714 9836
𪔐 𪔐 𪔐 𪔐 𪔐 𪔐

PINYIN PRONUNCIATION IS MIU4

4972 10215
𪔐 𪔐

PINYIN PRONUNCIATION IS MI1

1985 3465 4293
𪔐 𪔐 𪔐

PINYIN PRONUNCIATION IS MI2

2044 4874 5147 5148 5151 5158 5414 5430 6489 6490
𪔐 𪔐 𪔐 𪔐 𪔐 𪔐 𪔐 𪔐 𪔐 𪔐
6608 6863 6867 9039 9040 9855 9857 9870 9878
𪔐 𪔐 𪔐 𪔐 𪔐 𪔐 𪔐 𪔐 𪔐

PINYIN PRONUNCIATION IS M13

3466 6571 6613 9850 9853
 眯 米 救 弭 弭

PINYIN PRONUNCIATION IS M14

2160 4890 4891 5906 5907 5909 5910 5911 5913 5989
 覓 謐 謐 宓 蜜 密 宓 蜜 密 蜜
 5990 6176 6823 6825 6893 6894 6991 7292 7293 8394
 密 汨 冫 冪 祕 祕 袂 秘 秘 覓

PINYIN PRONUNCIATION IS MOU2

2371 3576 4783 8110 9971
 𪛗 眸 謀 倖 牟

PINYIN PRONUNCIATION IS MOU3

794 2303
 某 冇

PINYIN PRONUNCIATION IS MOU4

9476
 瞽

PINYIN PRONUNCIATION IS MO1

2546 3346
 摸 冫

PINYIN PRONUNCIATION IS M02

1094	1438	4792	5145	5146	5152	5153	5155	5156	6576
磨	模	謨	磨	磨	摩	摩	魔	魔	模
8454	8474	9089							
饅	饅	膜							

PINYIN PRONUNCIATION IS M03

2511
抹

PINYIN PRONUNCIATION IS M04

336	848	1009	2426	2428	2429	3539	4096	4520	4525
末	茱	莫	歿	歿	歿	眈	嚙	默	墨
4528	5222	5852	6016	6061	6404	6421	6431	7233	8070
默	瘼	寞	沫	漠	沒	沒	沒	秣	血
8073	8416	8419	9193	9207	9512				
脈	貌	貌	脉	脈	陌				

PINYIN PRONUNCIATION IS MU2

4308
無

PINYIN PRONUNCIATION IS MU3

PINYIN PRONUNCIATION IS MU3

2925	2927	4442	4443	5004	5005	7520	9934	9937	10269
拇	拇	母	母	亩	畝	牡	母	母	姥
10424	10425								
姆	姆								

PINYIN PRONUNCIATION IS MU4

1001	1010	1011	1012	1013	1014	1015	1016	1018	1019
苜	蔦	墓	蔦	暮	墓	幕	募	募	慕
1381	3352	3367	4573	6075	7299	7531	8190		
木	目	睦	膜	沐	穆	牧	鉅		

PINYIN PRONUNCIATION IS NA13

2010	2011	8923	10286	10290	10350	10382	10385
迺	迺	乃	孌	孌	妳	妳	奶

PINYIN PRONUNCIATION IS NA14

1398	2306	2311	6996	7188	8926	8927
柰	耐	奈	襪	氖	甬	甬

PINYIN PRONUNCIATION IS NANG2

1868	3662
囊	嚙

PINYIN PRONUNCIATION IS NANG3

PINYIN PRONUNCIATION IS NANG3

2559 3685
攘 囊

PINYIN PRONUNCIATION IS NANG4

7982
鼻 囊

PINYIN PRONUNCIATION IS NAN1

4561
因

PINYIN PRONUNCIATION IS NAN2

893 1349 1444 1559 3640 3976 4135 9625
難 南 楠 柶 喃 男 蟪 难

PINYIN PRONUNCIATION IS NAN3

717 721 9092
赧 赧 腩

PINYIN PRONUNCIATION IS NAO1

2165
不 好

PINYIN PRONUNCIATION IS NAO2

2523 4456 8131 9034
撓 呶 饒 獠

PINYIN PRONUNCIATION IS NA03

319 320 2297 2298 5717 5801 5802 9162 9242 9243
 瑙 瑙 瑙 瑙 惱 惱 惱 脑 腦 腦

PINYIN PRONUNCIATION IS NA04

192 3143 5570 9711
 鬧 鬧 鬧 鬧

PINYIN PRONUNCIATION IS NA2

9387 10402
 拿 拏

PINYIN PRONUNCIATION IS NA3

4380 4437
 哪 哪

PINYIN PRONUNCIATION IS NA4

1562 1563 2584 4100 4101 4847 4848 6951 6952 8217
 衲 衲 捺 呐 呐 讷 讷 衲 衲 衲
 8218 9230 9919 10091 10092
 衲 那 那 納 納

PINYIN PRONUNCIATION IS NEI4

4613 4615 7179 7180
 內 內 氖 氖

PINYIN PRONUNCIATION IS NENG2

9974
能

PINYIN PRONUNCIATION IS NG1

2460
兀

PINYIN PRONUNCIATION IS NIANG2

10326 10352
孃 娘

PINYIN PRONUNCIATION IS NIANG4

1976 1989
釀 娘

PINYIN PRONUNCIATION IS NIAN1

860
萑

PINYIN PRONUNCIATION IS NIAN2

7098 7134 7305 8792 8829
年 年 黏 鮎 鯰

PINYIN PRONUNCIATION IS NIAN3

PINYIN PRONUNCIATION IS NIAN3

348	2290	2513	2611	2833	2851
輦	碾	攢	拈	撚	撚

PINYIN PRONUNCIATION IS NIAN4

785	786	4405	9418
廿	廿	唸	念

PINYIN PRONUNCIATION IS NIAO3

1192	3979	7999	8000	8101	10367	10416
薦	勦	裊	鳥	鸟	嫗	嫗

PINYIN PRONUNCIATION IS NIAO4

9827
尿

PINYIN PRONUNCIATION IS NIE1

2631	2781	2878	9563
捏	捏	捻	隍

PINYIN PRONUNCIATION IS NIE4

58	387	388	791	1201	1202	1203	3377	3582	3608
齧	聶	聶	聶	孽	孽	孽	齧	聶	聶
3822	3828	3913	4715	4716	6181	6348	7975	8129	8130
躡	躡	齧	孽	孽	涅	涅	集	鑷	鑷

PINYIN PRONUNCIATION IS NIE4

8141	8142	8283	8350	8351
鐳	鐳	鐳	鐳	鐳

PINYIN PRONUNCIATION IS NING2

1597	1598	1602	1603	1604	2718	2719	2721	2722	2723
寧	寧	寧	寧	寧	寧	寧	寧	寧	寧
4270	4279	4280	4281	4282	5865	5866	5902	5904	5905
寧	寧	寧	寧	寧	寧	寧	寧	寧	寧
5906	5912	7091	9000	9001	9003	9004	9005		
甯	甯	凝	甯	甯	甯	甯	甯		

PINYIN PRONUNCIATION IS NING4

6292	6293	6296	6297	6298	7601	7847
寧	寧	寧	寧	寧	倭	倭

PINYIN PRONUNCIATION IS NIN2

7874	7921
您	您

PINYIN PRONUNCIATION IS NIU1

10417
妞

PINYIN PRONUNCIATION IS NIU2

PINYIN PRONUNCIATION IS NIU2

7095 7519

牛 牛

PINYIN PRONUNCIATION IS NIU3

2918 5792 8337 9041 10212

扭 扭 鈕 扭 紐

PINYIN PRONUNCIATION IS NIU4

8076 8077 8078

血 血 血

PINYIN PRONUNCIATION IS NI1

9616

3

PINYIN PRONUNCIATION IS NI2

1811 2089 3478 4431 5416 5432 5790 6483 7901 8424

靦 靦 睨 呢 麁 麁 怩 泥 倪 貌

8822 9013 9830 10413

鯢 猊 尼 妮

PINYIN PRONUNCIATION IS NI3

2678 2900 2930 5463 5602 7873 7920

拟 拟 擬 旒 懼 你 你

PINYIN PRONUNCIATION IS NI4

325	3156	3356	3371	3777	4746	6492	6668	9073
匿	恚	瞞	瞞	昵	疑	溺	逆	膩

PINYIN PRONUNCIATION IS NONG2

1446	1452	1970	1972	3998	4001	4070	4071	6208	6210
農	農	醞	醞	農	農	嚨	嚨	濃	濃
6841	7267	7268	7791	7792	7984	7985	9134	9135	
农	穰	穰	儂	儂	龔	龔	膿	膿	

PINYIN PRONUNCIATION IS NONG4

165
弄

PINYIN PRONUNCIATION IS NOU4

40 45
耨 耨

PINYIN PRONUNCIATION IS NUAN3

3730 6788
暖 煖

PINYIN PRONUNCIATION IS NUE4

3983 3985
虐 虐

PINYIN PRONUNCIATION IS NU13

8505

餒

PINYIN PRONUNCIATION IS NUN4

10278 10279

嫩 嫩

PINYIN PRONUNCIATION IS NU02

2805 2846 2923 7631 10387 10421

掇 挪 挪 攤 娜 娜

PINYIN PRONUNCIATION IS NU04

2916 4789 5642 6582

搦 諾 懦 糯

PINYIN PRONUNCIATION IS NU2

10397 10398 10399 10404

奴 駑 駑 孖

PINYIN PRONUNCIATION IS NU3

10403 10405

奴 弩

PINYIN PRONUNCIATION IS NU4

PINYIN PRONUNCIATION IS NU4

10401

怒

PINYIN PRONUNCIATION IS NU1E4

3225

3230

4823

4825

5210

5244

5249

5250

虐 虐 謔 謔 疟 疟 瘧 瘧

PINYIN PRONUNCIATION IS NU13

10254

女

PINYIN PRONUNCIATION IS NU14

2307

慝

PINYIN PRONUNCIATION IS ONG1

9957

ㄥ

PINYIN PRONUNCIATION IS OUI

1887

1888

1889

1890

1891

1892

2484

2485

2487

2488

甌 甌 毆 鷗 歐 毆 瓠 瓠 鷗 鷗

2489

2490

3766

4801

7035

欧 毆 呕 謳 讴

PINYIN PRONUNCIATION IS OU3

48 796 3668 7783
耦 耦 呕 偶

PINYIN PRONUNCIATION IS OU4

5635 5657 6094 6134
怙 怙 漚 洳

PINYIN PRONUNCIATION IS OI

769
乚

PINYIN PRONUNCIATION IS PAI1

2786
拍

PINYIN PRONUNCIATION IS PAI2

1520 1525 2607 2617 7725 7739 7744 8620 8622
排 排 排 排 牌 俳 俳 徘 徘

PINYIN PRONUNCIATION IS PAI4

6336 6388
湃 派

PINYIN PRONUNCIATION IS PANG2

PINYIN PRONUNCIATION IS PANG2

2078	2144	2330	2331	2471	4181	5122	5187	5188	6257
罟	厖	龐	龐	虬	螃	旁	龐	龐	滂
7836	8640	9150							
傍	傍	膀							

PINYIN PRONUNCIATION IS PANG3

50	4264
𦉳	𦉳

PINYIN PRONUNCIATION IS PANG4

9174
胖

PINYIN PRONUNCIATION IS PAN1

1715	2590	2818	6381
攀	扳	扳	潘

PINYIN PRONUNCIATION IS PAN2

4222	8703	8719	8720	8721	8739	8755	8756	8757
蟠	盤	槃	磐	盤	盤	槃	磐	盤

PINYIN PRONUNCIATION IS PAN4

3551	3552	3965	3966	6307	6538	6552	6553	6554	6921
盼	盼	畔	畔	泮	叛	判	判	叛	攀

PINYIN PRONUNCIATION IS PA01

2863 9203

抛 孚

PINYIN PRONUNCIATION IS PA02

2315 4386 5371 5419 5435 6978 9301

匏 咆 庖 麇 麇 袍 包

PINYIN PRONUNCIATION IS PA03

3927

跑

PINYIN PRONUNCIATION IS PA04

2171 2224 2279 5320 6182 6422 6803 9450

礲 礲 砲 庖 瀑 泡 炮 咆

PINYIN PRONUNCIATION IS PA1

3930

趴

PINYIN PRONUNCIATION IS PA2

2865 7161 7395 8680

扒 弄 挹 爬

PINYIN PRONUNCIATION IS PA4

PINYIN PRONUNCIATION IS PA4

4598 5750

怕 怕

PINYIN PRONUNCIATION IS PEI1

1978 3719 9103 9104

醅 胚 胚 胚

PINYIN PRONUNCIATION IS PEI2

608 3069 3265 3512 9540

培 裴 裴 賠 陪

PINYIN PRONUNCIATION IS PEI4

300 1840 2006 2008 2081 2083 4603 5444 5447 6107

珮 轡 配 配 霈 霈 帔 旆 旆 沛

6244 7950

沛 佩

PINYIN PRONUNCIATION IS PENG1

2202 2571 5023 5641 9249

砰 抨 烹 怦 匸

PINYIN PRONUNCIATION IS PENG2

32 447 584 585 1232 1264 1693 2278 3052 4118

翯 翯 彭 螫 蓬 芄 棚 砌 翯 螳

PINYIN PRONUNCIATION IS PENG2

6030 7475 9082 9214 9215
澎 蓬 膨 朋 鵬

PINYIN PRONUNCIATION IS PENG3

2504

捧

PINYIN PRONUNCIATION IS PENG4

2254 2255 2741 2742
碰 碰 碰 碰

PINYIN PRONUNCIATION IS PEN1

3589

噴

PINYIN PRONUNCIATION IS PEN2

9428

盆

PINYIN PRONUNCIATION IS PIAN1

7015 7444 7875
翩 篇 偏

PINYIN PRONUNCIATION IS PIAN2

94 98 3106 9142 9177
駢 駢 駢 駢 駢

PINYIN PRONUNCIATION IS PIAN3

4888

編

PINYIN PRONUNCIATION IS PIAN4

100 3108 7699

騙 騙 片

PINYIN PRONUNCIATION IS PIAO1

1930 6097 9097

飄 漂 膘

PINYIN PRONUNCIATION IS PIAO2

1929 10284

瓢 嫖

PINYIN PRONUNCIATION IS PIAO3

2423 3379 10029

殍 嫖 嫖

PINYIN PRONUNCIATION IS PIAO4

76 1927 1928 3087 5637 7656 8789

驃 票 剽 驃 嫖 嫖 鰲

PINYIN PRONUNCIATION IS PIE1

PINYIN PRONUNCIATION IS PIE1

2620 2795 3299 8380
撇 撇 瞥 瞥

PINYIN PRONUNCIATION IS PIE3

945 7093
丕 丩

PINYIN PRONUNCIATION IS PING1

10310
娉

PINYIN PRONUNCIATION IS PING2

488	489	938	990	1125	1481	2047	2048	4587	4594
坪	坪	苹	蘋	萍	枰	平	平	餅	餅
4607	4608	4807	4808	4994	6547	6548	7047	7048	7062
幌	幌	評	評	瓶	瓶	瓶	憑	憑	憑
7063	7130	7131	7888	9806	9811				
憑	餅	餅	凭	屏	屏				

PINYIN PRONUNCIATION IS PING4

392
聘

PINYIN PRONUNCIATION IS PIN1

PINYIN PRONUNCIATION IS PIN1

2680 2739 2910 2933 10325 10345

拼 拼 擗 拚 姘 姘

PINYIN PRONUNCIATION IS PIN2

3185 3186 3938 9427

頻 頻 頻 貧

PINYIN PRONUNCIATION IS PIN3

4073

品

PINYIN PRONUNCIATION IS PIN4

798 7542

聘 牝

PINYIN PRONUNCIATION IS PI1

493 2100 2219 2221 2598 2603 2883 9802 10044 10047

坯 霹 砒 砒 批 批 披 劈 紕 紕

PINYIN PRONUNCIATION IS PI2

153 154 693 1507 1513 3809 3810 3811 3812 4333

毳 毳 埤 枇 枇 毗 毘 毗 毘 啤

4304 5330 8427 8428 9201 9448 9565

羆 疲 貔 貔 脾 皮 陴

PINYIN PRONUNCIATION IS P13

759 2196 2158 2462 5237 5345 7691 7731 9443
圮 丕 邳 匹 痞 癖 仉 仉 疋

PINYIN PRONUNCIATION IS P14

5594 8052 9734 9778 9779 9792 9798 10370 10371
闢 僻 闢 屁 屁 辟 譬 媿 媿

PINYIN PRONUNCIATION IS POU1

5076

剖

PINYIN PRONUNCIATION IS POU2

2581 2687

抔 掬

PINYIN PRONUNCIATION IS POU3

1577 5073 5075

梧 瓠 瓠

PINYIN PRONUNCIATION IS PO1

743 6449 9449 9592

坡 潑 頗 陂

PINYIN PRONUNCIATION IS PO2

PINYIN PRONUNCIATION IS P02

6447 8027
婆 瞞
女 畚

PINYIN PRONUNCIATION IS P03

1925 7381
匜 匱

PINYIN PRONUNCIATION IS P04

255 2285 6359 6614 8016 8026 8032
珀 破 泊 粕 迫 魄 迫

PINYIN PRONUNCIATION IS PU1

2618 2619 3257 4004 7746
撲 扑 支 撲 仆

PINYIN PRONUNCIATION IS PU2

208 1083 1123 1244 1958 3859 6353 6934 7745 9248
璞 菩 蒲 葡 圃 蹕 濮 濮 僕 圃

PINYIN PRONUNCIATION IS PU3

487 1526 1528 4097 4872 4873 6105 6106 6568 6570
埔 樸 朴 圃 譜 譜 浦 溥 普 普

PINYIN PRONUNCIATION IS PU4

8114 8160 8532
鋪 鋪 鋪

PINYIN PRONUNCIATION IS QIANG1

1711	1719	3871	3872	3932	4197	4629	6541	6542	8219
槍	枪	蹻	蹻	蹻	蹻	戕	羌	羌	鏘
8220	8319	9168							
鏘	鎗	腔							

PINYIN PRONUNCIATION IS QIANG2

475	497	881	957	1497	4622	4628	9854	9862	9883
墙	墙	蔷	蔷	樯	𢇛	牆	彊	强	強
10291									
媯									

PINYIN PRONUNCIATION IS QIANG3

2679	6992	6993	8335	8336
搶	襁	襁	鋺	鋺

PINYIN PRONUNCIATION IS QIANG4

4406
𠵽

PINYIN PRONUNCIATION IS QIAN1

901	902	1161	1938	1940	2352	2564	2565	2763	4296
𨔵	𨔵	芊	遷	遷	牽	擥	擥	扞	𠵽

UNCLASSIFIED

DAAG17-68-C-0064

NL

100

END
DATE
FILMED
7-77

PINYIN PRONUNCIATION IS QIAN1

4878	4879	5512	5523	5636	5835	5838	5842	5844	7193
謙	謙	牽	牽	慳	蹇	騫	褰	蹇	千
7226	7469	7470	7485	7486		8264	8312	8330	8644
迁	籤	籤	簽	筌	針	鉛	鋟	鋟	愆
9363	9558								
𪔐	𪔐								

PINYIN PRONUNCIATION IS QIAN2

1314	2537	2757	3247	3249	4532	4535	6017	6146	6660
軋	柑	捐	虔	虔	黔	黔	潛	潛	前
7390	8140	8173	8317						
箝	鉗	錢	鈴						

PINYIN PRONUNCIATION IS QIAN3

3962	3992	4837	4840	6138	8469	8470	10078	10080
遣	遣	譴	譴	淺	醴	醴	縊	縊

PINYIN PRONUNCIATION IS QIAN4

933	1178	1222	1814	1815	4644	5726	6665	7578	8765
茜	倩	芡	塹	塹	嵌	慊	歉	倩	欠
10107	10110	10136	10247						
緯	緯	紆	紆						

PINYIN PRONUNCIATION IS QIA01

2185	2762	3824	3904	3905	5011	7285	7289	8271
磽	擣	蹺	蹻	蹻	敲	磬	鍤	鍬

PINYIN PRONUNCIATION IS QIA02

456	459	1072	1173	1174	1636	1642	1643	1655	3481
堯	翹	莠	蕎	莽	橈	橋	桥	樵	瞧
5749	7512	7513	7817	7893	7894				
瞧	喬	乔	鰓	僑	侨				

PINYIN PRONUNCIATION IS QIA03

504	5669
巧	悄

PINYIN PRONUNCIATION IS QIA04

906	4677	4704	4705	4830	4912	5934	5961	7752
鞘	峭	嶠	峽	諂	譙	窈	竅	俏

PINYIN PRONUNCIATION IS QIA1

2836	2853
招	招

PINYIN PRONUNCIATION IS QIA3

3152
卡

PINYIN PRONUNCIATION IS QIA4

5777 6435
恰 洽

PINYIN PRONUNCIATION IS QIE1

2946 2980
切 切

PINYIN PRONUNCIATION IS QIE2

1245
𪛗
加

PINYIN PRONUNCIATION IS QIE3

3351
且

PINYIN PRONUNCIATION IS QIE4

59	353	4261	5109	5604	5611	5940	5941	5966	5967
𦉳	𦉳	𦉳	𦉳	𦉳	𦉳	𦉳	𦉳	𦉳	𦉳
5968	7354	8119							
𦉳	𦉳	𦉳							

PINYIN PRONUNCIATION IS QING1

277	278	1792	4110	6012	6013	7172	7175	7690	7728
青	青	輕	蜻	清	清	靄	氫	傾	傾

PINYIN PRONUNCIATION IS QING1

8106 8778 9064

傾 鯖 卿

PINYIN PRONUNCIATION IS QING2

1251 1254 3365 3366 4522 4530 5599 5600

敬 敬 晴 晴 鯨 鯨 情 情

PINYIN PRONUNCIATION IS QING3

2945 2979 4761 4762 9940

頃 頃 請 請 頃

PINYIN PRONUNCIATION IS QING4

763 764 765 5164 5438

聲 聲 聲 庆 慶

PINYIN PRONUNCIATION IS QIN1

122 3128 4717 5046 5047 8015 8294 9417

駸 駸 欽 亲 親 侵 欽 衾

PINYIN PRONUNCIATION IS QIN2

133 137 152 157 889 890 1216 1273 1709 2793

秦 秦 琴 琴 勤 懃 芹 苓 檣 擒

2874 4108 4109 4402 9408

擒 螭 螭 噙 禽

PINYIN PRONUNCIATION IS QIN3

5880 5894
寢 寢

PINYIN PRONUNCIATION IS QIN4

2794 2877 4303 4421 6331
揷 揷 𠵽 𠵽 沁

PINYIN PRONUNCIATION IS QIONG2

229 266 267 268 269 736 737 745 1345 5964
琮 瓊 瓊 瓊 瓊 玆 玆 邛 芎 窮
5974 6768 6769 7364
穷 𦑔 𦑔 邛

PINYIN PRONUNCIATION IS QIONG3

5982
穹

PINYIN PRONUNCIATION IS QIU1

684 910 1164 1640 4217 6778 7282 7288 7608 7628
坵 鞦 萩 楸 蚯 炆 秋 鶩 丘 邱
8816 8820
鰭 鰭

PINYIN PRONUNCIATION IS QIU2

181	2496	2497	2498	3499	4244	4245	4541	6226	6639
球	求	裘	逌	赇	虬	虬	囚	泗	酉
6647	7165	7689							
迺	毬	球							

PINYIN PRONUNCIATION IS QIU3

6615	8501
糗	餽

PINYIN PRONUNCIATION IS QI1

818	820	974	1510	2148	2151	2326	2961	2975	3717
欺	期	萋	棲	慼	慼	岐	妻	七	噉
4666	4719	5647	5659	6081	6137	6139	6144	6145	6379
崎	嶧	慼	悽	漆	沕	淒	柒	沕	溪
7058	8438	10253							
淒	谿	谿							

PINYIN PRONUNCIATION IS QI2

13	68	80	167	177	430	496	703	731	811
髻	騏	騎	琪	琦	髻	埼	圻	耆	其
814	815	821	875	1041	1237	1429	2325	3035	3079
碁	碁	碁	萁	蘄	芪	棋	奇	髻	騏

PINYIN PRONUNCIATION IS Q12

3091	3101	3800	3835	3848	4122	4648	5111	5408	5424
騎	歧	畦	跂	踦	蜚	岐	齊	鹿	麒
5443	5454	5481	5484	6040	6859	6898	6899	6900	6903
旗	旂	齊	齊	淇	祺	祈	祈	祇	祁
8165	8587	8782	9149	9161					
錡	頤	鰭	臍	臍					

PINYIN PRONUNCIATION IS Q13

537	1748	2287	4652	4743	4744	7006	7010	7011	7019
起	杞	啓	豈	邕	岷	啓	启	啟	榮
7020	7022	7559	10039						
啓	縻	乞	綺						

PINYIN PRONUNCIATION IS Q14

57	2149	2175	2218	2220	4052	4061	4063	4708	4905
契	戚	磧	砌	砌	噐	噐	噐	屹	訖
5509	5510	5511	6245	6337	7171	7185	7216	7222	7560
弃	棄	棄	泣	汽	气	氣	憇	憇	迄
9404	10067	10068							
企	緝	緝							

PINYIN PRONUNCIATION IS QUAN1

PINYIN PRONUNCIATION IS QUAN1

4539 5799

卷 悛

PINYIN PRONUNCIATION IS QUAN2

27	442	1042	1267	1439	1734	3047	3893	4198	4953
鬚卷	鬚卷	頤	荃	權	杈	鬚卷	蹠	蜷	詮
5323	5724	6561	7482	8033	8313	9363			
痊	倦	拳	筌	泉	銓	全			

PINYIN PRONUNCIATION IS QUAN3

2345 3806 8949 10126
犬 吠 牙 綣

PINYIN PRONUNCIATION IS QUAN4

1046 6562 6563 9630
勸 券 券 劝

PINYIN PRONUNCIATION IS QUE1

7133
缺

PINYIN PRONUNCIATION IS QUE2

5319
癩

PINYIN PRONUNCIATION IS QUE4

601	665	674	778	924	1605	1627	2239	2249	2258
塙	慤	慤	却	鵲	榷	榷	碣	確	確
2273	2274	2725	2753	5578	5593	8556	9644	9718	9733
确	确	摧	摧	阙	阙	卻	雀	闕	闕

PINYIN PRONUNCIATION IS QUN1

9977
逡

PINYIN PRONUNCIATION IS QUN2

6987	9744	9745
裙	羣	群

PINYIN PRONUNCIATION IS QU1

75	83	532	534	1886	2483	2486	3086	3996	4152
驅	驅	趋	趨	區	区	岐	驅	曲	蛆
4165	4556	4650	4671	6858	8087	8088	9083	9829	
蚰	驱	岖	岖	祛	軀	軀	祛	屈	

PINYIN PRONUNCIATION IS QU2

204	993	2369	2370	3441	3442	3443	5255	6084	6141
瓌	遽	麥曲	麥菊	瞿	瞿	瞿	癰	渠	渠

PINYIN PRONUNCIATION IS QU2

7645 7719 8626 9264 9266

佢 佢 衢 鳩 劬

PINYIN PRONUNCIATION IS QU3

410 419 832 841 3173

取 娶 取 娶 齒 禹

PINYIN PRONUNCIATION IS QU4

518 519 770 3233 3237 5584 9724

趣 趣 去 覷 覷 闕 闕

PINYIN PRONUNCIATION IS RANG2

2682 5007 5008 6240 6886 7274

攘 薶 勦 攘 襁 襁

PINYIN PRONUNCIATION IS RANG3

600 4290

壤 壤

PINYIN PRONUNCIATION IS RANG4

4621 4851 4887 7036

詵 讓 諒 让

PINYIN PRONUNCIATION IS RAN2

22 437 3042 6794 6801 8851 9283

鬚 鬚 鬚 燃 燃 然 然

PINYIN PRONUNCIATION IS RAN3

1063 4563 6428
冉 冉 染

PINYIN PRONUNCIATION IS RA02

858 1409 8450 10265
堯 橈 饒 嫖

PINYIN PRONUNCIATION IS RA03

2583 2594
擾 扰

PINYIN PRONUNCIATION IS RA04

458 10005
遶 繞

PINYIN PRONUNCIATION IS RENG1

2839
扔

PINYIN PRONUNCIATION IS RENG2

7931
仍

PINYIN PRONUNCIATION IS REN2

PINYIN PRONUNCIATION IS REN2

7194 7561 7562 9360 10137 10147 10357 10365

壬 亻 仁 人 紕 紕 妊 妊

PINYIN PRONUNCIATION IS REN3

1191 7320 9278 9310

苙 稔 忍 忍

PINYIN PRONUNCIATION IS REN4

917 920 1824 1825 4943 4948 4952 6964 6970 7043

韌 韌 韌 韌 認 認 訖 衽 衽 讖

7883 7886 7944 7946 8490 8500 9271 9309 9891 9892

任 恁 仞 仞 飪 飪 刃 刃 韌 韌

10184 10187

紉 紉

PINYIN PRONUNCIATION IS RE3

950 3618

惹 喏

PINYIN PRONUNCIATION IS RE4

643 727 864 869 2861

執 執 執 執 執

PINYIN PRONUNCIATION IS R11

PINYIN PRONUNCIATION IS R11

4513

日

PINYIN PRONUNCIATION IS R14

3349 8148

日 鉅

PINYIN PRONUNCIATION IS RONG2

356	856	874	1022	1023	1145	1894	5922	5978	6302
戎	茸	茸	茸	茸	荣	融	容	容	溶
6303	6509	6746	6747	6759	7164	8246	8247	10000	
溶	戎	熔	熔	榮	越	鎔	鎔	絨	

PINYIN PRONUNCIATION IS RONG3

5985 6844

冗 冗

PINYIN PRONUNCIATION IS ROU2

2889	3937	4621	9470
揉	蹂	肉	柔

PINYIN PRONUNCIATION IS ROU3

6627

糴

PINYIN PRONUNCIATION IS ROU4

4614

肉

PINYIN PRONUNCIATION IS RUAN3

1788

1819

5653

9495

輓 軟 懊 阮

PINYIN PRONUNCIATION IS RUI2

967

豕
豕生

PINYIN PRONUNCIATION IS RUI3

988

989

1154

1155

芷
止止

芷
禁

蕊
心

蕊
米

PINYIN PRONUNCIATION IS RUI4

226

1006

1067

3217

3219

4175

4176

8254

8255

瑞 芮 芮 睿 睿 蚋 蚋 銳 銳

PINYIN PRONUNCIATION IS RUNG2

6315

灑

PINYIN PRONUNCIATION IS RUN4

PINYIN PRONUNCIATION IS RUN4

5536 6283 6470 9676

闰 润 潤 閏

PINYIN PRONUNCIATION IS RUQ4

947 7370 7501 7632 9871 9872

若 箸 筭 偌 弱 弱

PINYIN PRONUNCIATION IS RU2

1370 2065 3704 4141 6113 6925 7598 7666 9607 10032

茹 顙 嚙 蠕 濡 襦 伢 儒 孺 濡

10301

如

PINYIN PRONUNCIATION IS RU3

142 2113 6505 8413

辱 辱 汝 乳

PINYIN PRONUNCIATION IS RU4

823 942 2573 6007 6114 6912 6926 9361 9997 10033

蓐 蓐 孺 潯 潯 褥 褥 入 綈 綈

PINYIN PRONUNCIATION IS SAI1

3971 8802 9133

頤 鰓 腮

PINYIN PRONUNCIATION IS SA14

5036 5839

塞 賽

PINYIN PRONUNCIATION IS SANG1

1375 1884 2361 9633

喪 喪 喪 桑

PINYIN PRONUNCIATION IS SANG3

2896 4414 9634

桑 噪 頰

PINYIN PRONUNCIATION IS SAN1

3 9962

三 叁

PINYIN PRONUNCIATION IS SAN3

2060 6635 6636 8453 9410 9424 9433 10018

霰 糝 糝 餓 傘 傘 傘 繖

PINYIN PRONUNCIATION IS SAN4

969

散

PINYIN PRONUNCIATION IS SAO1

PINYIN PRONUNCIATION IS SA01

118 121 2891 2894 3125 3127 9138 9229 9231 10084
騷 騷 搔 搔 騷 騷 臊 臊 臊 臊
10225
縹

PINYIN PRONUNCIATION IS SA03

749 2901 2905 10362
埽 掃 掃 嫂

PINYIN PRONUNCIATION IS SA1

1285 1286 2545 7563
薩 薩 撒 仨

PINYIN PRONUNCIATION IS SA3

6102 6108 6109
洒 灑 灑

PINYIN PRONUNCIATION IS SA4

982 3919 5105
卅 趺 颯

PINYIN PRONUNCIATION IS SENG1

7867
僧

PINYIN PRONUNCIATION IS SEN1

1431

木
林

PINYIN PRONUNCIATION IS SE4

155	156	1374	2360	6125	6156	6414	6418	6424	6425
𠂔	𠂔	𠂔	𠂔	𠂔	𠂔	𠂔	𠂔	𠂔	𠂔
必	必	𠂔	𠂔	𠂔	𠂔	𠂔	𠂔	𠂔	𠂔
7245	8922								
𠂔	𠂔								
𠂔	𠂔								

PINYIN PRONUNCIATION IS SHAI1

7462

𠂔
𠂔
師

PINYIN PRONUNCIATION IS SHAI3

4034

𠂔
𠂔

PINYIN PRONUNCIATION IS SHAI4

3451

3452

3453

𠂔 𠂔 𠂔

PINYIN PRONUNCIATION IS SHANG1

2421

3319

5119

7892

7895

8881

8904

𠂔 𠂔 𠂔 𠂔 𠂔 𠂔 𠂔

PINYIN PRONUNCIATION IS SHANG3

3315 3725
賞 晌

PINYIN PRONUNCIATION IS SHANG4

3031 3307 3308 7737
上 尚 尚 仕

PINYIN PRONUNCIATION IS SHAN1

225	298	991	1265	1676	2758	3870	3926	4578	4641
珊	珊	苫	芟	杉	搨	跚	跚	刪	山
4849	6077	6513	6514	6776	6975	6976	7181	8681	8705
訕	潛	羶	羴	煽	衫	衫	氤	彡	舩
8741	9143	9292	9355	10322	10389				
舩	臙	刪	剗	姍	姍				

PINYIN PRONUNCIATION IS SHAN3

5585 9513 9519 9725
閃 陝 陝 閃

PINYIN PRONUNCIATION IS SHAN4

101	2685	3109	3530	4193	4194	4195	5268	6230	6511
駢	擅	駢	贍	蟪	蟪	蟪	疝	汕	善

PINYIN PRONUNCIATION IS SHAN4

6515	6526	6887	7026	8480	8481	8483	8804	8812	8813
善	善	檀	扇	饔	饔	饔	鯽	𩚑	𩚑
8814	9171	9172	9175	10121	10122	10124	10328		
𩚑	膳	膳	膳	𩚑	𩚑	𩚑	嬪		

PINYIN PRONUNCIATION IS SHAD1

1531	2626	6693	7254	7373	7392	7402	8700	8736
梢	捎	燒	稍	梢	捎	筍	艄	艄

PINYIN PRONUNCIATION IS SHAD2

1256	1696	5069	9272
芍	杓	韶	勺

PINYIN PRONUNCIATION IS SHA03

9643
少

PINYIN PRONUNCIATION IS SHA04

4014	9267	9270	10182
哨	劬	邵	紹

PINYIN PRONUNCIATION IS SHA1

2288	5278	6462	6463	6465	8314	9375	9378	9379	10202
砂	痧	沙	蓑	𩚑	鍛	𦏧	殺	殺	紗

PINYIN PRONUNCIATION IS SHA2

4395 4408 7952 7963
𠵹 𠵹 𠵹 𠵹

PINYIN PRONUNCIATION IS SHA3

7911 7960
𠵹 𠵹

PINYIN PRONUNCIATION IS SHA4

2076 3723 7229 7507 7508 8918
𠵹 𠵹 𠵹 𠵹 𠵹 𠵹

PINYIN PRONUNCIATION IS SHE12

4911
誰

PINYIN PRONUNCIATION IS SHENG1

760 761 762 3711 5084 7097 7101 7212 7445 7530
𠵹 𠵹 𠵹 𠵹 𠵹 𠵹 𠵹 𠵹 𠵹 𠵹
9359
𠵹

PINYIN PRONUNCIATION IS SHENG2

10073 10074 10083 10243
繩 繩 繩 繩

PINYIN PRONUNCIATION IS SHENG3

7100 9645

省 省

PINYIN PRONUNCIATION IS SHENG4

391 394 797 800 2451 2456 3545 7199 9184 9187

聖 聖 聖 聖 盛 盛 晟 剩 賸 勝

9188 9194 9618

勝 胜 圣

PINYIN PRONUNCIATION IS SHEN1

247 1135 1193 1354 1356 3579 4051 6321 7176 7776

琛 浸 侵 蔘 蔘 申 呻 深 氤 伸

6086 10066

身 紳

PINYIN PRONUNCIATION IS SHEN2

2232 6878 6879

呻 神 神

PINYIN PRONUNCIATION IS SHEN3

3677 4869 4958 5883 5921 6301 7157 10342

哂 審 諗 审 審 瀋 矧 孀

PINYIN PRONUNCIATION IS SHEN4

144 825 876 1910 2115 5620 5621 6499 6502
蜃 甚 甚 腎 蜃 慎 慎 滲 滲

PINYIN PRONUNCIATION IS SHE1

2322 3534
奢 賒

PINYIN PRONUNCIATION IS SHE2

3525 4192 5545 7213 9371 9684
貼 蛇 閣 舌 佗 閣

PINYIN PRONUNCIATION IS SHE3

2867 2880
捨 捨

PINYIN PRONUNCIATION IS SHE4

718 2133 2518 2521 2538 2541 4951 5417 5433 6159
赦 庫 攝 攝 攝 攝 設 麇 麇 涉
6853 6854 8089 9030 9033 9365 9422
社 社 射 捨 捨 舍 舍

PINYIN PRONUNCIATION IS SHI1

671 3340 4773 5464 6147 6191 6201 7141 8058 9015
著 師 詩 施 溼 濕 濕 失 師 獅

PINYIN PRONUNCIATION IS SHI1

9339 9763 9777 9953
 蝨 尸 屍 虱

PINYIN PRONUNCIATION IS SHI2

380 557 1004 2167 2208 2869 3403 3555 5882 5898
 十 埭 蒔 石 碩 拾 時 时 寔 实
 5995 7607 7710 8448 8471 8796 9421
 寔 什 鼯 食 蝕 鮓 食

PINYIN PRONUNCIATION IS SHI3

90 2447 3099 4394 7140 7653 9812 10426
 駛 豕 駛 史 矢 使 屎 始

PINYIN PRONUNCIATION IS SHI4

305 335 345 366 382 545 646 728 976 977
 式 示 頤 示 士 𠂔 勢 勢 世 貰
 1574 1772 1924 2509 2813 2814 2862 3414 3602 4314
 柿 軾 事 拭 誓 逝 勢 是 嗜 噬
 4763 4855 4875 4957 5039 5116 5607 5876 6849 6876
 試 識 謚 諡 市 適 恃 室 丕 視
 6877 7037 7219 7224 7388 7609 7614 8493 8494 8544
 視 识 适 舐 筮 仕 侍 飾 飾 釋

PINYIN PRONUNCIATION IS SHI4

9048 9376
氏 弑

PINYIN PRONUNCIATION IS SHOU1

3269 4749 4750
収 收 収

PINYIN PRONUNCIATION IS SHOU3

2501 5873 6648 7160
才 守 首 手

PINYIN PRONUNCIATION IS SHOU4

130 363 740 2800 4080 5300 6684 7813 8400 9002
寿 壽 壽 授 獸 瘦 兽 售 受 狩
10156
綬

PINYIN PRONUNCIATION IS SHUAI1

2710 2711 5003
摔 摔 衰

PINYIN PRONUNCIATION IS SHUAI3

9237
甩

PINYIN PRONUNCIATION IS SHUAI4

3341 4188 4189 5522 5524 5525 8060

帥 蟀 蟀 率 率 率 帥

PINYIN PRONUNCIATION IS SHUANG1

2062 2204 7822 9632 10287

霜 礮 雙 双 孀

PINYIN PRONUNCIATION IS SHUANG3

2482

爽

PINYIN PRONUNCIATION IS SHUAN1

1703 2866 5533 9672

栓 拴 问 問

PINYIN PRONUNCIATION IS SHUAN4

6480

涮

PINYIN PRONUNCIATION IS SHUA1

4429 9805

唰 刷

PINYIN PRONUNCIATION IS SHUA3

PINYIN PRONUNCIATION IS SHUA3

2308

耍

PINYIN PRONUNCIATION IS SHUI3

6001 9648 9650

氵 冰 水

PINYIN PRONUNCIATION IS SHUI4

3473 4595 7280 7281

睡 悅 稅 稅

PINYIN PRONUNCIATION IS SHUN3

1670 4447

楯 吮

PINYIN PRONUNCIATION IS SHUN4

3522 3523 7743 8399

瞬 瞬 順 舜

PINYIN PRONUNCIATION IS SHUO1

4880 4881

說 說

PINYIN PRONUNCIATION IS SHUO4

2748 6670 6672 6786 8287 8310 8358 10388

掬 朔 槊 爍 鑠 銖 銖 鈞

PINYIN PRONUNCIATION IS SHU1

1472	1402	1504	1588	1829	1830	2419	2572	2614	2888
樞	樗	枢	梳	輸	輸	殊	擣	攄	抒
8117	8535	9354	9451	9452	9658	9896	10199	10356	
舒	舒	𠂔	疎	疏	書	书	紓	姝	

PINYIN PRONUNCIATION IS SHU2

986	3154	3491	5026	5027	5028	6153	7238
叔	叔	贖	孰	塾	熟	淑	秫

PINYIN PRONUNCIATION IS SHU3

1053	1074	3410	3411	3420	3674	4469	4470	4500	5302
薯	諸	暑	暑	野	曙	署	署	蜀	瘋
7321	7708	9781	9785	9818					
黍	鼠	屬	屬	属					

PINYIN PRONUNCIATION IS SHU4

1415	1613	1735	1869	1907	1909	2380	3663	3671	5137
樹	述	树	束	豎	豎	戍	唳	數	庶
6029	6090	6091	6638	7755	7756	7763	7764	8612	8613
澍	漱	漱	数	條	條	條	條	術	術
10315									
恕									

PINYIN PRONUNCIATION IS S11

817	2126	2539	3611	3970	4220	4452	4454	5130	6041
斯	廝	撕	嘶	思	師	絲	絲	廝	漸
7528	7789	8207	9898	9958	10079	10222	10223	10228	10229
私	俚	錫	司	厶	總	絲	驚	系	絲
10230									
驚									

PINYIN PRONUNCIATION IS S13

2435

死

PINYIN PRONUNCIATION IS S14

38	49	54	92	453	500	3058	3101	4098	4549
肆	耜	耜	馬	四	肆	寺	肆	馬	嗣
4752	5107	6227	6486	6905	7503	7808	7970	8111	8527
兄	竝	泗	汜	祀	筭	似	似	俟	飼
8528	9840	9950	9952	10324	10407				
飼	巳	兄	兄	姒	姒				

PINYIN PRONUNCIATION IS SONG1

15	432	883	1721	3037	4647	4693	6082
鬆	鬆	崧	松	鬆	崧	嵩	淞

PINYIN PRONUNCIATION IS SONG3

5052 5631 8661 8662 8663
竦 悚 聳 聳 慫

PINYIN PRONUNCIATION IS SONG4

4960 4962 5856 6559 8579
訟 誦 宋 送 頌

PINYIN PRONUNCIATION IS SOU1

1198 2782 4320 5358 6349 8277 8499 8714 8750 9349
蒐 搜 叟 廋 洩 鍤 餽 艘 艘 颶

PINYIN PRONUNCIATION IS SOU3

1026 1139 2645 4271 7703
𪛗 𪛘 擻 𪛚 𪛛

PINYIN PRONUNCIATION IS SOU4

3665 3666
嗽 嗽

PINYIN PRONUNCIATION IS SUAN1

2009 5351 9043
酸 痠 𩇛

PINYIN PRONUNCIATION IS SUAN4

PINYIN PRONUNCIATION IS SUAN4

367 833 7350 7404
示 蒜 筭 算

PINYIN PRONUNCIATION IS SUI1

1214 3480 8932
姝 睢 夙

PINYIN PRONUNCIATION IS SUI2

4020 4085 4086 9508 9510 9515 9967 10158
髓 虽 雖 隋 隨 隨 雖 綏

PINYIN PRONUNCIATION IS SUI4

244 651 2246 3162 3163 4659 4727 4862 5955 6658
璪 璪 碎 歲 歲 歲 岁 誅 邃 遂
6753 7240 9552 9927 10024 10129
燧 穗 隧 崇 總 緣

PINYIN PRONUNCIATION IS SUN1

1296 2431 8864 9036 9611 9613
蓀 殮 殮 獮 孫 孫 孙

PINYIN PRONUNCIATION IS SUN3

1652 1653 2660 7480 7496
榘 榘 損 筍 笋

PINYIN PRONUNCIATION IS SU01

1077 1134 1756 2734 3645 4446 6464 6466 7420 10114
 蓑 莎 梭 抄 嗦 唆 掌 娑 簑 縮
 10118
 縮

PINYIN PRONUNCIATION IS SU03

209 318 1379 4010 8181 8182 8341 8691
 瑣 瑣 索 啖 鎖 鎖 鎖 所

PINYIN PRONUNCIATION IS SU04

2553
 擦

PINYIN PRONUNCIATION IS SU1

1225 1257 1280 1850 1992 3631 8819
 蘇 苏 蔬 甦 酥 蘇 穌

PINYIN PRONUNCIATION IS SU2

7916
 俗

PINYIN PRONUNCIATION IS SU4

316 1114 1117 1872 1943 3423 4839 4924 5601 5862
 素 蓓 蓓 速 粟 嗦 謾 訴 憐 宿

PINYIN PRONUNCIATION IS SU4

5918	6048	6311	6386	6671	6673	6674	7377	8457	8870
宿	涑	溯	沂	塑	朔	愬	簌	餽	觥
8893	9075	9332	9668	9669	9670				
觥	膝	夙	肅	肅	肅				

PINYIN PRONUNCIATION IS TAI1

1355	3729	9239
苔	太	胎

PINYIN PRONUNCIATION IS TAI2

126	588	1416	1755	2529	2935	3131	9351	9965	9968
駘	臺	檯	桤	擡	抬	駘	颱	台	炆

PINYIN PRONUNCIATION IS TAI4

139	861	2346	2349	6123	9976
泰	臺	太	恣	汰	態

PINYIN PRONUNCIATION IS TANG1

3861	4011	6185	8183
蹚	噏	湯	鎗

PINYIN PRONUNCIATION IS TANG2

617	2703	3312	3314	4151	4183	5405	6266	6604	9126
塘	搪	堂	棠	螳	塘	唐	澹	糖	膛

PINYIN PRONUNCIATION IS TANG3

6173 7747 7750 7751 8090 10400

淌 倘 儻 傥 躺 帑

PINYIN PRONUNCIATION IS TANG4

523 6187

趟 湯

PINYIN PRONUNCIATION IS TAN1

724 2543 2754 2895 5219 5337 6045 6461 8100 9415

坍 攤 探 摊 癱 瘫 灘 滩 慫 貪

PINYIN PRONUNCIATION IS TAN2

427 485 559 606 1401 1572 1941 1957 3470 4804

坛 壇 塢 壇 耘 檀 覃 醴 曇 譚

4882 5286 6101 6773 7124 7129 9861 9869
談 痰 潭 郊 譚 鑪 彈 彈

PINYIN PRONUNCIATION IS TAN3

553 1988 2662 2749 3153 6938 7168

坦 醢 揮 掸 志 袒 毯

PINYIN PRONUNCIATION IS TAN4

894 2237 3615 4413 4669 4670

歎 碳 嘆 呖 炭 炭

PINYIN PRONUNCIATION IS TA01

131	364	2802	2852	3790	4377	4918	5757	6003	6020
焔	燾	搯	掬	饕	叨	諂	惱	涛	濤
6035	6376	7761	7768	9881	9890	10143	10144	10157	
濤	滔	條	條	攷	韜	絛	絛	緇	

PINYIN PRONUNCIATION IS TA02

741	1259	1386	1397	1423	1667	1700	4349	4383	4391
燾	萄	梲	櫛	櫛	桃	桃	吡	陶	吡
6384	6419	6427	8582	8584	8849	9284	9320	9322	9581
洮	淘	洮	鼗	逃	迢	甸	鼗	逃	陶

PINYIN PRONUNCIATION IS TA03

4815

討

PINYIN PRONUNCIATION IS TA04

2310	2318	2334
套	套	套

PINYIN PRONUNCIATION IS TA1

572	5996	6945	7541	8099	10419
塌	它	榻	牠	他	她

PINYIN PRONUNCIATION IS TA3

472
塔

PINYIN PRONUNCIATION IS TA4

1552	2530	2650	3779	3825	3867	3939	4486	4501	5544
榻	撻	搨	趵	蹻	跼	踏	逌	逌	達
5560	8903	8964	9651	9683	9701				
闢	獺	獺	沓	闢	闢				

PINYIN PRONUNCIATION IS TENG2

1239	1240	5314	6558	7476	9160	9181	9183	9185	9186
滕	滕	疼	誊	滕	騰	騰	騰	騰	騰
9189									
滕									

PINYIN PRONUNCIATION IS TE1

3004
𡗗

PINYIN PRONUNCIATION IS TE4

326	1373	2104	7521	8162
𡗗	忒	忒	特	鉞

PINYIN PRONUNCIATION IS TIAN1

347 6018 6343
天 添 添

PINYIN PRONUNCIATION IS TIAN2

473 3793 3973 5549 5741 7215 8205 9688
填 田 畋 寘 恬 甜 鈿 闋

PINYIN PRONUNCIATION IS TIAN3

354 2432 3548 4003 5683 7214 7220 7514 8491 9136
忝 殄 腆 覲 慙 舔 舔 忝 飮 腆

PINYIN PRONUNCIATION IS TIAN4

2515 2776
拵 拵

PINYIN PRONUNCIATION IS TIAO1

2808 2858 6897 6902
挑 挑 挑 挑

PINYIN PRONUNCIATION IS TIAO2

33 448 1247 3053 4232 4939 7479 7517 7754 7762
髻 髻 茗 髻 蜩 調 筲 条 條 條
7917 7947 8935 9263
佻 佻 条 迢

PINYIN PRONUNCIATION IS TIAO3

5970 5976

窈 窈
兆 兆

PINYIN PRONUNCIATION IS TIAO4

3538 3549 3914 3928 8580 8583 9061 9321 9929 9930

眺 眺 跳 跳 兆頁 兆頁 頰 頰 祟 祟
米 雀

PINYIN PRONUNCIATION IS TIE1

3503

貼

PINYIN PRONUNCIATION IS TIE3

8133 8134 8175 8263 8356

鐵 鐵 鏤 鐵 鉄

PINYIN PRONUNCIATION IS TIE4

2433 4579

餐 帖

PINYIN PRONUNCIATION IS TING1

386 506 546 790 2119 2121 2122 2125 2145 4350

聽 聽 聽 聽 廳 廳 廳 廳 厅 听
5127
廳

PINYIN PRONUNCIATION IS TING2

2086 3807 4211 5014 5354 7210 7829 10327
 霆 町 蜓 亭 庭 廷 停 婷

PINYIN PRONUNCIATION IS TING3

1639 2766 8268 8713 8749
 挺 挺 鉦 艇 艇

PINYIN PRONUNCIATION IS TI1

1626 3759 3865 8256
 梯 剔 踢 錫

PINYIN PRONUNCIATION IS TI2

558 1967 2633 3415 3416 3718 3844 3879 3916 4263
 堤 醞 提 題 題 唬 踭 蹄 踭 啼
 4351 6819 6875 6944 10133
 唬 鵠 褪 裼 涕

PINYIN PRONUNCIATION IS TI3

4025 7642 7673
 體 体 仵

PINYIN PRONUNCIATION IS TI4

349 1159 3469 3643 3644 3706 5680 5732 6317 6817
 替 薙 睇 嚏 嚏 嚏 惕 涕 涕 剃

PINYIN PRONUNCIATION IS T14

7941 9009 9774 9819
惆 逖 屈 屨

PINYIN PRONUNCIATION IS TONG1

9463

通

PINYIN PRONUNCIATION IS TONG2

1560 3436 4564 4691 5059 5697 6248 7803 7833 7934
桐 瞳 同 峒 童 恫 潼 侗 僮 佟
8215 8629 8706 8742 9275 9373
銅 衙 舫 舫 彤 仝

PINYIN PRONUNCIATION IS TONG3

1724 2886 2887 7419 7489 10108
桶 捅 捅 筒 筩 統

PINYIN PRONUNCIATION IS TONG4

5332 5743
痛 慟

PINYIN PRONUNCIATION IS TONG1

7958

偷

PINYIN PRONUNCIATION IS TOU2

1915 2864 4756 5596

頭投 ㄣ 头

PINYIN PRONUNCIATION IS TOU4

7210

透

PINYIN PRONUNCIATION IS TO2

4001

𪛗

PINYIN PRONUNCIATION IS TUAN1

6232

湍

PINYIN PRONUNCIATION IS TUAN2

2557 4056 4418 5630 6579 6598

搏 團 团 博 搏 糰

PINYIN PRONUNCIATION IS TUI1

2783

推

PINYIN PRONUNCIATION IS TUI2

PINYIN PRONUNCIATION IS TUI2

7318

頹

PINYIN PRONUNCIATION IS TUI3

9233

腿

PINYIN PRONUNCIATION IS TUI4

4201 9757

蛻 退

PINYIN PRONUNCIATION IS TUN1

3686 4255 7511

噉 哼 吞

PINYIN PRONUNCIATION IS TUN2

4550 8520 9029 9108 9314 9772

囤 飪 狍 豚 屯 屨

PINYIN PRONUNCIATION IS TUN4

6426 6988

沌 褪

PINYIN PRONUNCIATION IS TUO1

2732 2777 2778 4904 7858 9191 9192

挖 拖 托 託 佗 脱 脱

PINYIN PRONUNCIATION IS TU02

79	81	97	1866	1984	2251	3090	3092	3105	3890
駝	駝	駝	橐	陀	陀	駝	駝	駝	陀
4082	6305	8001	9548	9561					
鼉	沱	鸵	陀	陀					

PINYIN PRONUNCIATION IS TU03

1731	1732	8439
橢	橢	妥

PINYIN PRONUNCIATION IS TU04

972	1671	2582	4307	6334	7393
擇	柝	拓	唾	唾	籜

PINYIN PRONUNCIATION IS TU1

7317
禿

PINYIN PRONUNCIATION IS TU2

1268	2003	2041	3216	3638	4508	4547	4553	4560	5939
荼	酖	凸	凸	啍	圖	图	圖	圖	突
6432	6433	8607	9369	9769	9960				
涂	塗	徒	途	屠	啍				

PINYIN PRONUNCIATION IS TU3

383 3580
土 吐

PINYIN PRONUNCIATION IS TU4

1199 1255 8055 9268
菟 菟 兔 兔

PINYIN PRONUNCIATION IS WAI1

2157
歪 正

PINYIN PRONUNCIATION IS WAI4

4364 8848
啾 外

PINYIN PRONUNCIATION IS WANG1

2463 2465 6010 8560 8561
亢 亢 汪 允 尙

PINYIN PRONUNCIATION IS WANG2

148 5495
王 亡

PINYIN PRONUNCIATION IS WANG3

PINYIN PRONUNCIATION IS WANG3

1394 4460 4612 4616 4617 5698 8046 8639 8648 10090
枉 𡵓 罔 𦉳 𦉳 惘 魘 往 徃 網

PINYIN PRONUNCIATION IS WANG4

3361 5492 5493 5503 5505 5506 5508
旺 望 望 忘 望 望 妄

PINYIN PRONUNCIATION IS WAN1

1916 4191 4987 5396 5927 6236 6265
豌 蜿 彎 𠂔 剗 灣 灣

PINYIN PRONUNCIATION IS WAN2

160 335 359 5845 9338 10189
玩 頑 頑 完 丸 紈

PINYIN PRONUNCIATION IS WAN3

242 1109 1119 1607 1820 1821 2250 2827 2829 3739
琬 莞 苑 惋 輓 輓 碗 挽 挽 晚
3741 3964 5926 8014 8865 10117 10119 10343 10383 10384
晚 畹 宛 皖 盥 綰 綰 婉 婉 婉

PINYIN PRONUNCIATION IS WAN4

1028 2430 5722 5928 9167 9916 9948
萬 万 惋 寤 腕 翫 𠂔

PINYIN PRONUNCIATION IS WA1

465 466 2730 3584 4115 4353 5952 6026 10313
鼃 鼃 挖 哇 蛙 呱 窪 洼 媧

PINYIN PRONUNCIATION IS WA2

10264

娃

PINYIN PRONUNCIATION IS WA3

2473 2474 2475 2476 2477 2478 2995 2996 2997 2998
瓦 𡗗 𡗘 𡗙 𡗚 𡗛 𡗜 𡗝 𡗞 𡗟
2999 3000 7684 7733
𡗠 𡗡 𡗢 𡗣

PINYIN PRONUNCIATION IS WA4

6914 6918

袜 襪

PINYIN PRONUNCIATION IS WEI1

944 2147 3716 4661 7330 7787 8636 8637 9538
葳 威 噉 歲 逄 偎 微 微 隈

PINYIN PRONUNCIATION IS WEI2

1219 1220 1680 3348 4322 4554 4597 4609 4703 4713
薇 薇 桅 𠂔 唯 圍 帷 幃 巍 嵬

PINYIN PRONUNCIATION IS WEI2

5539	5748	6504	6820	6821	6994	8406	8770	9735	9886
闍	惟	維	為	为	禕	爲	危	闡	韋
9889	10146								
違	維								

PINYIN PRONUNCIATION IS WEI3

309	372	1169	1346	3417	4901	5170	5171	5295	6130
璋	韦	萎	葦	韮	諉	鹽	鹽	痿	洧
6613	7329	8064	8065	8982	9567	9817	10213	10214	10412
煒	委	偉	偉	猥	隈	尾	緯	緯	媿

PINYIN PRONUNCIATION IS WEI4

337	467	1329	3435	3808	3978	4068	4163	4838	6206
未	恚	蔚	味	畏	胃	喂	蝟	謂	渭
6727	7331	7831	7870	7871	7913	8467	8492	8675	8676
煨	魏	位	偽	伪	偽	餵	餵	衛	衛
8677	8983	9765	9767	9900					
衛	狴	尉	慰	卫					

PINYIN PRONUNCIATION IS WENG1

4410	9441	9442
翁	翁	翁

PINYIN PRONUNCIATION IS WENG4

5528 5529 5530 9439 9440
雍 雍 雍 瓮 瓮

PINYIN PRONUNCIATION IS WEN1

5260 6192 6193 8800
瘟 温 温 鯁

PINYIN PRONUNCIATION IS WEN2

2079 4185 5469 5540 5547 7516 9679 9686 10105
雯 蚊 文 闻 闻 文 聞 聞 紋

PINYIN PRONUNCIATION IS WEN3

4384 7300 7308 9217 9287
吻 穩 穩 脬 刎

PINYIN PRONUNCIATION IS WEN4

2646 2706 5490 5556 6273 7581 7585 9697
搵 抻 紊 问 汶 璽 璽 問

PINYIN PRONUNCIATION IS WO1

1038 5947 6212 7890
窩 窩 渦 倭

PINYIN PRONUNCIATION IS WO3

PINYIN PRONUNCIATION IS W03

7537

我

PINYIN PRONUNCIATION IS W04

1311 1897 1905 2908 3178 4426 4606 6342 6479
 幹 卧 臥 握 齧 喔 幄 沃 渥

PINYIN PRONUNCIATION IS WU1

454 1402 2359 4335 4810 6021 6022 6785 8034 8035
 圯 朽 巫 鳴 誣 汙 汚 鴆 烏 鄔
 5103 8286 9780
 烏 鷄 屋

PINYIN PRONUNCIATION IS WU2

357 1157 1471 1880 2981 3667 4172 4457 7108 9935
 无 蕪 梧 吾 无 唔 蜈 吳 無 毋

PINYIN PRONUNCIATION IS WU3

206 207 1766 2791 5353 5735 5737 7096 7109 7110
 武 鵠 五 搗 廬 忤 憮 午 舞 舞
 7524 7644 7879 7897 7899 10259 10355
 牯 伍 仵 侮 侮 媿 媿

PINYIN PRONUNCIATION IS WU4

PINYIN PRONUNCIATION IS WU4

696	1502	2092	2096	2097	2448	2464	3450	4844	5634
塢	杌	霧	霧	霧	戊	兀	晤	誤	悟
5692	5893	7111	7535	8942	9286	9474	9475	9478	9479
悞	寤	迂	物	务	勿	驚	驚	驚	務
9400	9481	9518	9566						
教	務	阮	鵑						

PINYIN PRONUNCIATION IS XIANG1

95	1537	3103	5009	5159	6079	7259	7374	8223	8693
驤	相	驤	襄	廂	湘	香	箱	鑲	舡
8729	10022	10235	10236						
舡	絳	乡	鄉						

PINYIN PRONUNCIATION IS XIANG2

4670	5192	6520	6890	6891
詳	庠	翔	祥	祥

PINYIN PRONUNCIATION IS XIANG3

1540	4338	5022	8504	10237	10239
想	响	享	餉	響	饗

PINYIN PRONUNCIATION IS XIANG4

494	961	962	1682	3787	7923	8097	8608	8838	10238
項	巷	巷	橡	鄉	像	伺	衞	象	嚮

PINYIN PRONUNCIATION IS XIAN1

1678 2815 3720 3838 3839 7207 7657 7658 7804 8269
 杓 掀 暹 蹁 蹁 先 僊 僊 仙 銛

6293 8811 10161 10162 10378 10379
 鉦 鮮 纖 纖 蟻 蟻

PINYIN PRONUNCIATION IS XIAN2

1908 2136 3211 3462 3562 4305 4306 4352 5274 5275
 賢 咸 鹵 咸 暎 暎 啣 啣 銜 疝 疝

5276 5338 5339 5550 5591 6352 8657 8709 8745 9689
 疝 疝 疝 闲 闲 涎 銜 舷 舷 閑

9731 9804 10109 10337 10338 10346 10409 10410
 閒 弦 絃 嫵 嫵 嫌 嫵 嫵

PINYIN PRONUNCIATION IS XIAN3

829 1224 2443 3428 3626 3786 3900 4154 4593 4736
 甚 藪 藪 顯 顯 顯 跣 蜺 懣 嶮

8266 9031 9587
 銑 獫 險

PINYIN PRONUNCIATION IS XIAN4

216 1020 1350 3226 3394 3573 4678 5825 5915 6531
 現 覓 獻 獻 縣 縣 峴 憲 宪 羨

PINYIN PRONUNCIATION IS XIAN4

6533	8515	8517	9202	9574	9582	9596	10045	10150
羨	餡	餡	腺	陷	陷	限	綫	線
次								

PINYIN PRONUNCIATION IS XIAO1

67	1317	1318	1553	2069	2227	2228	3078	3323	3324
驍	蕭	蕭	杓	霄	硝	硝	驍	肖	肖
3325	3326	3327	3585	3791	4059	4436	5215	5878	5879
削	削	逍	曉	鴉	囂	嘒	瘳	宵	宵
6070	6071	6174	6175	7492	7493	7760	7767	7997	8045
瀟	瀟	消	消	簫	簫	脩	脩	巢	魑
8185	10059								
銷	綃								

PINYIN PRONUNCIATION IS XIAO3

3401	7455	7456	7457	9639
曉	筱	篠	篠	小

PINYIN PRONUNCIATION IS XIAO4

711	1585	3599	4292	4419	4420	5199	5200	7451	7595
孝	校	哮	咲	嘯	嘯	效	効	笑	黷
7839									
倣									

PINYIN PRONUNCIATION IS XIA1

3463	4136	4155	4242	8798	8833
瞎	吓	蝦	蝦	魚	魚

PINYIN PRONUNCIATION IS XIA2

218	306	1546	1803	1843	2070	2099	2210	3566	3658
瑕	瑕	柙	轄	匣	霞	霞	硖	遐	暇
3776	4050	4518	4526	4668	7679	8969	8979	9762	
暇	呬	黠	黠	峽	俠	狹	狎	遐	

PINYIN PRONUNCIATION IS XIA4

1372	1926	2140	2183	3641	5163	7128	9530
下	𠂔	廈	夏	吓	廈	罅	隲

PINYIN PRONUNCIATION IS XIE1

1385	3188	3757	4157	4158
楔	些	歇	蝎	蝎

PINYIN PRONUNCIATION IS XIE2

60	571	747	897	913	1761	1762	2589	2987	3578
繫	頤	邪	鞋	鞣	协	協	挾	邪	叶
4816	4820	5775	7692	7732	8346	9216	9218	9293	9294
諧	諧	恹	偕	偕	斜	胁	脇	恹	脅

PINYIN PRONUNCIATION IS XIE2

9368 10009

斜 績

PINYIN PRONUNCIATION IS XIE3

5919 6832 6848

寫 写 写

PINYIN PRONUNCIATION IS XIE4

963	964	1396	1665	3875	4225	4226	4227	4228	4229
𪛗	𪛗	械	榭	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗
4230	4883	4913	4991	4992	4997	5364	5365	5366	5367
𪛗	𪛗	謝	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗
5368	5369	5763	5764	5765	5766	5767	5768	6057	6058
𪛗	𪛗	懈	懈	懈	懈	懈	懈	泄	𪛗
6165	6166	6198	6300	6319	6324	6397	6398	6399	6400
𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗
6401	6402	7099	7103	7565	8878	8879	8886	8887	8889
𪛗	𪛗	卸	卸	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗
8890	8901	8902	8909	8910	8912	8913	9021	9022	9023
𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗
9024	9025	9026	9784	10019	10072	10273			
𪛗	𪛗	𪛗	𪛗	𪛗	𪛗	𪛗			

PINYIN PRONUNCIATION IS XING1

766 3707 4543 5677 5807 7580 7584 8981 9131
 馨 星 興 惺 興 興 猩 腥

PINYIN PRONUNCIATION IS XING2

327 328 331 332 2180 6770 8463 8602 9525
 刑 型 形 邢 硯 榮 錫 行 陞

PINYIN PRONUNCIATION IS XING3

1969 2787
 醒 擤

PINYIN PRONUNCIATION IS XING4

637 1217 1533 5610 5736 7622 10354
 幸 苻 杏 悻 性 倖 姓

PINYIN PRONUNCIATION IS XIN1

1081 1082 1153 3736 5043 5049 5068 5597 5760 7030
 莘 薪 芯 昕 辛 新 歆 忄 忻 心
 7102 8225 8289 8596 9642
 生 銍 金 欣 小
 金 金

PINYIN PRONUNCIATION IS XIN3

7877
 仙

PINYIN PRONUNCIATION IS XIN4

7583 7587 7825 8069 8085
 𪔐 𪔐 信 衅 𪔐

PINYIN PRONUNCIATION IS XIONG1

4390 4946 5776 6420 6445 9219 9296 9297 9436 9437
 兄 詢 恂 洵 汹 胸 凶 冑 凶 兇

PINYIN PRONUNCIATION IS XIONG2

2479 9973
 雄 熊

PINYIN PRONUNCIATION IS XIU1

4318 5355 6523 6540 7641 7758 7759 7765 7766 8423
 咻 麻 羞 羞 休 修 脩 修 脩 貅

8482 8485 9173 9176
 饒 饒 膳 膳

PINYIN PRONUNCIATION IS XIU3

1517
 朽

PINYIN PRONUNCIATION IS XIU4

4326 4686 6362 6946 7309 8272 8327 8328 10139 10203
 嗅 岫 溴 袖 秀 锈 鏽 鏽 綉 繡

PINYIN PRONUNCIATION IS XIU4

10204

繡

PINYIN PRONUNCIATION IS XII

379	568	582	886	1326	1479	1668	1669	1672	1745
下	熹	熹	昔	熙	栖	析	皙	皙	樨
1746	1949	1981	2200	2446	2677	2784	2785	2837	2976
樨	西	醯	哂	猗	攜	攜	携	扱	匸
3437	3550	3591	3592	3650	3701	3765	3911	4137	4223
晰	晞	嘻	嘻	晰	曦	晞	蹊	蜥	蟋
4368	4398	4400	4674	4675	4676	4975	5639	6080	6535
吸	噏	唏	巖	巖	巖	諗	恹	淅	羲
6656	7319	7337	7525	7528	7617	7618	7713	7915	8435
禧	稀	熙	牺	犧	僖	僖	鼯	僖	奚
8545	8659	9094	9392	9393	9402	9782	9786	10267	10268
悉	僖	膝	希	歙	兮	犀	犀	嬉	嬉

PINYIN PRONUNCIATION IS XII

1091	1661	4921	5097	5104	5136	5613	6784	7991	8202
蓆	檄	謖	襲	襲	席	惜	熄	息	錫
9537	9902	9914	9915	10360					
隰	习	習	習	媳					

PINYIN PRONUNCIATION IS X13

507	569	581	583	1218	2043	2342	2977	4116	4117
喜	熹	喜	熹	蓰	璽	璽	亡	蟪	蟪
6339	6855	8621	9821	9966					
洗	禧	徙	徙	臬					

PINYIN PRONUNCIATION IS X14

194	1838	2271	3145	3227	3232	3236	5587	5972	6350
鬩	繫	矽	鬩	戲	戲	戲	廟	窅	馮
6356	6850	7706	7951	8371	8489	8555	8844	9358	9389
汐	楔	烏	係	歛	餽	卻	夕	系	翕
9401	9531	9595	9620	9727	9788	10076	10163		
郤	隙	隙	戏	闕	員	細	裕		

PINYIN PRONUNCIATION IS XUAN1

241	1113	1596	1768	1771	2717	3698	4277	4866	4916
瑄	萱	萱	亘	軒	揎	暄	喧	諠	媛
5357	6703	6745	7799	10113					
宣	烜	煊	僊	綰					

PINYIN PRONUNCIATION IS XUAN2

202	235	3395	3570	3575	5460	5520
璿	璇	懸	懸	懸	旋	玄

PINYIN PRONUNCIATION IS XUAN3

5310 7208 9846

癩 选 選

PINYIN PRONUNCIATION IS XUAN4

3459 6269 6282 6290 6742 8241 10183

眩 漩 洿 渲 炫 鋇 絢

PINYIN PRONUNCIATION IS XUE1

699 912 1200

華 靴 薛

PINYIN PRONUNCIATION IS XUE2

5486 5820 7594

孝 学 學

PINYIN PRONUNCIATION IS XUE3

2098

雪

PINYIN PRONUNCIATION IS XUE4

5987 8066

穴 血

PINYIN PRONUNCIATION IS XUN1

PINYIN PRONUNCIATION IS XUN1

576	680	1172	1993	3713	4046	6779	7338	7339	7340
塤	堦	薰	醺	曛	勛	燠	熏	勳	勲
9012									
獾									

PINYIN PRONUNCIATION IS XUN2

285	1248	3112	4734	4942	5773	6412	6468	6469	8664
珣	荀	馴	峣	詢	恂	洵	潯	潯	循
8830	8831	9253	9257	9660	9664	9665	10439	10441	
鱗	鱗	旬	郇	尋	尋	寻	巡	巡	

PINYIN PRONUNCIATION IS XUN4

104	2039	2427	4806	4910	4949	6111	8667	9028	9340
馴	迅	殉	訊	訓	訊	汛	徇	狗	迅
9612	9614	9845							
遜	遜	巽							

PINYIN PRONUNCIATION IS XU1

31	446	541	542	2064	2146	3051	3231	3234	3235
鬚	鬚	墟	墟	需	戍	鬚	虛	歔	虛
3238	3358	3557	3986	3987	4769	6120	6626	8682	8683
歔	吁	吁	嘘	嘘	訐	湏	糈	須	須

PINYIN PRONUNCIATION IS XU1

9446
胥

PINYIN PRONUNCIATION IS XU2

8669
徐

PINYIN PRONUNCIATION IS XU3

1751 4893 4971
栩 許 詡

PINYIN PRONUNCIATION IS XU4

742	1106	2004	3527	3656	3657	3752	4672	4709	4710
壻	蓄	酗	賁	勛	勛	煦	屿	嶼	嶼
4748	5375	5753	6366	6369	6370	6371	6772	8079	8345
屿	序	恤	洫	淅	淅	淅	歛	卹	敘
8347	8348	9335	10010	10013	10014	10318	10393		
敘	叙	旭	續	緒	緒	絮	婿		

PINYIN PRONUNCIATION IS YA12

3382 4660
涯 崖

PINYIN PRONUNCIATION IS YANG1

PINYIN PRONUNCIATION IS YANG1

908 2413 4088 4340 4348 6217 7271
 鞅 殃 映 央 鸯 泐 秧

PINYIN PRONUNCIATION IS YANG2

1542 2637 5257 6306 6508 6720 6749 7859 8645 9347
 楊 揚 瘍 洋 羊 煬 烱 佯 徉 颺
 9532 9535
 阳 陽

PINYIN PRONUNCIATION IS YANG3

5279 5282 6543 6544 7184 7938
 痒 癢 養 养 氧 仰

PINYIN PRONUNCIATION IS YANG4

1618 1621 5688 6308 6532
 样 樣 怏 漾 恙

PINYIN PRONUNCIATION IS YAN1

483 486 509 510 1101 1960 2214 2335 2337 2338
 堙 堙 焉 鄢 菸 醃 慫 剗 奄 劓
 4089 4667 5553 5650 6122 6704 6706 6707 6731 9086
 咽 崦 庵 懣 淹 煙 煙 煙 烟 燕
 9106 9139 9693 10266
 腌 腮 閤 嫫

PINYIN PRONUNCIATION IS YAN2

551	678	1143	1679	1898	2174	2179	4057	4058	4084
盐	盐	严	檐	鹽	研	研	嚴	嚴	岍
4218	4662	4688	4689	4757	5088	5265	5475	5534	5588
延	岩	巖	巖	言	顏	癌	顏	闫	阎
5592	6429	6754	6795	6802	7454	7473	7627	7730	9673
阎	沿	炎	焰	焰	筵	簷	延	延	閭
9728	9732	10258	10261						
閻	閻	妍	妍						

PINYIN PRONUNCIATION IS YAN3

245	2215	2586	2870	3563	4481	5190	6291	6755	6866
琰	魃	掩	揜	眼	罨	兗	演	剡	禡
7709	7711	7794	7795	8643	8985	8986	9381		
鼯	鼯	儼	儼	衍	獫	獫	弇		

PINYIN PRONUNCIATION IS YAN4

56	112	115	481	926	927	1854	1973	1974	2141
艳	驗	驗	堰	燕	鷺	郾	醞	醞	戾
2211	2216	2231	2385	2386	2387	2388	3065	3066	3067
厭	饜	硯	雁	贗	鴈	贗	豔	豔	豔
3120	3122	3617	3699	3700	4000	4249	4788	4824	4856
驗	驗	燕	晏	鸚	艷	唁	讌	讌	諺

PINYIN PRONUNCIATION IS YAN4

4864	5087	5474	5886	5999	6152	6756	7115	7649	8868
諺	彥	彦	宴	鴛	豔	焮	艷	偃	燄
9265	10272								
燄	嬋								

PINYIN PRONUNCIATION IS YAO1

779	780	3676	4392	4450	4451	4751	6896	7510	8013
坳	均	噍	么	么	哟	凹	袄	夭	邀
9098	9356	9949	9951	9996	10358				
腰	么	凹	凹	么	妖				

PINYIN PRONUNCIATION IS YAO2

262	263	271	299	457	1823	2801	2835	2955	4738
瑶	珧	瑤	珧	堯	輶	搖	搖	尧	嶠
4917	4934	5756	5762	5953	5956	5965	5973	6439	7912
謠	謠	搖	搖	窯	窑	窑	窑	淆	徭
7927	8401	8403	8524	8658	8666	8855	8857	9017	9020
徭	遙	颯	飭	徭	徭	遙	颯	徭	徭
9395	9396	9431	10380	10390					
肴	肴	爻	姚	姚					

PINYIN PRONUNCIATION IS YAO3

PINYIN PRONUNCIATION IS YA03

1534 2422 2940 2941 3171 4270 5944 5984 8405
 杳 歺 拗 拗 齧 咬 窅 窈 臼

PINYIN PRONUNCIATION IS YA04

1197 1359 1366 1947 8402 8856
 藥 葯 药 要 鷄 鷄

PINYIN PRONUNCIATION IS YA1

1425 2124 2212 2639 2986 3646 3781 6680
 桲 压 壓 押 鴉 鴨 呀 丫

PINYIN PRONUNCIATION IS YA2

182 872 978 1512 2120 2983 4146 6115 8614
 琊 芽 芽 桺 厓 牙 蚺 涯 衙

PINYIN PRONUNCIATION IS YA3

746 2985 3605 3627 5216
 雅 雅 啞 啞 瘕

PINYIN PRONUNCIATION IS YA4

782 1137 1839 2558 2984 4819 7173 8139 10270
 亞 亚 軋 揶 訝 訝 氦 鉅 婭

PINYIN PRONUNCIATION IS YE1

409 2038 3596
 耶 卮 噎

PINYIN PRONUNCIATION IS YE2

831	1406	1431	2520	2540	8568	8569	8574
耶	椰	椰	擲	擲	爺	爺	爺

PINYIN PRONUNCIATION IS YE3

1448	3419	7092	9901
埜	野	冶	也

PINYIN PRONUNCIATION IS YE4

878	2181	2213	3270	3271	3272	3774	4835	5174	5177
葉	頁	靨	业	業	鄴	曳	謁	夜	夜
6698	6718	9152							
燁	燁	腋							

PINYIN PRONUNCIATION IS YIE4

6259
液

PINYIN PRONUNCIATION IS YING1

171	214	1050	1541	2636	3427	3506	3507	3508	4045
瑛	璵	英	櫻	櫻	映	嬰	嬰	鸚	嬰
5191	5360	5361	5362	6765	6766	10062			
应	應	鷹	膺	螢	鶯	纓			

PINYIN PRONUNCIATION IS YING2

1147	1688	2018	4160	4161	4168	5500	5502	6279	6757
營	楹	迓	蠅	蠅	蠅	羸	羸	羸	螢
6758	6760	6761	6762	6763	6771	8929	9066		
塋	營	螢	營	螢	榮	盈	迎		

PINYIN PRONUNCIATION IS YING3

3690	5256	9939	9945	9946
影	癭	穎	穎	穎

PINYIN PRONUNCIATION IS YING4

2198	3672	9190
硬	映	媵

PINYIN PRONUNCIATION IS YIN1

1051	4257	4341	5057	5269	6098	6104	6949	7178	8689
茵	音	因	音	瘠	湮	湮	裊	氤	殷
8690	9580	9584	9586	9589	9590	10316	10363	10377	
慇	陰	陰	陰	陰	陰	姻	嫵	嫵	

PINYIN PRONUNCIATION IS YIN2

751	891	2084	2085	3174	4342	4403	5569	5858	6373
垠	鄞	霑	霑	齟	吟	吟	閭	寅	淫

PINYIN PRONUNCIATION IS YIN2

6375 8332 8854 8991 9710 10372 10375
淫 銀 蜚 狎 闇 姪 姪

PINYIN PRONUNCIATION IS YIN3

4243 5335 6630 8507 8508 9486 9569 9575 9742 9859
蚓 癰 糲 飲 飲 又 隱 隱 尹 引

PINYIN PRONUNCIATION IS YIN4

1288 1289 1290 1291 5376 5377 5378 5379 5951 7599
蔭 蔭 蔭 蔭 廕 廕 廕 廕 審 印
9357
胤

PINYIN PRONUNCIATION IS YI1

1 371 656 2106 2107 2110 2329 2640 2641 2953
一 弋 壹 医 醫 緊 欹 揖 揖 弋
4332 4422 5398 6407 6906 6911 7841 8019 8966
咿 伊 衣 漪 褱 衣 依 伊 猗

PINYIN PRONUNCIATION IS YI2

657 758 1325 2974 3537 3574 3778 3953 4974 5243
懿 圯 頤 夷 貽 貽 噫 遺 詒 癩
5798 5881 6142 6385 7307 7450 7545 7862 7872 7959
怡 宜 涕 沂 移 籜 迤 儀 儀 儀

PINYIN PRONUNCIATION IS Y12

8529	8862	9111	9943	9987	9988	9989	9990	10295
飴	迢	腴	疑	彝	彝	彝	彝	姨

PINYIN PRONUNCIATION IS Y13

1073	1298	1495	4754	5445	7674	8711	8712	8723	8747
苾	苾	椅	以	旖	倚	舫	舫	舫	舫
8748	8759	9654	9839	9947	9972				
舫	舫	以	已	乙	矣				

PINYIN PRONUNCIATION IS Y14

91	862	863	867	868	1084	1353	1809	2108	2109
驛	執	藝	執	藝	薏	艺	軼	醫	翳
2111	2398	2403	2668	2700	2844	3100	3613	3614	3758
嬰	殪	殄	挹	掖	抑	驛	囁	囁	易
3203	4159	4178	4196	4202	4235	4258	4433	4468	4690
異	蜴	螳	蟻	蚁	蚁	噫	邑	罍	嶧
4046	4867	4871	4973	5067	5089	5106	5239	5322	5380
譯	誼	議	詣	意	毅	翊	瘞	疫	亦
5381	5383	5399	5691	5694	5710	5796	6221	6309	6536
弈	奕	裔	悒	懌	憶	忆	浥	溢	義
6655	6656	6822	7039	7044	7834	7881	7900	7966	7983
益	益	义	议	议	億	佚	仡	侑	劓

PINYIN PRONUNCIATION IS YI4

8108	8251	8668	8836	8840	9145	9359	9405	9407	9492
亿	鎰	役	逸	逸	臆	义	刈	义	卩
9841	9905	9906	9907	9908	9909	9944	10086	10126	
巳	羽	翼	翼	立	立	肄	繹	縊	

PINYIN PRONUNCIATION IS YONG1

616	634	5316	5352	5402	5526	5527	5531	5713	7842
墉	雍	痾	癰	庸	雍	壅	饔	慵	傭
8237	9163	10434	10435						
鏞	臃	邕	雛						

PINYIN PRONUNCIATION IS YONG2

1118	1120	1606	1609	4055	4702
蓉	蓉	榕	榕	喁	嶸

PINYIN PRONUNCIATION IS YONG3

744	2712	2845	3935	3936	4239	4302	4889	6330	6450
涌	擁	拥	踊	踴	蛹	咏	詠	泳	涌
6451	6452	7028	7967	9462	9465	9466			
湧	湧	永	俑	甬	兪	勇			

PINYIN PRONUNCIATION IS YONG4

7940	9113
佣	用

PINYIN PRONUNCIATION IS YOU1

46	2205	4273	4453	4753	5421	5437	5656	7670	7683
擾	憂	唷	呦	幽	麇	麇	忧	優	优
7753	7757								
攸	悠								

PINYIN PRONUNCIATION IS YOU2

1234	1806	2468	3794	3991	4162	4184	5241	5461	6203
猶	輜	尤	由	邨	蚰	蚰	疣	遊	油
6270	6641	7105	8204	8404	8791	8858	8970	9006	9007
游	猷	郵	鈿	繇	魷	繇	犹	猶	猶

PINYIN PRONUNCIATION IS YOU3

1166	1930	2393	2438	4534	4537	6539
莠	酉	有	友	黝	黝	羨

PINYIN PRONUNCIATION IS YOU4

1554	2168	4354	4900	5869	6864	6865	7668	7680	7712
柚	右	囿	誘	宥	祐	祐	佑	侑	鼬
7721	8538	9617	10227						
牖	紬	又	幼						

PINYIN PRONUNCIATION IS YUAN1

PINYIN PRONUNCIATION IS YUAN1

2954	5923	5924	6351	6380	6838	6839	8867
鴛	冤	冤	淵	淵	冤	冤	鴛

PINYIN PRONUNCIATION IS YUAN2

358	360	361	477	593	851	1758	1776	2389	2797
元	黿	黿	垣	袁	芫	緣	轅	原	援
3762	4044	4511	6019	6129	8390	8955	9016	10205	10220
園	員	圓	沅	源	爰	猿	援	緣	緣

10373

媛

PINYIN PRONUNCIATION IS YUAN3

362	592	3961
沅	遠	園

PINYIN PRONUNCIATION IS YUAN4

260	1228	2390	2391	2939	8866	9547
媛	苑	願	愿	掾	怨	院

PINYIN PRONUNCIATION IS YUE1

3350	3843	4103	10185
曰	噦	噦	約

PINYIN PRONUNCIATION IS YUE4

PINYIN PRONUNCIATION IS YUE4

521	539	1411	1790	3291	3294	3775	3780	3903	3941
越	趯	越	軌	耀	耀	曜	曜	趯	趯
3945	4731	5580	5729	5730	6436	6814	7484	7619	8038
趯	嶽	閱	悅	悅	瀾	耀	籥	岳	樂
8080	8171	8303	8315	8357	9071	9127	9317	9382	9719
粵	鉞	鉤	鑰	鉤	月	刖	乐	龠	閱
9720									
閱									

PINYIN PRONUNCIATION IS YUN1

7177
氫

PINYIN PRONUNCIATION IS YUN2

44	373	855	939	2055	3753	7234	7360	9282	10002
耘	云	芸	藝	雲	昀	耘	筠	勻	紆

PINYIN PRONUNCIATION IS YUN3

2236	2411	9044	9539	9979
碩	殞	狃	隕	允

PINYIN PRONUNCIATION IS YUN4

374	1127	1358	1951	1968	3703	5066	5070	5676	5733
运	蒞	蘊	醞	醞	暈	韻	韵	愠	惲

PINYIN PRONUNCIATION IS YUN4

6724	6827	6830	8928	9766	9888	10070
煨	運	鄆	孕	熨	韞	緼

PINYIN PRONUNCIATION IS YU1

370	3684	5272	6271	10001
迂	愚	瘀	淤	紆

PINYIN PRONUNCIATION IS YU2

301	368	369	425	1182	1708	2058	2873	2875	3245
瑜	于	孟	圩	莠	榆	雩	揄	於	虞
3681	3931	4685	4908	5465	5778	5779	6392	6440	7356
禺	踰	隅	諛	於	愉	愉	漁	渝	筭
7566	7575	7606	7702	7705	8374	8375	8523	8777	9200
輿	與	與	昇	與	覷	鼯	餘	魚	腴
9366	9367	9398	9467	9536	10319	10394			
余	畚	俞	予	隅	娛	好			

PINYIN PRONUNCIATION IS YU3

2017	2019	3023	3167	3967	4074	4337	4800	5301	5359
雨	雨	与	齒	圉	圉	噢	語	痠	庾
5850	5971	7570	7602	7652	7686	8049	9903	9904	10444
宇	窳	與	與	偃	佺	禹	羽	羽	与

PINYIN PRONUNCIATION IS YU4

119	228	480	854	1633	1716	1717	1718	1853	2394
馭	玉	域	芋	鬱	鬱	鬱	鬱	或	郁
3126	3682	3691	3804	4139	4401	4721	4955	4956	5181
馭	遇	昱	域	蛾	喻	峪	諭	諭	廬
5324	5325	5513	5551	5809	5885	6382	6453	6725	6973
瘉	癒	育	國	譽	寓	浴	潁	煜	裕
7467	7547	7555	7573	7604	8123	8362	8495	8553	8554
籲	毓	毓	譽	譽	鉦	籲	飫	欲	慾
8649	8650	8651	8652	8992	9399	9400	9468	9472	9473
御	禦	御	禦	獄	逾	愈	預	齏	鵠
9483	9656	9690	9868	10282	10292				
豫	聿	闕	嚮	謳	謳				

PINYIN PRONUNCIATION IS ZAI1

476	594	5901	10438
栽	哉	灾	災

PINYIN PRONUNCIATION IS ZAI3

478	4552	4687	5895
載	囡	崽	宰

PINYIN PRONUNCIATION IS ZAI4

2012 2016 2152 7613

再 再 在 載

PINYIN PRONUNCIATION IS ZANG1

2461 3493 3498 3513 4017 4544 9077 9196

臧 贓 賊 贓 髒 髒 贓 贓

PINYIN PRONUNCIATION IS ZANG3

4624

壯

PINYIN PRONUNCIATION IS ZANG4

965 966 9088 9151

塋 葬 臟 脏

PINYIN PRONUNCIATION IS ZAN1

6620 6621 7353 7398

簪 簪 簪 簪

PINYIN PRONUNCIATION IS ZAN2

4371 4372 7935 7936 8945 8947

簪 簪 簪 簪 簪 簪

PINYIN PRONUNCIATION IS ZAN3

PINYIN PRONUNCIATION IS ZAN3

517 530 1760 2514 7887
趲 趲 趲 攢 攢

PINYIN PRONUNCIATION IS ZAN4

350 1818 4768 4898 7209
贊 斬 讚 讚 贊

PINYIN PRONUNCIATION IS ZAO1

1863 3837 6581
遭 糟 糟

PINYIN PRONUNCIATION IS ZAO3

1128 2021 2023 3397 6215 9485 9624
藻 束 束 早 澡 蚤 蚤

PINYIN PRONUNCIATION IS ZAO4

3868 4083 4331 4842 5687 5935 5936 6692 6728 7203
躁 噪 噪 噪 燥 竈 竈 灶 燥 造
7448 7979 8004
造 皂 皂

PINYIN PRONUNCIATION IS ZAI

3680
啞

PINYIN PRONUNCIATION IS ZA2

2025 2201 4325 5197 6969 9327 9330

匝 砸 咱 雜 襪 柰 雜

PINYIN PRONUNCIATION IS ZE12

3488 3489

賊 賊

PINYIN PRONUNCIATION IS ZENG1

653 4493 5731 6687 7149 10132

增 罾 憎 曾 矰 曾

PINYIN PRONUNCIATION IS ZENG4

3520 6688 6689

贈 甌 甌

PINYIN PRONUNCIATION IS ZEN3

7196

怎

PINYIN PRONUNCIATION IS ZEN4

4767 4818

諛 諛
言 言

PINYIN PRONUNCIATION IS ZE2

PINYIN PRONUNCIATION IS ZE2

213 2669 3406 3504 4569 6223 7336 7351
責 擇 嘖 則 憤 澤 蹟 簣

PINYIN PRONUNCIATION IS ZE4

1324 2395 3540
蹟 仄 晁

PINYIN PRONUNCIATION IS ZHA11

2693 5115 5471 5483 9980
摘 齋 齋 齋 𪛗

PINYIN PRONUNCIATION IS ZHA12

5916
宅

PINYIN PRONUNCIATION IS ZHA13

5957
窄

PINYIN PRONUNCIATION IS ZHA14

3190 5312 5837 7576
砦 瘵 寨 債

PINYIN PRONUNCIATION IS ZHANG1

232 1578 5058 5063 5411 5427 6247 8808 8993 9849
璋 樟 章 彰 𪛗 𪛗 漳 鯮 獐 張

PINYIN PRONUNCIATION IS ZHANG1

9851 9860 10330

張 張 璋

PINYIN PRONUNCIATION IS ZHANG3

905 3320 7948

鞫 掌 仇

PINYIN PRONUNCIATION IS ZHANG4

1503 2480 3455 3484 3490 3502 4567 4571 4577 4588

杖 丈 璋 賬 賬 賬 帳 帳 帳 幛

4694 5208 5211 5246 5270 6487 6488 6491 6589 7685

嶂 瘡 瘡 瘡 瘡 漲 漲 漲 杖 仗

9072 9080 9114 9541

脹 脹 脹 障

PINYIN PRONUNCIATION IS ZHAN1

2082 3198 3206 3541 3951 4356 4926 5037 5446 5457

霑 沾 占 瞻 沾 瞻 瞻 氈 旌 旃

6161 6594 7166 7167 8473 8769

沾 粘 毡 氈 饅 詹

PINYIN PRONUNCIATION IS ZHAN3

1013 1835 2906 2959 4649 9773

斬 輓 振 盞 斬 展

PINYIN PRONUNCIATION IS ZHAN4

826	934	1509	1816	3204	4076	5036	5056	6042	6959
戥	蘸	棧	暫	战	戰	顫	站	湛	綻
7740	10112								
佔	綻								

PINYIN PRONUNCIATION IS ZHA01

2847	3750	8186
招	昭	釗

PINYIN PRONUNCIATION IS ZHA02

6522	6537	6750	6751
着	着	燂	燂

PINYIN PRONUNCIATION IS ZHA03

2600	6411	8388	8679
找	沼	𠂇	爪

PINYIN PRONUNCIATION IS ZHA04

524	535	1752	3440	3751	4484	4941	5458	6162	6799
趙	趙	櫟	壘	照	罩	詔	旄	淖	炤
7007	7021	7472	8581	9250	9319				
肇	肇	筰	兆	召	兆				

PINYIN PRONUNCIATION IS ZHA1

1754 2554 2931 3649 6078
 紮 揸 紮 渣 渣

PINYIN PRONUNCIATION IS ZHA2

1209 1753 2928 3772 5558 7466 7722 7723 7724 8197
 劄 札 扎 哱 卮 劄 插 插 插 鋤
 9699
 間

PINYIN PRONUNCIATION IS ZHA3

3535 8818
 眨 鮓

PINYIN PRONUNCIATION IS ZHA4

1561 1608 1697 1983 2728 2764 4210 4283 4310 4316
 柵 榨 柵 榨 榨 榨 蚱 咤 咋 吒
 4896 5291 6777 7193
 詐 疰 炸 乍

PINYIN PRONUNCIATION IS ZHENG1

1294 3524 4718 4920 5307 7468 8132 8290 8434 8605
 蒸 爭 爭 爭 癥 箏 鉦 錚 爭 征

PINYIN PRONUNCIATION IS ZHENG1

8631 9018 9603
徵 掙 丞

PINYIN PRONUNCIATION IS ZHENG3

1075 2892
整 拯

PINYIN PRONUNCIATION IS ZHENG4

505 514 2804 4774 4961 5213 6564 6642 7034
正 政 掙 証 證 症 郑 鄭 证

PINYIN PRONUNCIATION IS ZHEN1

248 265 303 812 816 827 1303 1304 1388 1390
玆 玆 珍 蓁 蓁 斟 真 真 榛 榛
1430 1523 1931 1932 1962 1963 2188 2225 3006 3007
椹 楨 甄 甄 甄 甄 硯 砧 臻 臻
3202 3374 4580 6004 6006 6871 6872 7386 7742 8128
貞 瞋 幘 臻 臻 禎 禎 箴 偵 針
8163
鍼

PINYIN PRONUNCIATION IS ZHEN3

1628 1831 3981 4959 5328 7237 9228 10021 10196
枕 軫 畛 診 疹 稕 胗 縝 紕

PINYIN PRONUNCIATION IS ZHEN4

1987	2053	2063	2507	2576	3485	3495	6840	6843	8150
醜	震	震	振	振	賑	賑	鵠	鵠	鎮
8151	9178	9179	9502	10256	10288				
鎮	朕	朕	陣	娠	娠				

PINYIN PRONUNCIATION IS ZHE1

719	4265	5138
螫	噓	遮

PINYIN PRONUNCIATION IS ZHE2

642	2272	2809	2810	2811	2922	4144	4857	4858	5605
螫	礫	折	哲	蜇	摺	蜥	謫	適	懾
5612	5793								
懾	習								

PINYIN PRONUNCIATION IS ZHE3

688	689	715
者	者	赭

PINYIN PRONUNCIATION IS ZHE4

564	1092	1491	3845	3881	4886	5139	5480	6136
喆	蔗	柘	跖	蹠	這	廬	这	浙

PINYIN PRONUNCIATION IS ZHI1

1149	1494	1673	1674	1764	2533	2744	4209	6023	6901
芝	枝	梔	梔	支	摺	擲	蚰	汁	祇
6998	7146	7824	8599	8600	9095	9212	9238	9925	10097
之	知	隻	卮	卮	肢	胝	脂	出	織

10244
织

PINYIN PRONUNCIATION IS ZHI2

395	397	639	647	801	803	1300	1315	1442	1443
职	職	執	繫	职	職	直	直	植	植
2400	2401	2698	2859	3894	7638	7639	7734	10297	
殖	殖	撫	執	躋	值	值	侄	姪	

PINYIN PRONUNCIATION IS ZHI3

512	987	1556	2929	3160	3279	3855	4339	5795	6154
址	芷	枳	指	止	黹	趾	只	悵	汙
6869	6870	8931	9050	9526	9833	9941	10179		
祉	祉	乂	帑	陟	咫	旨	紙		

PINYIN PRONUNCIATION IS ZHI4

641	644	645	676	1515	1791	3005	3009	3011	3012
贄	摯	鷲	志	桎	輕	至	致	致	郅

PINYIN PRONUNCIATION IS ZHI4

3915	4147	4476	4477	4586	4590	4596	4642	4780	5125
躋	蛭	置	置	帙	幟	帙	峙	誌	袞
5212	5214	5623	5624	5643	5855	5943	6056	6060	6500
痔	痣	懷	懷	懷	寘	窒	滯	滯	治
6730	6739	7116	7117	7148	7155	7294	7297	7325	7326
炽	熾	制	製	智	雉	秩	稚	穉	穉
7327	8414	8590	8591	8595	8853	8873	8880	8896	8903
穉	豸	質	質	質	炙	觶	觶	觶	觶
9169	9527	9528	9529	9593	9594	9985	9986	10049	10050
脛	陟	隲	隲	隲	隲	隲	隲	緻	緻

PINYIN PRONUNCIATION IS ZHONG1

1879	3792	4006	4035	5006	8203	8226	8273	8354	8940
衷	中	盅	忠	衷	鍾	鐘	鍾	钟	蟲
10176									
終									

PINYIN PRONUNCIATION IS ZHONG3

662	3902	6831	7295	9132	9197
塚	踵	冢	種	腫	腫

PINYIN PRONUNCIATION IS ZHONG4

PINYIN PRONUNCIATION IS ZHONG4

4494 4495 4498 4499 7332 7785 8071 8072 8074 8075
眾 眾 眾 眾 重 仲 眾 眾 眾 眾

8557

人人

PINYIN PRONUNCIATION IS ZHOU1

3532 4378 6313 6690 7918 7919 8692 8728 9119 9121
賄 啁 洲 州 侑 侑 舟 舟 周 週

9867

粥

PINYIN PRONUNCIATION IS ZHOU2

1798 10309

軸 妯

PINYIN PRONUNCIATION IS ZHOU3

7495 9110 9741

筵 肘 帚

PINYIN PRONUNCIATION IS ZHOU4

3977 4091 4092 4843 5887 7283 7284 7394 8919 9305

胄 呪 咒 詛 宙 瓠 瓠 籀 皺 皺

9639 9832 10043 10186 10249

晝 昼 紂 縐 纒

PINYIN PRONUNCIATION IS ZHUAI3

3866

跣

PINYIN PRONUNCIATION IS ZHUAI4

2649

拽

PINYIN PRONUNCIATION IS ZHUANG1

1069

1391

1582

3330

3339

4625

4640

5126

6601

莊 椿 桩 装 妝 裝 妝 庄 粧

PINYIN PRONUNCIATION IS ZHUANG4

2688

3329

3331

4623

4627

5062

5065

撞 壯 狀 壯 狀 戇 戇

PINYIN PRONUNCIATION IS ZHUAN1

378

1844

1845

1846

2197

4663

4664

专 專 甄 甄 磚 耑 顛

PINYIN PRONUNCIATION IS ZHUAN3

3654

轉

PINYIN PRONUNCIATION IS ZHUAN4

PINYIN PRONUNCIATION IS ZHUAN4

1752 2915 3510 3517 4968 7505 8526
轉 撰 賄 賺 譔 篆 饌

PINYIN PRONUNCIATION IS ZHUA1

2658 2817
搨 抓

PINYIN PRONUNCIATION IS ZHUI1

105 3113 7809 8061 8279
騅 騅 佳 迨 錐

PINYIN PRONUNCIATION IS ZHUI4

290 623 2259 5701 8525 9555 9556 10152 10201
贅 贅 碰 惴 餽 墜 墜 縋 綴

PINYIN PRONUNCIATION IS ZHUN1

4852 5975 9222
諄 寃 肫

PINYIN PRONUNCIATION IS ZHUN3

6357 7069 7070 7810 7811
準 准 準 隼 隼

PINYIN PRONUNCIATION IS ZHUO1

1522 2655 2924 3199 3201 6132
棹 捉 拙 卓 桌 涿

PINYIN PRONUNCIATION IS ZHUO2

176	1352	1501	2000	2269	2921	3603	3621	3745	3858
琢	茁	琢	酌	斫	擢	斲	斲	啄	蹕
4012	6216	6224	6497	6800	7741	8213	9054		
詠	浊	濁	濯	灼	倬	鑄	斲		

PINYIN PRONUNCIATION IS ZHU1

251	1158	1565	1632	2260	2441	4208	4781	4782	4894
珠	茱	赭	株	硃	豬	蛛	諸	諸	誅
6133	6335	7113	7880	8262	8956				
瀦	洙	朱	侏	銖	猪				

PINYIN PRONUNCIATION IS ZHU2

1564	2444	3869	6729	6732	7227	7228	7341	7342	7361
朮	逐	躅	烛	燭	竹	竹	𪔐	竺	筑
8957									
猪									

PINYIN PRONUNCIATION IS ZHU3

691	692	2679	3564	3565	4427	4428	4430	4755	4990
煮	煮	拄	矚	矚	囁	囁	囁	、	主
5410	5426	6032							
塵	塵	渚							

PINYIN PRONUNCIATION IS ZHU4

93	697	865	866	1115	1566	1726	3102	3515	3544
馬駐	翦	著	著	苧	柱	杼	駐	貯	助
4179	4850	5082	5872	6237	6736	6884	6885	7359	7362
蛙	註	佇	宁	注	炷	祝	祝	箸	築
7409	7827	7850	8120	8127	8137	8349	10115		
筋	住	佇	鑄	鑄	鑄	鑄	紵		

PINYIN PRONUNCIATION IS ZII

53	528	529	1361	1365	1371	1841	3192	3651	4892
耜	趲	趲	茲	孳	菑	輜	貲	吱	諮
6073	6312	6506	6675	6679	7077	7078	7080	7081	7083
滋	滋	淄	茲	孳	咨	資	柒	恣	姿
8342	9491	9609	10226						
鎰	孖	孜	緇						

PINYIN PRONUNCIATION IS ZI3

1575	3193	3197	6295	6628	7322	7487	7968	9488	10285
梓	訾	紫	滓	籽	秣	第	仔	子	姊
10329	10392								
姊	姊								

PINYIN PRONUNCIATION IS ZI4

3191 3404 5988 6011 7972

眚 眦 字 漬 自

PINYIN PRONUNCIATION IS ZONG1

24 114 117 240 439 1594 1710 1720 3044 3121

鬃 驥 駿 琮 鬃 棕 櫻 櫻 鬃 驥

3124 3886 3917 5849

驥 踪 蹤 宗

PINYIN PRONUNCIATION IS ZONG3

6685 7910 7945 10131 10153

总 僇 僇 總 總

PINYIN PRONUNCIATION IS ZONG4

6606 6623 6625 10111 10160 10165 10248

粽 櫻 櫻 綜 縱 縱 縱

PINYIN PRONUNCIATION IS ZOU1

111 412 413 416 417 834 835 838 839 3119

騶 鄒 鄒 鄒 鄒 鄒 鄒 鄒 鄒 騶

4559 4772 4785 4947 7042 8779 8783 8920 9306 9497

騶 諏 諏 譚 譚 鯁 鯁 邹 鄒 陬

PINYIN PRONUNCIATION IS ZOU1

9501

取

PINYIN PRONUNCIATION IS ZOU3

515

走

PINYIN PRONUNCIATION IS ZOU4

63	64	65	66	69	70	71	72	134	2505
馬取	馬取	馬取	馬取	馬取	馬取	馬取	馬取	奏	揆
3074	3075	3076	3077	3080	3081	3082	3083		
馬取	馬取	馬取	馬取	馬取	馬取	馬取	馬取		

PINYIN PRONUNCIATION IS ZUAN1

2765	3820	3901
攢	躐	躐

PINYIN PRONUNCIATION IS ZUAN3

7407	9999	10138
纂	績	績

PINYIN PRONUNCIATION IS ZUAN4

2771	2840	2841	8126	8177	8267	8352
攢	搭	搭	鑽	鑽	鑽	鑽

PINYIN PRONUNCIATION IS ZUI3

3195 3196 3947 3948
𪗇 𪗇 𪗇 𪗇

PINYIN PRONUNCIATION IS ZUI4

1003 1006 1654 1980 3400 3424 4482 4485
𪗇 𪗇 𪗇 𪗇 𪗇 𪗇 𪗇 𪗇

PINYIN PRONUNCIATION IS ZUN1

650 1625 6643 6644 6645 7132
𪗇 𪗇 𪗇 𪗇 𪗇 𪗇

PINYIN PRONUNCIATION IS ZUN3

2745 4295
𪗇 𪗇

PINYIN PRONUNCIATION IS ZUO1

4040 4041
𪗇 𪗇

PINYIN PRONUNCIATION IS ZUO2

3709
𪗇

PINYIN PRONUNCIATION IS ZUO3

PINYIN PRONUNCIATION IS ZU03

2117 7667
左 佐

PINYIN PRONUNCIATION IS ZU04

1037 1990 3277 3278 5363 5740 6895 7640 7884 8550
柞 酢 鑿 凿 座 乍 祚 做 作 坐
9195
昨

PINYIN PRONUNCIATION IS ZU1

7260
租

PINYIN PRONUNCIATION IS ZU2

2701 3982 5196 5450 8240
猝 足 卒 族 鏃

PINYIN PRONUNCIATION IS ZU3

2409 4831 6873 6874 8552 8624 9533 10061
殂 詛 祖 祖 俎 徂 阻 組